

# Orange Box and Orange Box Controller V3.0.0.88

April 2025



The Ora	inge	Box	2
1.1	Intro	oduction	2
1.2	DMI	Cards	2
1.2.	1	Compatible DMI Cards	2
1.2.	2	Inserting a DMI Card	3
1.2.	3	DMI Card Pin outs and Hardware setup.	3
1.2.	4	DMI Card Firmware in Orange Box Controller V3.0.	3
Orange	Вох	Controller	4
2.1	Intro	oduction	4
2.1.	1	Orange Box Controller connections and Drivers.	4
2.2	Insta	alling Orange Box Controller	4
2.2.	1	Installation Instructions.	5
2.3	The	Orange Box Controller Interface	5
2.3.	1	OBC Options menu.	6
2.3.	2	Sync Source Setup and display	6
2.3.	3	Upgrading DMI Card Firmware	7
DMI Ca	rd so	ettings	8
3.1	Gen	eral	8
3.2	DMI	AES	8
3.3	DMI	HYDRA 2	9
3.4	DMI	MADI B & DMI MADI C	9
3.4.	1	DMI MADI C Hardware Switch	9
3.4.	2	MADI Mode Selector1	0
3.4.	3	MADI Connection Details1	1
3.4.	4	96 kHz MADI1	2
3.4.	5	Port Mode1	2
3.4.	6	MADI SRC1	3
3.5	DMI	Optocore1	4
3.5.	1	Overview1	4
3.5.	2	Channel Count Setup1	4
3.5.	3	Optocore System Clock1	5
3.6	DMI	Dante 64@961	5
3.7	DMI	KLANG1	6
3.8	DMI	AVB1	7



# The Orange Box

## 1.1 Introduction.

The Orange Box is a 2U Bi-Directional Multi-Channel audio format converter that utilises DiGiCo's range of DMI cards. The box has two DMI ports:- DMI 1 (MASTER) which is used to provide the Orange Box's sync source if no Work Clock is present and DMI 2 (SLAVE).

## 1.2 DMI Cards.

## 1.2.1 Compatible DMI Cards.

The Orange Box with Orange Box Controller supports the following DMI Cards.

DMI ADC	16 Ch Line input card 48/96kHz
DMI DAC	16 Ch Line output card 48/96kHz
DMI AES	16 AES IO card with SRC 48/96kHz
DMI Aviom	16 Ch D16 Aviom Output Card 48/96kHz
DMI HYDRA 2	56 IO Calrec Hydra 2 interface 48kHz only
DMI DANTE	4/32 Ch DANTE IO card 48/96kHz
DMI DANTE 64@96	64 Ch Dante card c/w SRC 48/96kHz
DMI MADI B	128/64 Ch MADI BNC IO Card 48/96kHz
DMI MADI C	128/64 Ch MADI Cat5e IO Card 48/96kHz
DMI Optocore	128/64Ch Optocore IO Card 48/96kHz
DMI Waves	64Ch Waves SoundGrid IO Card 48/96kHz
DMI Mic	8 Ch Mic Pre Amp 48/96kHz
DMI ME	A&H Personal Monitoring System 48/96kHz
DMI KLANG	64 Input into 16 immersive mixes 48/96kHz
DMI AVB	64 Channel Milan IO Card 48/96kHz

Each release of Orange Box Controller will contain current DMI card firmware for use with that release. Please see section 1.2.4 of this document for the Firmware contained within this release.

*Please note that compatible DMI firmware may vary between current Orange Box and SD/S/Quantum series releases.* 



#### 1.2.2 Inserting a DMI Card.

IMPORTANT:- The Orange Box should be powered Off when inserting or removing any DMI card.

Slide the DMI card into the locating guides on each side of the port as show below.



Slowly push the card in until it clicks into place and secure each card into the Orange Box using the four retaining screws.

#### 1.2.3 DMI Card Pin outs and Hardware setup.

DMI ADC, DAC and AES use 25 pin DSub connectors. In addition, DMI MADI C has physical switches on it that determine its CAT5e wiring configuration. This is specified in TN 339 which in the Document Folder of **Orange Box Controller**, can be downloaded from <u>https://digico.biz/base\_product/all-technical-notes/</u> or requested from DiGiCo Support – <u>support@digiconsoles.com</u>

#### 1.2.4 DMI Card Firmware in Orange Box Controller V3.0.

DMI Card	Processor Version	FPGA Version	
DMI ADC	V83	08/12/2015	
DMI DAC	V83	08/12/2015	
DMI AES	V83	08/12/2015	
DMI AVIOM	V83	08/12/2015	
DMI HYDRA 2	V222	08/12/2015	
DMI DANTE*	V83	02/03/2016	
DMI DANTE 64@96*	V104	27/10/2021	
DMI DANTE 64@96z*	V105	27/03/2023	
DMI MADI B	V168	28/02/2019	
DMI MADI C	V168	28/02/2019	
DMI OPTOCORE	V196	28/02/2019	
DMI WAVES	V83	22/02/2016	
DMI MIC	V243	21/06/2019	
DMI ME	V238	04/02/2019	
DMI KLANG**	N/A	N/A	



DMI AVB	N/A	N/A

\*Additional Dante firmware updates are manged via Dante Controller. \*\* DMI KLANG firmware is available from https://www.klang.com/en/downloads

## **Orange Box Controller**

## 2.1 Introduction

The **Orange Box Controller (OBC)** program allows configuration and firmware updates of the DMI cards contained within the Orange Box.

Once the DMI cards have been configured using OBC, OBC can be disconnected, and the cards will return in the same state after every power cycle.

If a card is replaced, then OBC should be connected again to configure the new card as required.

**OBC** is currently compatible with Windows XP, Windows 7, Windows 8 and Windows 10.

## 2.1.1 Orange Box Controller connections and Drivers.

**OBC** uses a standard FTDI USB to Serial Adaptor, the driver for which should automatically install on first connection. If automatic installation does not occur, the drivers are available from <a href="http://www.ftdichip.com/FTDrivers.htm">http://www.ftdichip.com/FTDrivers.htm</a>

As an example, the picture below shows Windows Device Manager with an Orange Box connected to the PC using a standard USB A-B cable. Each DMI port is controlled by a separate COM port. Here, the Orange Box has been assigned COM ports 60 & 61. The COM port assignment is managed by Windows and the assignment will differ on each PC.

File Artico View Help				
Gomputer				
E Sector des				
List and the second sec				
i Sprotovova anves				
I I I I I I I I I I I I I I I I I I I				
(i) him Kaukeande				
<ul> <li>Weyboards</li> <li>Wre and other neithing devices</li> </ul>				
<ul> <li>B Notema</li> </ul>				
Notres				
Im Network adapters				
Ports (COM & LPT)				
BT Port (COM15)				
BT Port (COM16)				
BT Port (COM17)				
BT Port (COM18)				
J BT Part (COM19)				
- J BT Port (COM20)				
- J BT Port (COM21)				
BT Port (COM22)				
BT Port (COM6)				
BT Port (COM7)				
US8 Senal Port (COM60)				
y Use Senal Port (COM61)				
<ul> <li>A Processors</li> <li>A Port and DAD controllers</li> </ul>				
Sec up Digital back controllers				
<ul> <li>B. Sound video and name controllers</li> </ul>				
Sustem devices				
a det Universal Serial Pus controllers				

## 2.2 Installing Orange Box Controller

The Orange Box Controller Installer will install the current version on to your PC.

It is currently compatible with Windows XP, Windows 7, Windows 8 and Windows 10.

The installer contains the Orange Box Controller program as well as all current DMI card firmware.

The installer will create the required folders in C:\Program Files\DiGiCo\Orange Box Controller. DMI firmware files are copied to C:\ProgramData\DiGiCo\Orange Box Controller\Firmware



#### 2.2.1 Installation Instructions.

- 1. Download the latest version of the Orange Box Controller Installer package from <u>https://digico.biz/base\_product/orange-box/</u>
- 2. Unzip the installer package
- 3. Double click on DiGiCo\_Orange\_Box\_Controller\_Installer\_VXXXXX.exe. The Installer can be run from either the computer or an attached USB drive.
- The welcome screen will appear. Click on Install. Note that clicking Uninstall will only uninstall OBC V3.0 or higher. It will not uninstall any earlier versions.
- 5. The License Agreement window will now appear. The option to create a desktop shortcut is selected by default. Please click to accept the License terms and then click **Install.**
- 6. Once complete, the Finish window will appear. Click on **Exit** to close this window.

## 2.3 The Orange Box Controller Interface

Version 3 of the OB interface contains an updated GUI, additional features as well as supporting new DMI functionality.

When connected to an Orange Box, the OBC main *Control* display shows the contents of the two DMI ports, Orange Box Sync information plus any data or controls specific to each DMI card.

The picture below shows the OBC main *Control* page. There is a DMI MADI B in DMI 1 MASTER port and DMI AES in DMI 2 SLAVE port.

Orange Box Controlle	er v3.0.0.56 (Beta)				– 🗆 ×
Ξ					
96001 Hz	MI MADI-	Master 19°c	96001 Hz	DMI A	ES Slave 20°c
Port A Sync:	OK Port B	Sync: OK			
Sync Select:	uto Wordclock N	ADI A MADI B			
Sunc Sourco:					
Sync Source:				-	•
	Controls Update			Controls Up	odate
	Controls			Contro	ols
	MADI A	MADI B		Input Socket S	Selection 🛛 🖉
In Channels	57	57	A	ES AES AES AES AES AES 1 2 3 4 5	AES AES AES AES 6 7 8
Out Channels	96000 Hz (Smux) 57	96000 Hz (Smux) 57	AES	Samula Data	SPC
Sync	Locked	Locked	AES	Sample Rate	SKC
Connection	Console	Console	1	48000 Hz	
MADI Mode	Auto	DiGiCo	2	48000 Hz	<ul> <li>Image: A set of the set of the</li></ul>
			3	48000 Hz	Image: A start of the start
SMUX	(: On	Off	4	48000 Hz	<ul> <li>Image: A set of the set of the</li></ul>
Port Mode	Redundant	Dual	5	0 Hz	<ul> <li>Image: A set of the set of the</li></ul>
SRC To DMI 2	2: Off 48	kHz 96kHz	6	0 Hz	<ul> <li>Image: A set of the set of the</li></ul>
SPC State	Thactive		7	0 Hz	
SKC State	mactive		8	0 Hz	<b>/</b>

Since not all cards have variable setting, a control panel will only be display when appropriate.

#### 2.3.1 OBC Options menu.

Clicking on the **menu** icon in the top left-hand corner of OBC will open the **Options** Menu. When this menu is open, the DMI card view will be blurred.

Orange Box Controller v3.0.0.56 (Beta)	- 50 - 17 - 2015 I I	– 🗆 X
Options 🗰 🖸 Open Firmware Folder		
View Licensing		

Items that can be accesses in this Menu are:

- The DMI firmware folder.
- The Documentation folder
- The Software Licensing agreement

The **Options** menu can be closed at any time by clicking the arrow in the top right corner of the options menu.

#### 2.3.2 Sync Source Setup and display

The Orange Box Clock is controlled by the DMI card in the MASTER (DMI 1) port. Any DMI card in the MASTER port will show its clocking options in its *Sync* panel as shown below.

🌚 Orange Box Cont	roller v3.0.0.56 (Beta)			- 🗆 X
Ξ				
96001 Hz	DMI MADI-B Master 19°c	96001 Hz	DMI AES	Slave 20°c
Port A Sync:	OK Port B Sync: OK			
Sync Select:	Auto Wordclock MADI A MADI B			
Sync Source:	MADI A			

When set to **AUTO**, the sync priority for that card will be as shown. In the case of the MADI card shown above, clock priority is **Word Clock>MADI A>MADI B**. Each DMI card shows its available Sync Source options. The **Sync Source** in use is displayed under the **Sync Select**.

If the *Sync Select* is not set to *AUTO* and a specific Sync has been selected and that source becomes unavailable or the DMI card cannot lock to the selected Sync source, the DMI card will revert to its internal clock and the *Sync Source* will show **FreeRun**.

In the top left corner of DMI 1 is the sample rate display showing the Current sample rate of DMI 1The DMI card in the SLAVE (DMI 2) port will always be clocked to the MASTER (DMI 1) port. The sample rate display in



the top left corner of DMI 2 I the sample rate provided from DMI1 > DMI 2. If any SRC is enabled, this will show the internal Sample Rate of DMI 2.

### 2.3.3 Upgrading DMI Card Firmware

When OBC is started, it will check the DMI Firmware Codes are up to date with the codes contained within the Orange Box Controller Folder. If either DMI card requires a change in firmware the **Update Code** tab will automatically be selected.

In *Update*, the code the DMI card is currently running and the available code is displayed. If an update is required, the tick in the Update column will be replaced by a Green arrow and **Update Required!** will be displayed.



The picture below shows the *Update* section for both DMI ports. Both cards are running up to date codes.



IMPORTANT:- Remove ALL Audio connections from the DMI cards before beginning the update process.

Clicking *Update All* will update both the Processor and FPGA codes. Alternatively, each code can be individually updated by clicking on the tick in the *Update* column.

The update process can be run simultaneously on both DMI cards if required.

Please note:- Firmware packaged with OBC maybe different to the DMI firmware included in the current S/SD/Quantum releases, 4rea4 or KLANG Konductor. OBC only supports the firmware packaged with each OBC release.



# **DMI Card settings**

## 3.1 General

In addition to *Sync Source* Selection, <u>DMI AES</u>, <u>DMI H2</u>, <u>DMI MADI B</u>, <u>DMI MADI C</u>, <u>DMI Dante 64@96</u>, <u>DMI KLANG</u> and <u>DMI Optocore</u> have variable settings which are adjusted using the OBC.

These settings are stored on the card until either the Firmware is changed or the DMI card is used in a DiGiCo S/SD/Quantum Console, 4rea4 or KLANG Konductor.

This section will detail the possible settings for each card.

Please note:-

DMI Dante card will need Dante Network configuration in addition to its Sync Source settings. All DANTE devices should be configured using Dante Controller which is available from:-

https://my.audinate.com/support/downloads/dante-controller

DMI Waves Card will need Soundgrid Network configuration in addition to its Sync Source settings. This is done using either Waves MultiRack, SuperRack or SoundGrid Studio, all of which are available from:-

https://www.waves.com/products

## 3.2 DMI AES

The DMI AES card has SRC controls on each pair of inputs. The default setting for the SRCs is **ON**.



OBC will also display the incoming sample rate of each AES stream.

The AES outputs do not have SRCs and will therefore be at system sample rate.



## 3.3 DMI HYDRA 2

The DMI H2 card requires an ID to be set before joining a Hydra 2 network. The Hydra Network must be running V3.2 or above software.

Please note the DMI Hydra card will only work when in the SLAVE Port of the Orange Box.



## 3.4 DMI MADI B & DMI MADI C

## 3.4.1 DMI MADI C Hardware Switch

DMI MADI C has a physical hardware switch which sets whether the card is acting as a "console" or "rack". The switch is located on the main pcb to the rear of the RJ45 connectors as shown below.



Further detail on this are in TN339 which is available from <a href="https://digico.biz/base\_product/all-technical-notes/">https://digico.biz/base\_product/all-technical-notes/</a>

#### 3.4.2 MADI Mode Selector

At the bottom of the OBC MADI DMI display is a **MADI type** connection. When the DMI card is in the Master slot there are two options, **Auto** & **DiGiCo**. When the DMI card is in the slave slot there are three options, **Auto**, **DiGiCo** & **64CH** 

Controls			Controls		
	MADI A	MADI B		MADI A	MADI B
In Channels			In Channels		
In Sample Rate	96000 Hz (Smux)	96000 Hz (Smux)	In Sample Rate	0 Hz	0 Hz
Out Channels			Out Channels	64	64
Sync	Locked	Locked	Sync	Not Locked	Not Locked
Connection	Console	Console	Connection	NoDevice	NoDevice
MADI Mod	Auto	DIGICO	MADI Mode:	Auto	GICO 64 CH

**Auto** – When **Auto** is selected, the DMI card will set its transmit channel count and sample rate to match that of the received MADI stream.

When connected to an SD Series console, it will also detect and respond to DiGiCo CH57 Control Data where applicable and report the Orange Box as an IO Device.

The picture below shows an SD series Audio IO Page. The Console is connected to an Orange Box with MADI with a DMI MADI in the MASTER port and a DMI AES in the SLAVE port. The DMI MADI type is set to **Auto**.

Conforming all ports in Audio IO detects the Orange Box as an IO Device type. The DMI AES in the SLAVE port is also detected and the card slots are populated to allow for routing within the console.



If the SLAVE was a DANTE DMI, Audio IO would report 64 DANTE IO.

**DiGiCo** – When **DiGiCo** is selected, the DMI MADI card no longer responds to DiGiCo Ch57 control Data being received from an SD series console but acts as a pass-through device.

An additional function of the DMI MADI card is to allow the transparent transportation of DiGiCo CH57 Control Data, either as a MADI extender or across and 3 Party Digital Network. This allows an SD Series rack to be detected and controlled without a direct connection.



Here is an example.

SD Console>MADI>Orange Box MADI/DANTE>DANTE Network>Orange Box DANTE/MADI>SD Rack.

- The SD console is connected using BNCs to an Orange Box configured as MADI/DANTE.
- A second Orange Box configured as DANTE/MADI is connected to an SD Rack with BNC.
- Using OBC, in both Orange Boxes set DMI MADI Type to DiGiCo.
- Using DANTE Controller, create a 57CH Bi Directional connection between the two DMI DANTE cards.
- When Conform all ports is pressed in Audio IO, the console will report the SD rack as a device type and the console will have full control over all socket parameters eg, gain, +48v, pad.

In the above set up, both Orange Boxes transparently pass the DiGiCo control data across the DANTE Network allowing the console to directly communicate with the SD Rack.

**64CH** – When **64CH** is selected, the MADI channel RX/TX count is fixed to 64 Channels and the DMI card will not respond to DiGiCo Ch57 Control Data. The **SRC** Controls also become active and the **Device Connected At** sample rate must be defined.

Note - When a DMI MADI card is in the Master Slot, it is assumed that BOTH the MADI in & MADI out are connected to another device.

#### 3.4.3 MADI Connection Details

Below the **Controls** label are two columns labelled **MADI A** and **MADI B**, one for each connection to the DMI card. The following information is displayed in each box:-

- In Channels Number of MADI channels being received.
- In Sample Rate Sample rate of the connected MADI input.
- Out Channels Number of channels in the outgoing MADI Stream.
- Sync When locked is displayed, the incoming, outgoing MADI and DMI MADI Cards are synchronised.
- Connection Displays either Generic (Standard MADI), Console (connected to a DiGiCo Console). Rack (connected to an SD Rack), DiGiCo (control pass through mode) or Unknown.
- The picture below shows a DMI MADI B in the "SLAVE" port of an Orange Box connected to an SD Rack at 48 kHz,
- Rack type/Rack code When connected to an SD series rack and the MADI type is set to **Auto**, the rack type and Sharc firmware dates will be displayed.

In addition to the Rack type and Code dates, the contents of each card slot will be displayed as will rack power supply diagnostic data.

The picture below shows a DMI MADI B in the "SLAVE" port of an Orange Box connected to an SD Rack at 48 kHz. The **Racks** menu is selected so the card, firmware and PSU details are shown.



#### 3.4.4 96 kHz MADI

There are 2 MADI standards when running at 96 kHz, SMUX (48k frame) and High Speed (true or 96k frame). For a detailed explanation on the differences between the two standards, please consult DiGiCo Technical Note TN294.

The DMI MADI card auto detects sample rate changes between 48 kHz and 96 kHz. SMUX MADI uses a native 48 kHz clock which the DMI detects and reports. This 48 kHz SMUX clock cannot be differentiated from a standard 48 kHz without intervention.

If the DMI card is connected to an SD Series console and its **MADI type** is set to **AUTO**, the DiGiCo CH57 Control Data will instruct the DMI card to set itself to SMUX mode therefore providing the SLAVE DMI card with a 96 kHz clock.

In any other *MADI type* mode, the SMUX mode needs to be manually set. This is done by clicking the SMUX box located above each MADI details box.

In the following picture, the incoming sample rate in the MADI details box is being correctly reported as 96 kHz (SMUX). If SMUX was not selected, the sample rate would report as 48kHz. By activating *SMUX* mode, the Orange Box sample rate is set to 96 kHz and consequently the DMI Card in the SLAVE slot is being provided a 96 kHz sync source and audio will appear on the correct channels.

🜚 Orange Box Controlle	er v3.0.0.56 (Beta)				-	
≡						
96000 Hz	MI MADI-	B Master 24°c	96000 Hz	DMI DANT	re 64@96	Slave 26°c
Port A Sync:	OK Port B	Sync: OK	S	ync: OK		
Sync Select: A	uto Wordclock N	ADI A MADI B				
Sync Source: N	ADI A					
	Controls Update			Controls	Update	
	Controls			Cont	rols	
	MADI A	MADI B	Dar	nte Sample Rate:	47999 Hz	
In Channels	64	64				
In Sample Rate	96000 Hz (Smux)	96000 Hz (Smux)		SRC State:	Active	
Out Channels	64	64				
Sync	Locked	Locked				
Connection	Generic	Generic				
MADI Mode	e: Auto	DiGiCo				
SMUX	K: On	Off				
Port Mode	e: Redundant	Dual				
SRC To DMI 2	2: Off 48	kHz 96kHz				
SRC State	: Inactive					

An Orange Box containing two DMI MADI cards can be used to convert 96 kHz MADI between the SMUX and High-Speed Formats.

### 3.4.5 Port Mode

There are two Port Modes.

**Redundant**. – The same signal is sent and received on both sets on BNC/CAT5 connections. If the input from connection MADI A fails, then the Audio arriving on MADI B will be routed to the other DMI Card.

**Dual**. - MADI A and MADI B act as independent MADI connections allowing up to 128 Channels (2 x 64CH) of MADI at 48kHz and up to 64 Channels (2 x 32CH) at 96kHz of MADI to be passed between DMI 1 & DMI 2



## 3.4.6 MADI SRC

From OBC V3 and DMI MADI V167, Sample Rate Conversion (SRC) is supported. Additional controls have been added to OBC to control this. The controls are different depending on whether the DMI MADI card is in DMI1 or DMI 2.

MADI DMI In Master Slot			MAD	I DMI In Slave	e Slot
	Controls			Controls	
	MADI A	MADI B		MADI A	MADI B
In Channels	64	64	In Channels		
In Sample Rate	96000 Hz (Smux)	96000 Hz (Smux)	In Sample Rate	0 Hz	0 Hz
Out Channels	64	64	Out Channels	64	64
Sync	Locked	Locked	Sync	Not Locked	Not Locked
Connection	Generic	Generic	Connection	NoDevice	NoDevice
MADI Mo	de: Auto	DiGiCo	MADI Mode:	Auto DiG	iCo 64 CH
SM	UX: On	Off	SMUX:		
Port Mo	de: Redundant	Dual	Port Mode:	Redundant	Dual
SRC To DM	I 2: Off 48	kHz 96kHz	Device Connected At:	48k 96k Smi	JX 96k HiSpeed
SRC St	ate: Inactive		SRC State:	Active	

When in the Master Slot (DMI 1), the SRC controls decide the Sample rate provided to the DMI card in the Slave Slot (DMI 2).

The DMI MADI Mode must be set to Auto for the SRC controls to become active.

The controls are: -

**Off** – SRC is switched off. The sample rate provided to Slave Card (DMI 2) track the sample rate of the incoming MADI stream.

**48kHz** – The sample rate provided to Slave Card (DMI 2) will be 48kHz whatever the sample rate of the incoming MADI stream is.

**96kHz** - The sample rate provided to Slave Card (DMI 2) will be 96kHz whatever the sample rate of the incoming MADI stream is.

When in the Slave Slot (DMI 2), the SRC controls should match the Sample rate of the device that is connected to the MADI card.

The DMI MADI Mode must be set to 64CH for the SRC controls to become active.

The controls are: -

48kHz – The connected device has a sample rate of 48kHz

**96k SMUX** – The Connect device has a sample rate of 96kHz and the MADI format is set to SMUX.

96K HiSpeed - The Connect device has a sample rate of 96kHz and the MADI format is set to Hi Speed.

The SRC State box compares the Sample rate of the MADI input and the DMI Card Sample rate and will report either *Active* or *Inactive*.



## 3.5 DMI Optocore

## 3.5.1 Overview

This card enables an Orange Box to be added to an existing Digico Optocore Network. The card runs V221 Optocore firmware and so can only be integrated into systems using SD Racks.

The Optocore card will need its ID, Fibre speed and channel count set using OBC before it is added to a network.

The picture below shows a DMI Optocore card in the MASTER port of the Orange box. In the audio IO page of an SD Console, this would appear as an Orange Box, Optocore ID 14 with 48 inputs and 32 outputs.

Orange Box Controller v3.0.0.56 (Beta)
48000 Hz DMI OPTOCORE Master 17°c
Sync: OK
Sync Select: Auto Wordclock OPTOCORE
Sync Source: OPTOCORE
Controls Update
Controls
OPTOCORE Sample Rate: 48000 Hz
OPTOCORE ID: 14
Fibre Speed: 1GB 2GB
Port A Channels
Inputs: 48 🗸 🗸
Outputs: 32 V
Port B Channels
Inputs: 0 V
Outputs: 0 🗸

### 3.5.2 Channel Count Setup

When a DMI card is paired with a DMI Optocore card in an Orange Box, the OBC control panel will provide controls to set the required input and output channels to the Optocore system in groups of 8 channels. The Sample rate of the system will dictate the number of available channels.

DMI Optocore has extra configuration options when used with DMI MADI. At 48kHz, up to 128 inputs and outputs can be used using MADI A (64Ch) and MADI B (64Ch). At 96kHz, up 64 channels can be used but this can be configured as one 64 channel port or two independent 32 channel ports. This configuration will determine how the Orange Box is displayed in the SD consoles audio IO.

The picture below shows DMI Optocore panel at 96kHz configuring its MADI channel count. It is set as 2 x 32ch MADI connections with MADI A as 32in 32out and MADI B as 16in 16out.





If the MADI mode was set to 1x64, then only one 64ch port would be displayed.

#### 3.5.3 Optocore System Clock

The location of the DMI Optocore card in the Orange Box will have a direct impact on the clock set up of the Optocore network.

When located in the MASTER port, the card will get its clock from the Optocore Network.

When the card is in located in the MASTER port and a Word clock is applied to the Orange Box then the DMI Optocore will become the master clock for the Optocore Network.

When the card is located in the SLAVE port, it will automatically become the Optocore Network clock master and will get its reference clock from the DMI card located in the MASTER port.

## 3.6 DMI Dante 64@96

OBC V2.7 or above includes support for the new DMI Dante 64@96 card. This card provides 64 input and 64 output channels at both 48kHz &96kHz, along with support for SRC (Sample Rate Conversion). This enables the Orange Box to run at a different sample rate to the Dante network.

When the DMI Dante 64@96 is in the SLAVE port of the Orange Box **AUTO SRC** is active, the card keeps track of the sample rate of the card in the MASTER port of the Orange Box and the Dante network and will sample rate convert if they do not match. The picture below shows an Orange Box with a DMI Optocore in the MASTER port running at 96kHz and a DMI Dante 64@96 where the Dante Network is running at 48kHz with **SRC** active.





When the DMI Dante 64@96 is in the MASTER port of the Orange Box, the SRC control defines the sample rate that is applied to the card in the SLAVE port. The picture below shows an Orange Box with a DMI Dante 64@96 in the MASTER Port running at 48kHz and a DMI Optocore in the SLAVE port where the Optocore Network is running at 48kHz. The SRC control has been set to **96kHz** therefore the SLAVE port will always receive a 96kHz sample rate as its reference.



## **3.7 DMI KLANG**

OBC V2.8 and above includes support for DMI KLANG. The Card provides 64 sends from the console and returns 16 stereo binaural mixes plus a stereo solo (34 Channels). In order to get the full channel processing count when paired with a DMI Optocore, the Optocore card should be set for 40 inputs and 64 Outputs as shown below. The DMI KLANG must be running KOS 4.3.24 or higher to work with an Optocore Connection.

The card must be located in the Slave slot of the Orange Box



From the control panel, the card's network details can be viewed. There are 2 modes, Dynamic, where the cards IP is set by DHCP; and Fixed IP, where the IP address, Subnet Mask and Gateway (if required) can be defined.



All of these settings are also available in KLANG:app.

The DMI KLANG firmware version cannot be updated using Orange Box Controller.

For Firmware details please see <a href="https://www.klang.com/en/downloads">https://www.klang.com/en/downloads</a>

## 3.8 DMI AVB

OBC V3.0.0.88 or above includes support for the new DMI AVB card. This Milan Certified card provides 64 input and 64 output channels at both 48kHz & 96kHz. The card can be used in both the MASTER and SLAVE slot of the Orange Box.



The display for the DMI AVB will differ slightly according to its slot position, offering Sync Select options in when fitted in the MASTER slot but not in the Slave slot.

In the SLAVE slot the sync is provided automatically from the MASTER slot card.

There are three sample rate modes, 48kHz, 96kHz and Mixed mode which allows a 96KHz device to share AVB streams with other devices set to 48KHz but this will require additional configuration.

Firmware updates for DMI AVB are done via the AVB Update Tool.

Further information on DMI AVB is available in TN632 – DMI AVB User Guide.