



# SD & Quantum Software Reference Manual

Issue H - June 2025 – V20+

Copyright © 2025 Digico UK Ltd

### **All rights reserved.**

No part of this publication may be reproduced, transmitted, transcribed, stored in a retrieval system, or translated into any language in any form by any means without the written permission of Digico UK Ltd. Information in this manual is subject to change without notice, and does not represent a commitment on the part of the vendor. Digico UK Ltd shall not be liable for any loss or damage whatsoever arising from the use of information or any error contained in this manual.

All repair and service of the SD & Quantum products should be undertaken by Digico UK Ltd or its authorised agents. Digico UK Ltd cannot accept any liability whatsoever for any loss or damage caused by service, maintenance, or repair by unauthorised personnel.

### **Software Licence Notice**

Your license agreement with Digico UK Ltd, which is included with the SD & Quantum products, specifies the permitted and prohibited uses of the product. Any unauthorised duplication or use of Digico UK Ltd software, in whole or in part, in print or in any other storage and retrieval system is prohibited.

### **Licences and Trademarks**

The SD & Quantum logos and SD & Quantum names are trademarks, and Digico UK Ltd and the Digico UK Ltd logo are registered trademarks of Digico UK Ltd. Microsoft is a registered trademark and Windows is a trademark of Microsoft Corp.

Digico (UK) Ltd

No.5 The Distillery

Silverglade Business Park

Leatherhead Road

Chessington

Surrey

KT9 2QL

England

Telephone: +44 (0)1372 845600

Fax: +44 (0)1372 845656

Email: [sales@digiconsoles.com](mailto:sales@digiconsoles.com)

www: <http://www.digico.biz>

**Manual Issue and Date: Issue H – June 2025 – V2000+**

Licence Agreement

"Product": SD & Quantum software products produced by Digico UK Ltd intended for use on Target Platform identified below.

"Target Platform": Digico SD & Quantum Digital Console systems.

In return for the payment of the one-time fee, the Customer (identified at the end of this Agreement) receives from Digico UK Ltd a licence to use the Product subject to the following terms and conditions.

- 1. The Product may be used without time limit by the Customer on the Target Platform.
- 2. The Customer must register the Product with Digico UK Ltd. Registering the Product is deemed an acceptance of the terms and conditions in this agreement.
- 3. The Product and its licence are not transferable, and the Customer is not permitted to onward-license to any third party. The Customer indemnifies Digico UK Ltd against any and all claims and actions arising from third party use of copies of the Product made by the Customer.
- 4. The Customer agrees not to attempt to decompile the object code of the Product otherwise than in circumstances specifically provided for by law, and then only after consultation with Digico UK Ltd.
- 5. The Customer agrees not to use, or licence the Product for use, with equipment other than the Target Platform.
- 6. The Customer agrees not to modify the Product without the prior written consent of Digico UK Ltd.
- 7. This Agreement applies to any enhancement or upgrades that may become available for the Product.
- 8. This Agreement does not transfer any right, title, or interest in the Product to Customer except as specifically set forth herein.
- 9. Digico UK Ltd reserves the right to terminate this Agreement upon breach, in which event Customer shall thereafter only be authorised to use the Product to the extent that its contractual commitments to third parties require and then only where such commitments relate to use of the Product as authorised in the foregoing provisions of the Agreement.

**LIMITED WARRANTY** - Digico UK Ltd warrants for a period of 1 year from the date of purchase of the Product, the Product will reasonably execute its programming instructions when properly installed on the Target Platform. In the event that this Product fails to execute its programming instructions during the warranty period, the Customer's remedy shall be to return the Product to Digico UK Ltd for replacement or repair at Digico UK Ltd option. Digico UK Ltd makes no other express warranty, whether written or oral with respect of this Product.

**LIMITATION OF LIABILITY** - Except as otherwise expressly provided by law, (a) the remedies provided above are the Customer's sole and exclusive remedies and (b) Digico UK Ltd shall not be liable for any direct, indirect, special, incidental, or consequential damages (including lost profit whether based on warranty, contract, tort, or any other legal theory.)

This agreement is made under the Laws of England.

LICENCE NO: .....

REGISTRATION DATE:  
.....

# Contents

<b>Chapter 1: Channel Types &amp; Function .....</b>	<b>11</b>
1.1 Introduction to Channel Strip.....	12
1.2 Channel Input - Common Elements.....	13
1.2.1 Channel Strip Input Area.....	13
1.2.2 Channel Delay .....	14
1.2.3 DiGiTube .....	14
1.2.4 Naming Channels & Busses .....	15
1.2.5 Channel Safes .....	16
1.2.6 Copy Channels.....	16
1.2.7 Channel Presets.....	18
1.2.8 Channel Solos .....	20
1.3 Channel Output and Inserts - Common Elements .....	22
1.3.1 Channel Strip Output Area .....	22
1.3.2 Channel Strip Insert Area .....	24
1.3.3 Console Output and Insert Routing .....	25
1.3.4 FX Presets.....	26
1.4 Input Channel – Specific Functions.....	27
1.4.1 Gain Tracking.....	27
1.4.2 Relative Gain-Tracking - Snapshot Recalls Total Gain.....	27
1.4.3 Input Routing .....	28
1.4.4 Input Configuration .....	30
1.4.5 Channel Metering.....	30
1.4.6 CG/HARD mute indicators on the Meterbridge (Q7/SD7/Q5/SD5) .....	31
1.4.7 Output Routing.....	31
1.4.8 Pan Controls .....	32
1.4.9 Aux Buses & Assignable Controls .....	33
1.4.10 Aux Nodes Panel (all consoles) and Nodal Processing (Quantum only).....	36
1.4.11 KLANG Nodes .....	38
1.4.12 True Solo (Quantum only).....	39
1.4.13 Insert Point Locations (Quantum only) .....	40
1.4.14 Group Outputs .....	40
1.4.15 Mix Minus function on Quantum Consoles.....	41



1.4.16	Direct Outputs .....	41
1.5	Output Channel Specific Functions.....	42
1.5.1	Unfolding Channels.....	42
1.5.2	Group Channels Specific Functions.....	43
1.5.3	Aux Specific Functions .....	44
1.5.4	Buss EQ – SD5, SD7, SD10 & Quantum consoles .....	45
1.5.5	Addition Buss Features – Input Merge & Ident .....	45
1.6	Channel Signal Processing.....	46
1.6.1	Channel Filters (All SD and Quantum input channels and on SD8,9,11 output channels) .....	46
1.6.2	Input Channel EQ.....	46
1.6.3	Dynamic EQ.....	48
1.6.4	Output Channel EQ.....	49
1.6.5	Channel Dynamics .....	50
1.7	Mustard Channels (Quantum only) .....	53
1.7.1	Mustard Channel Strip .....	53
1.7.2	Insert Position .....	54
1.7.3	Safes/Scopes .....	54
1.7.4	Presets .....	54
1.7.5	Pre-amplifier Modelling.....	54
1.7.6	Mustard Equaliser.....	56
1.7.7	Mustard DYN1 & DYN2 .....	56
1.8	LCD Functions.....	58
1.8.1	Solo.....	59
1.8.2	Solo Choice.....	59
1.8.3	Gang .....	59
1.8.4	Join CG (Control Group) .....	60
1.8.5	Assign Faders.....	60
1.8.6	Unassign Faders.....	61
1.8.7	Swap Faders .....	61
1.8.8	Move Faders.....	61
1.8.9	Copy Bank From .....	61
1.8.10	Copy Bank To.....	61
1.8.11	Clear Bank .....	61

1.8.12	Create Multi .....	62
1.9	Multi Channels .....	62
1.9.1	Creating a Multi .....	62
1.9.2	Edit Multi .....	64

## **Chapter 2: The Master Screen..... 65**

2.1	System Menu .....	66
2.1.1	Diagnostics .....	66
2.1.2	Oscillator .....	66
2.1.3	GPIO Relays .....	67
2.1.4	Security .....	67
2.1.5	Signal Over Indicators .....	69
2.1.6	Overview Clear Screen .....	69
2.1.7	Clear Master screen .....	69
2.1.8	Keyboard Help .....	69
2.1.9	F10: Reset FX .....	69
2.1.10	F11: Reset Engine .....	70
2.1.11	F12: Reset Surfaces .....	70
2.1.12	Reset Computer .....	70
2.1.13	Set Date & Time .....	70
2.1.14	Enable Extensions .....	70
2.1.15	Quit to Windows/Home .....	70
2.1.16	Shutdown .....	70
2.1.17	Shutdown All .....	70
2.2	Files Menu .....	71
2.2.1	Templates .....	71
2.2.2	Session Structure .....	71
2.2.3	Load Session .....	74
2.2.4	Save Session .....	76
2.2.5	Save As New File .....	77
2.2.6	Load Presets .....	79
2.2.7	Save Presets .....	79
2.2.8	Global Set to Defaults .....	80
2.2.9	Session Notes .....	81

2.2.10	Session Report.....	81
2.3	Layout Menu .....	82
2.3.1	Fader Banks.....	82
2.3.2	The Overview Display .....	84
2.3.3	Channel List.....	85
2.3.4	Set Spill .....	86
2.3.5	Aux to Faders.....	87
2.3.6	Aux Nodes .....	87
2.3.7	Join Groups .....	87
2.3.8	AMM Control (Consoles with DMI slots).....	88
2.3.9	Transport Control .....	91
2.4	Snapshots Menu.....	91
2.4.1	Storing a Snapshot.....	92
2.4.2	Recalling a Snapshot.....	92
2.4.3	Replacing a Snapshot .....	92
2.4.4	Editing Multiple Snapshots .....	93
2.4.5	Moving a Snapshot .....	94
2.4.6	Renaming a Snapshot .....	94
2.4.7	Renumbering Snapshots .....	94
2.4.8	Deleting a Snapshot.....	94
2.4.9	Snapshot Undo .....	94
2.4.10	Snapshot Groups .....	95
2.4.11	Global Recall Scope.....	98
2.4.12	Individual Snapshot Recall Scope .....	99
2.4.13	Snapshot Recall Times .....	100
2.4.14	Snapshot Crossfades.....	101
2.4.15	Snapshots and MIDI.....	102
2.4.16	MIDI Devices .....	103
2.4.17	MIDI Program and MIDI List.....	104
2.4.18	Snapshot GPO Relays.....	105
2.4.19	Surface Offline & Snapshot Editing (Not SD11) .....	105
2.4.20	Auto Update.....	106
2.4.21	Snapshot Notes .....	108

2.4.22	Snapshot Locked.....	109
2.5	Options .....	110
2.5.1	Surface .....	110
2.5.2	Faders .....	112
2.5.3	Solo.....	114
2.5.4	Gangs .....	115
2.5.5	Delays .....	115
2.5.6	Disable .....	116
2.5.7	Brightness .....	116
2.5.8	Meters .....	116
2.5.9	Console .....	117
2.5.10	Status.....	121
2.6	FX & Processors .....	123
2.6.1	The Master FX Display .....	123
2.6.2	The Spice Rack (Quantum Engines only) .....	125
2.6.3	Chilli & Naga 6 Overview .....	125
2.6.4	User interaction options .....	128
2.6.5	Presets .....	128
2.6.6	Fourier transform.engine - Control Integration (V20xx) .....	128
2.6.7	Fourier transform.engine - Session and Snapshot integration (V20xx).....	130
2.6.8	Adjusting plugin parameters from the console interface .....	131
2.6.9	Sharing a transform.engine between multiple consoles.....	132
2.7	Matrix Menu .....	132
2.7.1	The Matrix Panel .....	132
2.7.2	Matrix Output Copy.....	135
2.8	Graphic EQ Panel .....	136
2.8.1	A Ganging Graphic EQs .....	137
2.8.2	Graphic EQ ALL Button .....	137
2.8.3	Graphic EQ Presets .....	137
2.9	Control Groups .....	138
2.9.1	The Master Control Groups Display .....	138
2.9.2	Control Group Fader Modes.....	140
2.9.3	Control Group Mute Functions.....	140
2.9.4	Control Group Spill (1272+).....	141

2.9.5	Control Group Aux Send Enable (v1445+) .....	141
2.10	Solos Menu .....	142
2.10.1	The Solo Panel .....	142
2.10.2	The No Solo Setup Display .....	143
2.10.3	Assigning Solo Busses to Faders .....	144
2.10.4	Solo Outputs Routing.....	144
2.10.5	Headphone Outputs .....	145
2.10.6	Solo Meters .....	145
2.10.7	Solo as an Input Source.....	145
2.11	Network and Mirroring.....	146
2.11.1	Network Configuration .....	146
2.11.2	Mirroring for the first time.....	146
2.11.3	Mirroring Mode.....	147
2.11.4	Mirroring with a laptop PC.....	148
2.12	Setup Menu .....	149
2.12.1	Audio I/O .....	149
2.12.2	Port Selection .....	150
2.12.3	Port Hardware Configuration .....	150
2.12.4	Port Control.....	151
2.12.5	The Socket Display.....	151
2.12.6	Socket Conforming .....	152
2.12.7	Group and Socket Names.....	152
2.12.8	Socket Options .....	153
2.12.9	Copy Audio.....	153
2.12.10	Audio Sync .....	156
2.12.11	Timecode & Transport .....	158
2.12.12	Macros .....	159
2.12.13	The Macro Editor .....	161
2.12.14	Advanced Macro Triggers (V19xx+) .....	163
2.12.15	Talkback .....	168
2.12.16	Text Chat .....	169
2.12.17	Video Link (SD7 & Quantum 7 Only).....	170
2.13	External Control .....	171

2.13.1	iPad Control.....	171
2.13.2	Generic OSC.....	173
2.13.3	L'Acoustics L-ISA.....	174
2.13.4	d&b Soundscape Control .....	177
2.13.5	KLANG Control.....	178
2.13.6	Spacemap Go control (V17xx+) .....	178
2.13.7	Adamson AFM control (V17xx+).....	181
2.13.8	Sound Devices Astral Control (V20xx+) .....	182
2.13.9	Additional Buttons.....	184

## **Chapter 3: Connections & Multiple Console Setups..... 185**

3.1	Console Audio Connections .....	186
3.1.1	Optocore V221 .....	186
3.1.2	FOH & Mons sharing a Stage Rack (MADI) .....	188
3.1.3	FOH & Mons sharing a stage SD Series Rack (MADI) .....	189
3.1.4	FOH & Mons sharing DiGiRacks (Optocore V220).....	190
3.1.5	FOH & Mons sharing SD Series Racks (Optocore V221) .....	192
3.1.6	4REA4 I/O Control (Optocore V221 and MADI) .....	194
3.1.7	MADI DMI (SRC) (for consoles with DMI slots) .....	197
3.1.8	Dante 64@96 (for consoles with DMI slots).....	198
3.1.9	DQ-Rack (for consoles with DMI cards) [V1455+].....	201
3.1.10	MQ-Rack [V1528+] .....	204

## **Chapter 4: Q8 Specific Features ..... 205**

4.2	Q8 Specific Features .....	206
4.2.1	Channel Macros (Q8 Only) .....	206
4.2.2	Expanded Channel Control Area (Q8 Only) .....	207
4.2.3	The Master Faders (Q8 Only).....	211
4.2.4	Macroders (Q8 Only) .....	212
4.2.5	Meterbridge Displays (Q8 Only) .....	213
4.2.6	Layers and Banks (Q8 Only).....	214

## **Chapter 5: Quantum Home..... 216**

5.1	Quantum Home.....	217
5.1.6	Main Shortcuts .....	217
5.1.7	Settings Pane .....	218

---

5.1.8	System Information .....	219
5.1.9	Advanced Settings .....	220
5.1.10	Network Settings .....	221
5.1.11	Keyboard Shortcuts .....	221
<b>Chapter 6: DMI Cards .....</b>		<b>222</b>
6.1	Fitting DMI Cards.....	223
6.2	DMI-MADI Cards .....	224
6.2.1	Connecting DMI-MADI .....	224
6.2.2	Sharing Racks with DMI-MADI .....	228
6.3	DMI - Dante Cards .....	231
6.4	DMI - ADC - DAC - MIC - AES Cards .....	233
6.5	DMI - Waves - Hydra Cards.....	235
6.6	DMI - ME - A3232 Cards .....	236
6.7	DMI – AMM .....	237
6.8	DMI KLANG .....	241
6.9	DMI AVB.....	241

## **Chapter 1: Channel Types & Function**



### 1.1 Introduction to Channel Strip

This chapter describes all the functions available within an SD and Quantum series channel strip. Sections 2 and 3 cover the common elements of input and output channels, sections 4 and 5 cover features specific to different channel types. Familiarise yourself with the **Channel Strip** (Figure 1) and **Channel Setup Display** (Figure 2).

*Note: Most of the images in this manual reference the SD display style and the Quantum console version will probably differ slightly in appearance and have separate manual chapters to deal with relevant additional features.*




Figure 1 - Channel Strip



Figure 2 - Channel Setup

## 1.2 Channel Input - Common Elements

### 1.2.1 Channel Strip Input Area



The **Input Area** is located at the top of the Channel Strip which displays digital trim and polarity on all channels.

Input channels also display Main/Alt input selection and input metering plus analogue gain, gain tracking and phantom power depending on the input route. Output channels display channel delay.

*Note: Alt inputs now store a separate digital trim Value. This feature will only function correctly in a new session made in V1528 or later.*

Other input parameters and channel settings are contained in the Channel Setup display, accessed by touching the channel's input or filters area at the top of the channel strip.

The large on-screen rotary controls remote pre-amp gain, if this is available on the input route socket of an input channel, or otherwise digital trim. The smaller on-screen rotary controls digital trim when the large on-screen rotary is controlling gain, or delay on an output channel.

The large on-screen rotary be adjusted on the rotary encoders immediately above the channel strip (SD7, 8, 10, Q7) or assigned to the under-screen rotaries using the Quick Select buttons (SD5, 9, 11, 12, Q3). When this on-screen rotary is selected, the buttons under the rotary encoders toggle polarity.

The smaller on-screen rotary can be adjusted by scrolling the selection down using the assign scroll buttons. When this on-screen rotary is selected, the buttons under the rotary encoders toggle gain tracking or delay on/off.

*Note: that a large channel input meter is displayed by scrolling up on the assign buttons or scroll buttons (already displayed on Q3)*

### 1.2.2 Channel Delay

Delay controls are found in the Channel Setup Display (opened by touching the top of the channel strip). The left-hand blue on-screen rotary controls the coarse delay amount in milliseconds. The right-hand blue on-screen rotary enables fine adjustments to be made, at sample precision. Both on-screen rotaries can be assigned to under-screen rotary encoders by touching this area of the Setup Display.

It is also possible to enter a specific delay amount using the delay keypad. Touch the keypad symbol to the right of the on button, select the desired units, enter the value using the keypad, and touch OK.

*Note: that altering the delay units in this keypad display will affect all instances of this value on the console.*



### 1.2.3 DiGiTube



DiGiTube emulates the non-linearities of a valve amplifier: At low levels the valve is almost linear and at high levels the valve starts to compress and exhibits 'soft clipping'.


To enable, touch the **on** button available in the Channel Setup Display.

The **drive** control increases the gain into the virtual valve and automatically reduces the output gain so that the volume stays constant; the indicator shows how hard the valve is being driven and hence how much distortion is being introduced.

The **bias** control sets the symmetry of the distortion: At 0 the distortion is symmetrical and produces largely 2nd harmonic (and other even) distortion; as the bias is increased, the distortion becomes more asymmetrical and starts adding 3rd harmonic (and other odd) distortion. In effect, the bias controls the characteristics of the distortion; a lower bias produces a softer distortion, whereas as a higher bias produces a harder distortion.

The **warmth** button (which is hidden if the on button is pressed) switches DiGiTube on, sets it to its default settings, and hides the rest of the controls.

1.2.4 Naming Channels & Busses



To edit a name, touch any white text box or the keyboard symbol to its right, to bring up an on-screen QWERTY keyboard.

This includes functions such as Cut, Copy and Paste which can be used to move names between channels. The arrow buttons in the bottom right-hand corner of the keyboard display move the cursor within the text box. Once editing is complete, press OK (or Enter on an external keyboard). To close the keyboard display without changing the name, press CAN (or Esc). To move the keyboard display to the following channel, press Next (or Tab).

The Channel Name display enables commonly used words to be inserted quickly without the use of the keyboard. To open the Channel Name display, touch the button immediately to the right of the channel name text box. Touching any word from the display inserts that word into the channel name text box. Further words can then be added to the channel name in the same way, divided by a single space. Numeric and L/R identifiers can be added from the column down the right-hand edge of the display. By default, text is entered in lower case. It can be entered in CAPS or Initial Caps by pressing the respective buttons at the top of the display.

CAPSInitial Capcustomedit

Channel Name

CLEARCLOSE

12 string	booth	clarinet	floor	hat	line	mp3	rack	spare	top	0
ac	bot	click	flute	head	lo	near	rear	speaker	track	1
acoustic	boys	conga	front	hi	loops	noise	record	stage	trombone	2
alto	brass	crash	fx	hi-hat	lower	o/h	reverb	stalls	trumpet	3
amp	bv	cymbals	girls	horn	madi	oboe	rhythm	strings	upper	4
audience	cab	di	glock	keys	main	opto	ride	sub	viola	5
backing	cd	direct	gong	kick	master	orchestra	right	surr	violin	6
backup	cello	double	gtr	kit	md	organ	sax	sync	vocal	7
band	centre	drums	guitar	l&r	mic	perc	seq	synth	vox	8
baritone	choir	far	hand	lead	mid	piano	side	tenor	wind	9
bass	chorus	feed	harmony	left	midi	princ	snare	timpani	woodwind	L
bongo	circle	fill	harp	lfe	mono	prog	soprano	tom	xylophone	R

CAPSInitial Capcustomedit

Kick In		
Kick Out		

Other commonly used words can be added and accessed by touching the Custom button. To add a new word to the custom set, touch an empty slot, press Edit, enter the word followed by OK (Enter). The Next button saves any text inserted in the current slot and moves the keyboard to the next slot in the custom list.

*Note: that Channel names can also be edited in quick succession within the Channel List as described in Chapter 2 (2.2.3)*

### 1.2.5 Channel Safes



Figure 3 - Safe Button in Channel Strip

The Channel Safes area of the Channel Setup Display defines which parts of the channel will not be changed when snapshots are recalled. The buttons turn red when pressed to indicate that they are safed. The presence of safes within the channel are also indicated by red text and the background of the channel's name turning red. EQ and dynamics parameters can also be safed and unsafed from within the EQ and dynamics displays. The whole channel can also be safed and unsafed quickly by pressing the SAFE button at the bottom of channel (using a mouse), shown in the red box in Figure 3. The SAFE button is lit red to indicate a full safe.

There is also a physical Safe button on the SD5 & Q5, SD7 & Q7 and Q8 consoles, which performs the same action as the button on the bottom of the channel strip.

*Note: that channel safes refer specifically to snapshot recalls and do not protect channel settings when using the copy from, copy to and presets.*

### 1.2.6 Copy Channels



Figure 4 - Channel Settings Area of Channel Strip




Figure 5 - Copy Channels Display

The **Channel Settings** area (Figure 4) of the **Channel Setup Display** (Figure 2) allow channel settings to be copied between channels. The left and right arrow buttons are used to move the Channel Setup Display to

adjacent channels. The Copy From button allows settings to be copied from other channels to this channel and following channels (if number of channels is greater than 1).

Pressing Copy From opens the **Copy Channels Display** (Figure 5). The segments of channel settings to be copied is selected using the scope buttons towards the bottom of the display. These buttons turn pink to indicate that they are included in the copy function. The number of channels to be copied from is selected using the appropriate grey numbered button, or by entering a number on the keypad available from the icon to the right of the text box

Press the LCD/channel select button (Figure 6) on the left-most source channel in order to action the channel copy. If more than one source channel has been selected, the settings of appropriate number of channels to the right of the source channel will copy to the channels to the right of the destination channel (the currently assigned channel).




Figure 6 - LCD Copy Functions




Figure 7 - Copy Channel Display

The Copy To function allows settings to be copied from one selected channel to either one or multiple channels. Pressing Copy To opens a slightly different **Copy Channels Display** (Figure 7). This also includes a Stay Open button on the top left of the display. This means that the display isn't closed when a user presses Copy using the

LCD function or the select buttons. Instead the display remains open allowing the user to copy the selected channel multiple times to different channels.

If a copy from or copy to function is actioned by mistake, it can be undone by pressing the undo previous copy button in the current Copy Channels display.

**Tip:** Use copy to for copying one channel's settings to a number of other channels; Use copy from to copy the settings of a group of channels to another group of channels.

### 1.2.7 Channel Presets



Figure 8 - Channel Settings Area of Channel Strip




Figure 9 - Presets Display

Presets are used for storing and recalling settings for channels, fx units, graphic EQs and the matrix. The **Presets Display** (Figure 9) can be accessed via **Channel Settings** (Figure 8) area of the **Channel Setup Display** (Figure 2) below the copy buttons.

The left-hand column of a **Preset Display** contains the available groups of presets and select one of these groups brings up the list of presets within that group. The columns to the right of the preset name displays the number of channels whose settings are included in the preset (chs) (Channel and Matrix presets only), the date and time it was created or updated (notes), and whether it is locked (lock).

*Note: that a presets display will only list presets of the relevant channel type.*

To recall a preset, select the name of the group containing the preset you wish to recall, and then touch the preset's name. The recall scope buttons at the bottom of the preset displays allow you to select which elements are recalled and which elements remain unchanged. The buttons are included in the recall when they are lit. To save the current settings as a new preset, select the group in which you want the preset to be stored and press the 'new' button on the right. To alter the preset's name, type the new name using the keyboard display (or the external keyboard) then, if relevant, touch and edit the number of channels' settings that you

want to store in the preset (the default is one channel - if more than 1 is specified then the channel settings of the channels to the right of the selected channel will be saved). Now press OK.

*Note: that pressing CAN in the keyboard display will cancel the display but create the new preset with a default name.*

To save the settings as an update of a previous preset, press update, select the preset you wish to overwrite, and press Yes in the confirmation display which appears.

*Note: that when updating a previous preset, failing to press update will result in the preset you wish to overwrite being recalled, and the settings to be saved being lost.*

To create a new group of presets, press new group. A new group will be created, called Group n, where n is the next available preset group number. To alter the group's name, type the new name using the keyboard display that appears (or the external keyboard) and press OK (or Enter).

*Note: that pressing CAN in the keyboard display will cancel the display but create the new group with its default name.*

The edit name button allows preset names and group names to be edited, and the preset to be locked, preventing them from being edited, overwritten, or deleted. The button is lit to indicate that it is active. To edit a preset's name, make sure the preset is unlocked (see below), activate the edit name button and touch the preset's name. Type the new name in the keyboard display and press OK. To edit a preset group name, activate the edit name button and touch the group name. Type the new name in the keyboard display and press OK.

To lock the preset, activate the edit name button and touch the preset's lock column. A grey padlock appears, indicating that the preset is now locked. Touching the lock again with edit name active unlocks the preset. To delete a preset, press delete, touch the preset to be deleted, and press confirm.

To delete a consecutive range of presets, press delete followed by select range, touch the first and last preset to be deleted and press confirm. To delete one preset, or a non-consecutive range, touch each preset to be deleted and press confirm. To delete an entire group of presets, press delete followed by select all, then press confirm.



1.2.8 Channel Solos

SD and Quantum consoles have two solo buses, and each channel can be assigned to solo 1, solo 2 or both. If the console was being used for stage monitors, this would allow the first solo bus to feed IEMs (In-Ear Monitors) and the second solo bus to feed a monitor wedge.

*Note: the solo busses are configured in the **Solo Display** accessed by pressing the Solos button from the menu bar at the top of the Master Screen (Figure 11).*



Figure 10 - Solo Display



Figure 11 - Master Screen

The channel’s solo routing is assigned in the section at the bottom section of the channel Setup display. Pressing the green solo 1 and solo 2 buttons enables the channel to be routed to solo busses 1 and respectively. The text is white to indicate that the solo buss is available, and grey to indicate that it isn’t.

When the auto solo buttons are active (indicated by blue), that channel is automatically routed to the solo bus whenever another channel is soloed to the same bus. Note that a list of channels with auto solo enabled is displayed in the auto solo section of the master solo display.

The auto solo function has to be activated by pressing the 'disabled' button below the auto solo list in the master solo display, this will turn blue with 'enabled' to indicate an on state. Auto solo is disabled when in single solo mode.

**Tip:** If you are using effects returns, selecting auto solo can allow soloed tracks to be auditioned with their effects returns.



Figure 12 - Solo Routing

The channel's solo routing (Figure 12) is assigned in the section at the bottom section of the **Channel Setup Display**. Pressing the green solo 1 and solo 2 buttons enables the channel to be routed to solo buses 1 and 2 respectively. The buttons turn green to indicate that the solo bus is enabled on that channel.

*Note: Each channel must be assigned to at least one solo bus.*

*Note: A list of channels with auto solo enabled is displayed in the auto solo section of the master Solo Display. The auto solo function has to be activated by pressing the blue enabled button below the auto solo list in the master solo display. Auto solo is disabled when in single solo mode.*

## 1.3 Channel Output and Inserts - Common Elements

### 1.3.1 Channel Strip Output Area

The **Channel Strip Output Area** (Figure 13) makes up the lower half of the **Channel Strip** (Figure 1). This is where the channel output routes are configured (including Aux sends in the case of Input channels). Some basic output and insert functions are found in the channel strip. However, most of the output and insert parameters are contained in the channel Output display, accessed by touching the channel's output or insert areas.



Figure 13 - Channel Output Display



Figure 14 - Aux Send Area of Channel Strip




Figure 15 - Output Channel Meter

On Input channels, the lower part of the channel strip contains the aux sends (Figure 14). For all output channel types, there is a channel meter displayed in place of aux outputs (Figure 15). On stereo and multi channels, symbols below each meter indicate which signal they correspond to. LFE meters are indicated by a small box with a dot in it.

*Note: input channels can display a meter in the top section of the channel strip.*

Meter sources are defined in the Options menu, described in Chapter 2: Master Section. Below the meters section of output channels, there is an FX Output button (Figure 15). This button brings up either the controller display for the effects preset that has been assigned, or the FX Presets display if no preset has been assigned.

*Note: that below the aux section of an Input channel, there is a pan control in place of the FX Output button. When an effects preset has been assigned to that channel's Direct Out, touching this pan control brings up the FX preset controller display.*



Figure 16 - Bottom of Channel Strip

Below the channel name (Figure 16), there is indication of the lowest group (**Grp:**) output (along with indication of the lowest direct output (**Dir:**) in the case of Input channels), and indication of any control group (**CG:**) to which the channel belongs. The on-screen channel has **MUTE** and **HARD** (mute) indicators located above the Channel Name.

### Hard Mute

Pressing the worksurface Mute Button of a channel silences all outputs from the channel apart from any which have been assigned pre-mute (this option is available for auxes and direct outs). Pressing the worksurface 2<sup>nd</sup> Function button to activate the Hard Mute silences all outputs from the channel, including those which are assigned pre-mute. A dedicated Hard Mute button for the selected channel can also be found on the worksurface of relevant consoles.

Immediately below the **HARD** button, there is a numeric display of the channel's main fader value in dB. Below the **MUTE** button there is a CG MUTE Indicator which shows when the channel is muted as the result of its membership of a muted Control Group. In the bottom left-hand corner of the channel strip, there is a GANG display. To the right of the GANG button there is a SAFE button. This indicates that one or more of the channel's recall safes have been activated

*Note: Multi channels do not have their own insert controls – each multi-channel component's insert points are configured individually.*

*Note: An Input channel's aux display is opened by touching the aux area. To open the Output display, touch in the muting and naming area below the pan control.*

### 1.3.2 Channel Strip Insert Area



Figure 17 - Insert A in the Channel Strip




Figure 18 - Insert B in the Channel Strip

Each channel also has two inserts: insert A and insert B. Both inserts follow the format (mono or stereo) of their channel. The channel strip insert areas are located above the **EQ Section (Insert A)** (Figure 17) and below the **2nd Dynamics Section (Insert B)** (Figure 18), and their signals are sent and returned to that position within the signal path: insert A is pre-signal processing (but post filters), and insert B is post signal-processing (SD- see below for Quantum). Only one point, either insert A or insert B, can be used per channel on SD9 or SD11.




Figure 19 - Insert A in the Channel Strip

Channel strip insert areas include a button for switching that insert send on and off. The button is grey when the send is off, and red when it is on. Below the on/off button, there is a display of the current insert routing. The send route is displayed on the left, with the prefix "S:", and the return route is displayed on the right, prefixed by R: (Figure 19). If no routing has been selected, these areas are blank apart from these prefixes. If the channel is stereo, only the left side of the insert routing is displayed.

#### Post Fader Inserts

Up to 32 mono input channels (SD) can have their insert B point switched to a post fader insert point using the button in the Channel Output display (Figure 20).



Figure 20 - Channel Output Display

#### Inserts on Quantum Consoles

On Quantum consoles, there are 5 selectable insert positions available on every channel. These are: pre-fade, mid EQ/dyn, pre-EQ/dyn, pre-processing and post-fade. These are shared between Inserts A & B, and Mustard processing. One of these items can be placed in each insert position, and each one can go in any of the 5 selectable positions (provided neither of the other items are using that particular insert point).

1.3.3 Console Output and Insert Routing

The Output displays for all channel types allow direct routing either to the external IO racks, or to one of a variety of internal locations, for both the channel’s main output (or direct output in the case of Input channels), and its insert send and return. In addition to touching inside the output area of the channel strip, it is also possible to open each channel's output display from the **Channel List Display (Figure 21)**, opened from the Master Screen menu **Layout > Channel List**. Activate the Edit button at the base of the display, expand the required channel type by touching its entry in the list, then touch the output column within the required channel row. An outputs display will open within the Master Screen.



Figure 21 - Channel List Display

Towards the bottom of the Outputs display, there are three buttons marked output (direct in Input channels), insert A and insert B. Selecting one of these buttons opens the Signal Routing Area. When either insert is assigned, the ins A send or ins B send routing button appears in the left-hand column, and the ins A return or ins B return routing button in the right-hand column; When the output (direct output in Input channels) is assigned, the outputs (direct outs in Input channels) routing button appears in the left-hand column and the right-hand column is left blank. Pressing any of these routing buttons opens a routing display (Figure 22).

An extra button labelled send+return is included above the ports list in the Insert Send Route display button (Figure 23). When this button is activated, the send and return routing is linked for all signals within the INTERNAL port; if Graphic EQ 1’s input is assigned to the insert send, then Graphic EQ 1’s output is automatically assigned to that insert return. Similarly, if it is the return which is manually assigned, the send automatically copies that send assignment. The send+return button is grey when inactive and brown when active (Figure 24).




Figure 22 - Direct Out Display



Figure 23 - Insert Send Route



Figure 24 - Insert Return Route

The mono > mono and mono > stereo buttons are used when routing a mono channel to internal FX units and Waves plug-ins (where available). When mono > mono is selected, the channel signal is routed to left side of an FX unit, or to a mono Waves rack input. When mono > stereo is selected, the channel is routed to both sides of the FX unit or Waves rack.

### 1.3.4 FX Presets

Each channel output or insert send can be sent to an internal FX Unit. Pressing the fx presets button at the bottom of the Outputs display brings up the fx Presets display. Or pressing the FX Output button available on Aux, Group and Matrix channels.

The fx preset is applied to whichever channel output is active in the Outputs display when the fx presets button is pressed: the main channel output (or direct output), insert send A or insert send B:



For more details of SD and Quantum FX and FX preset management, please refer to Chapter 2: The Master Screen.

## 1.4 Input Channel – Specific Functions

### 1.4.1 Gain Tracking

The gain tracking option allows the trim level to compensate automatically for any adjustments made to the analogue input level. If the analogue input level is increased, the trim level will decrease to keep the channel signal level the same (Figure 25). This function is particularly useful when the analogue level is being controlled from another console, such as when one console is running monitor mixes and another console is running Front of House. Control of the trim rotary and track on/off button can be assigned to the encoder and button above/below the channel using the assign scrollers to the left of the encoders or the quick select buttons.



Figure 25 - Input Area of Channel Strip

### 1.4.2 Relative Gain-Tracking - Snapshot Recalls Total Gain

Relative Gain-Tracking is implemented as a **Snapshot Recalls Total Gain** option at the bottom of the Snapshot Global Scope panel (Figure 26) When a snapshot recalls an input channel trim, it compares the snapshot’s stored analogue gain against the current gain on the channel’s input socket. If there’s a difference, it offsets the value recalled by the trim. This only happens when the socket’s rack is in Receive Only, or the analogue gain is not in Recall Scope.

Global Snapshot Scope

CLOSE

channel types	input/trim		delay		filters		eq		dynamics		inserts		sends		fader		mute		panner		to groups		outputs		external	
	recall	update	recall	update	recall	update	recall	update	recall	update	recall	update	recall	update	recall	update	recall	update	recall	update	recall	update	recall	update	recall	update
Input devices	✗	✗																								
Input Channels	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
Aux Outputs	✓	✓	✓	✓			✓	✓	✓	✓	✓	✓			✓	✓	✓	✓					✓	✓		
Group Outputs	✓	✓	✓	✓			✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓			✓	✓	✓	✓		
Control Groups															✓	✓	✓	✓								
FX	✓	✓																								
Matrix Inputs	✓	✓											✓	✓												
Matrix Outputs	✓	✓	✓	✓			✓	✓	✓	✓	✓	✓			✓	✓	✓	✓					✓	✓		
Graphic EQ							✓	✓																		
Video Link	✗	✗																								
Output devices																							✓	✓		

snapshot recalls  
TOTAL gain

✗

midi

✓

gpo relays

✓

Figure 26 - Snapshot Global Scope Panel

*Note: more information on snapshots and scope is available in Chapter 2: The Master Section*



1.4.3 Input Routing

Inputs are routed using the Channel Setup display, opened by touching the input area of the channel strip (Figure 25). It is also possible to open this display from the Channel List display, accessed via the Master Screen Menu **Layout > Channel List**. Activate the **Edit** button at the base of the display, expand the required channel type by touching its entry in the list, then touch the main input column within the required channel row. A Setup display will open within the Master Screen (Figure 27).



Figure 27 - Channel List with Setup Display

The buttons at the top of the channel Setup display to define the format of the channel: mono or stereo.

*Note: that Multi-channel formats are configured in a different way from mono and stereo formats, as described later in this chapter*

The channel format affects a number of functions within the Setup display, therefore it is advisable to select the format before any further configuration takes place. The current format of the channel is indicated in the channel strip by the number of meters displayed: One meter for mono channels and two for stereo.


For mono channels, each input channel has two inputs: a main input and an alt(ernative) input. These are selected using the 'main' button in the channel strip. The button is grey when the main input is selected and red when the alt input is selected. The input can also be selected using the main and alt buttons towards the top of the Setup display. These buttons light to indicate which one is currently selected (Figure 28). For stereo channels, the alternative input becomes the right side of the stereo input, and therefore no main and alt input selection buttons are shown.



Figure 28 - Alt Input in Channel Setup

*Note: The inputs available on an Input channel include feeds from the external IO racks, the local inputs on the back of the console and a variety of internal signals. Pressing either the main input or alt input routing button in the Setup display opens the Input Route display.*

(V1260+) Input Channels can be ripple routed by pressing or typing in the number of channels to be routed, then pressing the first input route source. There are two options for ripple routing, channel number or fader bank. Channel number is the default selection and routes channels in channel number order. So, if the first three channels in the bank are Ch 2, Ch 1, Ch 3: ripple routing from local IO gives Mic 2, Mic 1, Mic 3. Fader bank routes the channels in the order that they appear on the bank, so the routing in the example gives Mic 1, Mic 2, Mic 3.



#### 1.4.4 Input Configuration

If a channel is stereo, **balance** and **width** controls appear below the mono and stereo buttons. The left-hand blue, on-screen, rotary controls the balance and can be reset to centre by pressing the centre button below it. The right-hand blue rotary effects the width of the stereo signal, with a range from mono to wide. The width can be reset to stereo by pressing the stereo button beneath the width rotary. The value of the balance and width is displayed to the right of each rotary as a percentage divergence.



Stereo channels also have an m-s button, located above the input routing button, which switches in a decode function for replaying M-S signals as a normal stereo pair. There are three further buttons in this panel: L<>R swaps the channel's left and right outputs, L>L+R sends the left signal to both left and right busses, and R>L+R sends the right signal to both left and right busses.

#### 1.4.5 Channel Metering

Channel meters can be displayed in the top section of the Input channel strip, in place of the input and filters areas (Figure 29). To do this, press the Assign up arrow (SD7, Q7), or the Rotary Assign up arrow (SD8, SD10), or the Gain quick select and screen scroll up arrow (SD5, SD9, SD11, SD12, Q3, Q5), all located on the console's worksurface.





Figure 29 - Meter in Channel Strip

On Quantum consoles, switching the channel view from SD to Mustard will also switch the large meters at the top of the screen to display the relevant SD or Mustard dynamics metering.

A small SD or M indicator shows which of the 2 options is active.

### 1.4.6 CG/HARD mute indicators on the Meterbridge (Q7/SD7/Q5/SD5)

In the multi-layer meter view on consoles with meterbridges, there are indicators displayed for all 3 types of mute function – Channel mute, CG Mute and Hard mute.



### 1.4.7 Output Routing

Signals can be fed from Input channels to four different places: aux busses, group busses, insert sends and direct outputs. The top half of the output section of the Input channel strip contains the aux buss controls, as previously described. Touching under the pan controls opens the Output Display (Figure 30), from here the channel strip can be assigned to groups and to direct outputs. Outputs can be routed from the Channel List just like inputs (Figure 27).





Figure 30 - Output Routes

### 1.4.8 Pan Controls

The controls are formatted to match the format of the buss with the most components:

- Where there are only stereo or LCR busses, a simple pan slider is shown (see below left). Move the slider to adjust the pan. A text box indicates the panning position as a percentage from the centre towards the right.
- Where there are LCRS busses, a two-dimensional panning scope is shown (see below centre). Move the central grey square to adjust the position. Text boxes indicate the left-right and front-back position.
- Where there are 5.1 busses, a two-dimensional panning scope is shown, along with a pink LFE level control (see below right). Move the central grey square to adjust the position. Text boxes indicate the left-right and front-back position, as well as the LFE gain.



To send a channel to the LFE channel of the 5.1 buss, the LFE level must be assigned to a rotary row. Pressing the rotary button then toggles the channel between being sent to the 5 channels but not LFE, just LFE, and both LFE and the 5 other channels of the buss.

There is also an LCR blend knob. This control allows adjustment of the amount of signal that is sent to the centre leg (where one exists) of a surround or LCR buss. In the extreme left LR position, no signal will go to the centre leg:



*Note: the pan of the Assigned channel can be controlled using the worksurface joystick (SD5,7,8,10). The pan control can also be assigned to one of the encoder rows. LR/LCR Blend is adjusted using the 2nd function button.*

### 1.4.9 Aux Buses & Assignable Controls

Within an Input channel strip, each aux send has a level rotary and on/off switch to the right. The switch is grey to indicate that the send is off, and red to indicate that it is on. The send level is displayed in dB on the right of the channel strip, underneath the aux number.

There are three places within the channel from which the aux sends can be fed (SD), as indicated by the source display immediately to the right of the level trim (Figure 31), these are pre-fader, post-fader and pre-mute.

On Quantum consoles, there are 6 locations for the aux send in the channel strip. These are: pre-fade, pre-mute, mid EQ/dyn, pre-EQ/dyn, pre-processing and post-fade.



Figure 31 - Aux Send Position

The source position can be changed by pressing the worksurface 2nd function button and using the buttons below the rotary encoders (with the aux assigned to that particular row of rotaries). The source for each aux can also be adjusted globally via the aux channel's Setup display.

On stereo aux sends, there is a pan control to the right of the on/off switch. This can be adjusted by pressing the worksurface 2nd function button and using the rows of encoders below the worksurface screen. The pan controls for each aux can be globally linked (or reverse linked) to the channel pan via the aux channel's Setup display.

At the bottom of the assigned channel SD7/Q7 worksurface controls, there are four dedicated aux encoders with buttons, which control four contiguous aux send rotaries and on/off switches for the Assigned channel.



The auxes controlled by these encoders and buttons can be selected using the scroll buttons to the left of the top encoder and is indicated by purple ring on the on-screen aux sends.

*Note: that this assignment is channel specific and will be recalled if the Assigned channel is changed and returned to that channel.*

The encoders and buttons immediately below the Channel Strip can be used to control either the aux sends, or a separate function. This function is referred to as the 'locked' function, as it does not change when the auxes are moved. The button at the end of each row, next to the LCD display, flips the assignment of that row between the aux sends and the locked function.

Touching any on-screen aux send assigns the highest available encoder row to that send and assigns any other available encoder rows to the aux sends below it. The scroll button outside the bottom left-hand corner of the screen can also be used to change which auxes are assigned to the encoders. (SD5,7,8,10)

*Note: that a maximum of six auxes can be displayed in the Channel Strip panel at once. The panel will always display the auxes assigned to the encoder rows below it. This means that the auxes controlled by the dedicated aux encoders in the channel worksurface controls may not be visible.*

By default, the encoders control the aux level and the button controls the aux on/off status. However, by pressing the 2<sup>nd</sup> function button (located on the surface), the button becomes the aux's send position selector and the encoder becomes the pan control of a stereo channel. On mono auxes, the encoder has no second function.

It is also possible to show all of the aux sends for a channel in a single display and assign them to the rotaries beneath the screen. This is done by assigning the required channel to the aux controls (the assigned auxes will be displayed in dark purple with a dark purple surround) then touching one of the assigned auxes. The layout of the display indicates which encoder each aux is assigned to; if there are more sends than rotaries, the assignments become scrollable using the Screen Scroll function. The Picture below shows an SD7 with 36 Sends.



Once you have adjusted the auxes in this display, you need to close it manually before opening any other channel detail display.

**(V1260+)** Aux sends/nodes can be safed individually, which includes aux send level, aux on/off, node solo (Quantum only), nodal processing (Quantum only) and KLANG parameters. All aux nodes in a channel can still be safed together by pressing the **all safe** button in the expanded aux send panel or aux node panel. To safe nodes individually, press the **node safe** button, then press on the nodes to be safed, which will be indicated by the aux node text turning red. Once the safes are complete, press the **node safe** button again.

(V1455+) A **more/less** button has been added to **Aux Expanded** panel that will increase the panel size to show up to 5 rows of aux sends depending on the session. These can be scrolled to assign them to under screen rotaries.

More/Less button folds and unfolds up to 5 rows of aux sends.



*Note that when folded the amount of auxes displayed in the **Aux Expanded** panel will depend on how many rows of assignable rotaries a console has.*



...then pressing an  
Aux send rotary

*Note: that further worksurface assignments of auxes is available via the Surface, Faders and Solo tabs of the Options menu*





### 1.4.10 Aux Nodes Panel (all consoles) and Nodal Processing (Quantum only)

In **Layout > Aux Nodes**, there is an **input/groups** button, and an **aux buss** button.


The **input/groups** button will show the aux sends per channel for the last selected channel.

The **aux buss** view will show all the channel contributions or group contributions to an aux buss.

When in **aux buss** view, either channels or groups can be shown in the aux contribution panel. This is selected in the **show** section located bottom right corner of the panel.



When a console has more than 128 input channels, the **129-256** button will become available.



Along the top and bottom of the panel are function buttons.

**Solo node** Each aux node can be soloed. This feature can also be accessed from the channel screen expanded aux panel or from the nodal processor control panel. The circular node On/Off indicator will show a green “s” when nodal solo is active.

If **Options>Solo>Solo Displays All Aux Sends** is enabled, soloing either an input channel or an aux master will open the **aux nodes** panel with the appropriate view selected.

The **follow selection** button links the input/groups view and aux buss views together. If a node has been selected, switching between **input/groups** and **aux buss** view will show the sends for the selected channel.

For Example, in **input/groups** view select aux 17. When the **aux buss** view is selected, this will show all the contributions for aux 17. If in **aux buss** view the node for CH3 is selected, when the **input/groups** view is selected, the aux sends for Ch3 will be shown.

The **bring to surface** button will bring the selected channel or buss to the worksurface and open the nodal processing panel if active.

There are three Nodal processing mode buttons in the **Aux Nodes** panel.

**Add.** Touching **add** then selecting an aux node will activate nodal processing for that aux send.


**Bypass.** Toggling this control will temporarily bypass the Nodal processing on the selected aux send. This function is not recallable with snapshots.

**Remove.** This will remove nodal processing from the selected Aux send.

### Nodal Processing.

Each Aux node send can have SD Nodal EQ and Dynamics inserted in its audio path. The maximum number of aux nodes available simultaneously depends on the model of Quantum console. The number of nodes in use is displayed in the Diagnostics panel. Each nodal processor also has its own entry in snapshot scopes and they are also included in the channel list.

If processing is active on a node, a purple P is displayed next to the node on/off button.




This status will also be visible in the channel strip aux display. When the node is touched in the **Aux Nodes** panel, the processing controls will be displayed and assigned on the screen where that channel is located. Both the EQ and dynamics controls will be displayed at the same time. There is also a control panel for aux node functions located in the bottom right-hand corner.



### Nodal Processing Copying

‘Copy To’, ‘Copy From’, and ‘Copy From Channel’ are available for Nodal Processing via a popup panel on the nodal processing expanded view. Processing can be copied from other nodal dynamics or SD channel strip dynamics.



The processing can be copied from the main channel strip or from other nodes

### 1.4.11 KLANG Nodes



KLANG Nodes can be activated on aux send to allow control of the channel's KLANG parameters. A KLANG button is displayed in expanded aux panel and the Aux Nodes panel after KLANG is enabled in the External Control panel (See Chapter 2 - 2.12.14).

To add or remove a KLANG node press the KLANG button, which will turn purple to indicate edit mode, and press on the individual aux sends to activate or deactivate a KLANG node. A KLANG 'G' will appear in the aux send box to indicate a KLANG node. When the addition/removal of KLANG nodes is complete, press the KLANG button again to disable editing.

When an aux send with a KLANG node is pressed, an expanded KLANG control panel is shown at the bottom right of the display.

A KLANG 'orbit' is displayed in the left-hand side of the panel, which displays the KLANG source position. When pressed, this will show an expanded orbit in which positional data can be adjusted.

To the right of this are the individual KLANG parameter adjustments: azimuth, type, elevation and solo (indicated by a green KLANG 'G'). On the right-hand side are controls for the KLANG send level and an on/off toggle. All of these on-screen controls are assigned to the under-screen rotaries. In the top row of the panel there are 'copy' and 'copy from' buttons to copy the KLANG and aux parameters to another KLANG node.

When KLANG is active, a new copy to KLANG button is visible in the copy levels drop down menu in the Aux master setup panel. This will copy the aux send levels to the KLANG levels for that mix and in that snapshot.



1.4.12 True Solo (Quantum only)

This function allows the user to copy any internal processing used on an output buss to the solo buss so that they get a true representation of what the artist is hearing. Any changes to the buss processing are updated in real time to the solo buss. The True solo controls are accessed from the **Solos** panel or by creating a macro that will directly open the True Solo panel.



### 1.4.13 Insert Point Locations (Quantum only)

As with aux nodes, each insert point can be moved Post Fader, Pre-Fader, Mid EQ/Dyn, Pre EQ/Dyn and Pre Processing. Only one insert point can be in each location at any one time.



### 1.4.14 Group Outputs

Group outputs are routed from within the groups section of the channel Outputs display. Touching the mono button to the left of the display produces a list of available mono groups in the right of the display and touching the stereo or surround format buttons produces a list of the other types of groups. These buttons 'light' to indicate that it is their group outputs list which is currently displayed, and 'half-light' to indicate that there is routing to busses of that format which isn't shown in the display. Touching any of the groups within each list routes the channel to that group. Each channel can be routed to as many mono and stereo groups as have been created.



Any mono groups being fed by a stereo channel will receive a L+R summed signal of the channel output. The lowest selected group output is displayed in the channel strip, below the left side of the channel name, and the currently selected direct output is displayed below the right side of the channel name. When a new session is created, the lowest numbered stereo group is always designated the Master (SD7/Q7), or the first of the largest group type (e.g. 5.1 group) is master (all other consoles). All input channels are routed to the master group by default, and the master fader(s) are assigned to it.


### 1.4.15 Mix Minus function on Quantum Consoles

A different Mono Mix Minus feed can be created at the Direct Output of any mono input channel.

Firstly, send all required signals (including the channel that is to be removed) to an existing Mono Buss and note the name of this buss.


Then open the Output routing setup on the channel that is to be removed (see picture below) and in the Mix Minus section press the button for the Mix Minus buss that you have just created.

When this channel's Direct Output signal is now routed to a physical console or rack output, the channel's input signal will be removed from the direct output signal.



### 1.4.16 Direct Outputs

Basic routing is described in your console's Getting Started section. Once the direct output has been routed, it is switched on by pressing the grey on button next to the output level meter in the grey area below the direct outs routing button. The direct out is taken post-fader by default but can be switched to pre-fader or pre mute by pressing the button to the right of the on button. The current selection is displayed to the right of the button.





## 1.5 Output Channel Specific Functions

### 1.5.1 Unfolding Channels

Group and Aux Channels which are stereo or surround have an Unfold button above their meters, which is used to display the components of the signal in their own channel strip with a master channel displayed to their left.

In the top section of the unfolded Master channel, buttons for each component channel allow you to define which channel's elements are displayed in the Folded View.

In the middle area of the unfolded Master channel, the links between component channels can be edited. Links function in the same way as Gangs but are limited to the components of a multi-channel signal. To edit links, press the Set Links button so that it goes red, then press the LINK buttons above the channel meters in the channels to be linked or unlinked - each button will take on the same colour, indicating that they are linked. To remove a link, press the LINK button while Set Links is active. Note that if you start a set of links and then de-link and re-link another channel, a new link set will be started, as indicated by the introduction of a new link colour. When you have finished linking channels, deselect Set Links. You can also clear all links and link all using the buttons below Set Links.

*Note: that if component channels have different settings when linked, changes in hidden, linked channels will be made relative to the change in the Folded View channel, but the display will only reflect the Folded View channel.*

Below the link buttons in the master, there are buttons for each element in the components' channels - trim & delay, filters & EQ, dynamics and faders & mutes. Pressing one of these buttons will cause that element in all the channels to match those of the Folded channel. Once you have finished with the unfolded view, press the FOLD button to fold the channels back together (Figure 32)




Figure 32 - Folded and Unfolded View

### 1.5.2 Group Channels Specific Functions


The Group channel input signals are defined within the Input channels **Output** display. The top section of the Group channel **Setup** display lists all of the currently selected **inputs** to that group. The inputs list can be scrolled using the scroll bar to the right if necessary. Below the list there are two buttons: **clear all** removes all of the input routes to that group. Pressing this button produces a confirmation box in which the clear all can be confirmed or cancelled. **connect all** routes all Input channels to the group. When **select** is toggled, multiple input channels can be routed to the group by pressing their LCD button which will change to green (Figure 33). Press **select** again once you are finished. The **join all** button places all input channels in the group,

*Note: With either the connect or clear all functions, you can exclude individual channels from the function by touching their faders when the button is pressed.*



Figure 33 - Assign to Group LCD Function

Group output Busses can send audio to Aux output busses. Pressing the Aux send button, located above the output meter, will open the expanded aux panel and the sends will be assigned to the under-screen rotaries. To access the aux sends for a stereo, LCR, LCRS or 5.1 Group, the Buss must be unfolded to show the individual legs, each leg having its own aux send levels.





### 1.5.3 Aux Specific Functions

As the Aux channel input signals are defined within the Input channels, there is no input selection available within the Aux **Channel Setup display**. There are, however, a number of **configuration options** in the top half of the **Channel Setup display**:



The set all sends buttons at the top of the Setup display affect the sends to that aux bus from all of the Input channels. The three buttons on the left, pre mute, pre fader and post fader, set the point in the channel from which the aux send is taken. The current send point is displayed next to the aux send level in the Input channels.

*Note: that send points can also be individually selected within the Input channel using the 2nd function button.*

Pressing the link pans button, located to the right of the pre mute button, links that aux send pan to the main channel pan in the Input channels. This button lights red to indicate that it is active. Further indication is provided by the aux pan slider in the Input channel strip being lit pink. Rev link pans inverts the link between the channel pan and aux send pan. Pressing aux to fader assigns control of all input channel's auxiliary sends to the channel faders.

Pressing aux to rotary assigns control of all input channel's auxiliary sends to the top available encoder row beneath the Channel Strip panel. The purple copy levels from buttons also affect the sends to that aux bus from all of the Input channels. The buttons list can be scrolled using the scroll bar on the right. These buttons are used for universally setting the aux send levels: Off sets the level to off and 0dB to 0db. fader sets each Input channel's aux send level to match the level of its channel fader.

The remaining copy levels from buttons copy a different set of Input channel aux send levels to that aux send.


*Note: that when a copy levels from button has been pressed, send levels can still be individually readjusted within the Input channel.*

Touching the mix presets button (below the copy mix levels from list) opens the Aux Mix Presets display, where you can store and recall presets of an aux send's parameters for all input channels, using the standard presets procedure, detailed in Section 2.

### 1.5.4 Buss EQ – SD5, SD7, SD10 & Quantum consoles

On selected SD/Quantum consoles, the option is provided to switch between either high-pass and low-pass filters, or 4 extra bands of parametric EQ on output busses. These extra bands of EQ are pre-insert. This allows up to 8 bands of EQ in total on an output buss.

Pressing the curve button on Pre-Insert bands of output EQ will switch the top or bottom two bands to be 24dB/Oct filters rather than parametric filters. The filter points are controlled by the EQ Freq control.



### 1.5.5 Addition Buss Features – Input Merge & Ident

The merge input function allows an additional signal to be mixed with a buss. Touch the top of the buss/output channel to open the setup panel (Figure 34).




Figure 34 - Merge Input

Pressing the merge input button will open the input routing panel for source selection. The level control adjusts the level of the selected signal that is added to the buss and an On/Off switch activates the merge function.

Below the **merge input** button there is a **tone** button. Pressing **and holding** this button will route the oscillator signal into the output buss. The level and frequency of the oscillator is set in the master screen oscillator panel.

## 1.6 Channel Signal Processing

Each channel type contains similar signal processing functions, including EQ and dynamics. Input channels also have high-pass and low-pass filters. Pressing on each of these areas of the channel strip will open the relevant signal-processing display.

### 1.6.1 Channel Filters (All SD and Quantum input channels and on SD8,9,11 output channels)

The filters section of the channel-strip is located below the input section of each input channel. It consists of two frequency rotaries, each with its own on/off button and a display of the filter's cut off frequency (the -3dB value) in Hertz. The low-pass filter is at the top and the high-pass filter is at the bottom, and both have a roll-off of 24dB per octave.

The filters directly follow the input section in the signal chain. The filters area is replicated at the top of the EQ/filters display, accessed by touching the EQ area of the channel strip. The filter can be configured using the dedicated filter encoders and buttons at the top of the channel worksurface controls:




A graphic representation of the filters is included in the EQ graph located below Insert A in the channel strip, described below. The red line in the graph represents the current filter settings.


*Note: that the filters section of the input channel strip may be hidden behind channel meters. In this case, moving the filter encoders will cause them to be displayed momentarily. To hide the meters and retain a permanent display of the filter controls, press the assign down button, located to the left of the encoders above the screen.*

### 1.6.2 Input Channel EQ

The SD and Quantum input channel EQ has four bands, each of which can be made dynamic. The four EQ bands are colour coded: Blue for HF, green for HMF, yellow for LMF and red for LF. The in-channel display is located below Insert A and consists of a graphic representation of the current EQ and an on/off button. The button is grey to indicate that the EQ is off, and red to indicate that it is on. The green line in the graph represents the frequency response of the EQ, and the red line represents the response of the filters – each line goes bright to indicate that it is on. The extent and brightness of the opaque area in the bottom half of the graph also indicates which elements are on. The central frequency of each band is displayed by small lines in the band colours, along the bottom of the graph.



Touching the EQ area of the channel strip brings up the EQ/filters display. The EQ section of the display is below the filters section and has another graphic representation of the current EQ at the top. Touching this EQ graph will open an expanded view of the graph. The EQ can be configured using the dedicated encoders and buttons on the worksurface which follow the same layout as the display:



In both the EQ/filters display and on the worksurface, each band has a  $\pm 18\text{dB}$  gain controller on the left, a frequency controller (ranging from 20Hz to 20kHz) top right and a Q control bottom right. Each rotary has its value displayed to its right.

Bands can be switched between a bell curve (which is the default setting) and a Hi/Lowshelf using the bell button. On SD5, SD7 & Q3, the bell button's 2nd function allows each band to be switched between prec (precision, where the Q is narrower on the cut curve than the boost curve) and class (classic, where the cut and boost Q curves are identical in width). The active setting is shown in red to the right of the bell button. Pressing the precision or classic buttons above the EQ controls will switch all four visible bands to that shape. The active button goes blue – if different bands are employing different shapes, neither button will be lit. The EQ is switched on using the eq on button between the HMF and LMF controls which rings red to indicate that it is on.

*Note: that when a band is in dynamic mode, it can also be switched on and off individually in the dynamic display. See below.*

Towards the bottom of the EQ/filters display are four grey buttons marked 'safe', 'flat', 'preset' and 'copy to'. Touching 'safe' adds the EQ to that channel's list of channel safes. Touching 'flat' resets the EQ gain controls to 0dB. Touching 'preset' brings up the Presets display which can be used to save and recall presets. Touching 'copy to' will open the copy to panel with the EQ section pre-selected. Below these buttons is a smaller round button which is also found at the bottom of the channel worksurface controls, for switching the signal-processing order. The default setting is EQ followed by dynamics, as indicated by the eq-dyn label being to the left of the button. Pressing this button reverses the order, as indicated by the labelling switching to a dyn-eq display to the right of the button.

### 1.6.3 Dynamic EQ

When any dynamic EQ bands are on, a dynamic EQ icon appears above the EQ graph in the channel strip (as shown on the previous page). The four boxes beneath the icon indicate the status of each band – each box is empty (light grey) when the band dynamics are off, dark grey when the dynamics are on but the band is off, and coloured when the dynamics and band are on. DiGiCo dynamic EQ can operate in two modes: 'over' or 'under'.


#### Over Mode

To place the dynamic module into Over mode, ensure that 'over' below the threshold control is highlighted red. When the signal entering the module passes the threshold, the EQ adjustment (as determined by the frequency and Q controls) starts to be applied, up to a maximum adjustment, determined by the EQ band gain control. The manner in which the EQ adjustment is applied once the threshold has been reached is determined by the attack, release and ratio controls.

#### Under Mode

To place the dynamic module into Under mode, ensure that the Over indication below the threshold control is illuminated.

In under mode, the maximum EQ adjustment (as determined by the frequency, Q and band gain controls) is applied when the signal entering the module is below the threshold. As the signal level approaches the threshold, the EQ adjustment is reduced to the point where there is no EQ being applied at the threshold. The manner in which the EQ adjustment is reduced as the signal level approaches the threshold is determined by the attack, release and ratio controls.



**Gain:** Sets the maximum EQ adjustment that could be applied

**Frequency / Q / Curve:** Adjusts the EQ characteristics

**Threshold:** Sets the threshold at which the EQ starts to be applied

**Attack:** controls how quickly the dynamic module responds to level passing the threshold

**Release:** adjusts how quickly the module responds to a fall in level


**Ratio:** controls how quickly the maximum adjustment is reached once the threshold level is passed.

Over Mode is generally used with a reduction in gain at a specific frequency, such that when the threshold is reached, a gradual reduction of level at that frequency is applied. This could be used to control a change in tonal characteristics as a singer pushes their voice to sing louder.

### 1.6.4 Output Channel EQ

The EQ located in each output Channel is similar in operation to the input channel EQ, with the following exceptions: Output channel EQs have either have 4 Bands of EQ and HPF/LPF (SD8,9,11) or eight bands – four pre-insert and four post-insert (SD5,7,10). Buttons in the channel strip (**pre-insert eq** and **post-insert eq**) and in the EQ display (**pre-insert bands** and **post-insert bands**) select which set of bands is assigned to the worksurface and display controls. All eight bands are shown in the EQ graph, with the pre-insert bands shown in lighter shades than the post-insert bands.

The **precision** and **classic** buttons above the EQ bands only affect the four bands currently displayed, and not the full 8 bands available. The pre-insert bands do not have dynamic EQ or bell-shelf switching.



### 1.6.5 Channel Dynamics

The SD channel dynamics includes two dynamics modules. Module 1 can be a compressor, multiband compressor or desser; Module 2 can be a gate, ducker, or compressor with high and low-pass filtering on a self or external sidechain.

The channel strip dynamics section is located below the **eq**. Each module can be enabled individually using the dynamics section next to the screen.


The display includes an input (**In**) meter and a gain reduction (**GR**) meter. The input meter has arrows to its right which display the current threshold values for each module.

Each arrow is distinguished by its colour, which matches its associated threshold rotary.


When Module 1 is in Compressor or Multiband mode, **threshold** and **gain** rotaries, each with a value display in dB, are also shown in the channel strip (when in Multiband mode, the threshold rotary affects all bands and the mid band's value is displayed).

The Desser only displays a threshold rotary and its value. There is a threshold rotary (with value display) shown for Module 2, with three status indication lights shown when in Gate or Ducker mode.



At the top of the expanded display are buttons marked **undo**, **safe**, **presets**, **copy to** and **graph**. Touching the undo button will undo the last change that was made to a parameter of the module. Touching **safe** adds the dynamics to that channel's list of channel safes. Touching **preset** brings up the Presets display which can be used to save and recall presets. Touching **copy to** will open the copy to panel with the dynamics section pre-selected. Touching **graph** opens up a view of the module in a graphical format.



Dynamics 1




Dynamics 2



### Dynamics 1: Compressor

In Module 1's compressor, **threshold**, **attack**, **release**, **ratio** and **gain** controls are provided, each of which function in the normal way. The compressor has an auto gain function which is switched on by pressing the **auto gain** button below the **ratio** rotary. This function automatically adjusts the gain makeup when changes are made to the **threshold**, thus keeping the compressor output steady. The threshold knee can be switched between **hard**, **mid** and **soft** using the **knee** button in the right side of the module. The gain reduction (**GR**) meter is duplicated in this display.



### Dynamics 1: Multiband Compressor

In Module 1's multiband compressor, each band includes all of the parameters found in the single band compressor. The link function remains available for the whole compressor and is not assigned to any band. The bands can be switched on individually using the **on** buttons in the left-hand side of each band, or together using the **all on** button in the display's right.



The crossover frequency between bands is controlled using the purple and red rotaries to the left of the hi and lo bands. Each crossover has a range of 20Hz to 20kHz, and the crossover frequencies are displayed below each rotary. Each band can be auditioned (destructively) by pressing the **listen** button below each gain rotary.

### Dynamics 1: Desser

The de-esser's controls are similar to those of the compressor, with the following exceptions: In the right side of the module, there is a band-pass filter control for the de-esser sidechain, with rotaries provided for the centre frequency and filter width. The -3dB points for the hi-pass (**hp**) and lo-pass (**lp**) frequencies are shown. The filtered sidechain can be auditioned by pressing the **listen** button. Note that there is no makeup gain included.





### Dynamics 2: Gate


Gates can be keyed by a different signal by pressing the **key** button below the **attack** rotary. This brings up a **Gate Key Route** display from which a key input can be selected. Consecutive channel gates can be keyed by consecutive input signals using the **ripple channels** function. The key button is ringed red and displays the key input in the text box to its right to indicate that another signal is keying the gate. The key input signal can be auditioned by pressing the **key listen** button underneath the **range** rotary.

There is a band-pass filter available: the **width** control adjusts the width of the band being passed, and the **freq** control moves that band through the frequency range. The hi- and lo-pass sidechain filter frequencies are displayed. To the right of the **link** button, there are red, amber and green status indication 'traffic lights'.



### Dynamics 2: Ducker

The ducker has the same controls as the gate, though the sidechain performs the opposite function of ducking the signal rather than gating it.



### Dynamics 2: Compressor

Module 2's compressor is identical to the single band mode of Module 1, with the addition of the band-pass filter in the sidechain as described above, and a sidechain input function (**S/C**) which functions exactly like the **key** function of the gate.




### 1.7 Mustard Channels (Quantum only)

Mustard channels are a feature of Quantum engines and work alongside standard SD channel strip processing, with both being available at once.

Mustard provides a tube/preamp modelling section, an EQ, a compressor with four different models and a gate/ducker.


The maximum number of simultaneous Mustard instances available is dependent on the model of console. In **System > Diagnostics > Engine**, there are two counters to display the amount of Mustard Channel Processing currently in use and the amount remaining.

A channel is counted as having Mustard processing active once any one of the Mustard modules are turned on. When this is the case, the channel will display the 'Active' icon above the Mustard processing icon, as shown below.



#### 1.7.1 Mustard Channel Strip

The Mustard channel strip layout and operation is similar to that of the SD channel strip, as shown below.




1.7.2 Insert Position

There are 5 selectable positions to choose from when enabling Mustard processing on a channel.

The default position for Mustard processing is between the EQ & Dynamics module (depending on the EQ/Dynamics order).

Two options will be unavailable as these are the locations of the channel’s Insert A and Insert B. These insert positions can be selected for the Mustard processing by changing the location of Insert A/B, at which point they become available.



1.7.3 Safes/Scopes

Each Mustard module (tube, EQ, dynamics) can be safed individually, with the tube safe including the insert position of the Mustard processing.


The global scopes follow SD processing with tube under input/trim, EQ under EQ and the compressor and gate under dynamics. Input/trim scope also includes the insert position of Mustard processing.

1.7.4 Presets

Channel presets can be created as normal and each Mustard module can be included or excluded in the recall scope.


Recalling a preset from within the view of a particular module will include only that module in the recall scope by default.

The insert position of the Mustard processing is included within the pre-amp scope.



1.7.5 Pre-amplifier Modelling

The Mustard pre-amp modelling section provides the user with a choice of either a simple tube model or a more advanced pre-amp model. This is chosen by selecting **type**, where a menu will display with the two options.



## Mustard Tubes

Mustard Tubes has a **drive** control, an **output** gain control, an on/off button and six selectable preset options.



**Odd harm** – This is a modern sounding, low gain distortion preset

**Even harm** – This is a vintage sounding, medium gain distortion preset

**Overdrive** – This is modern sounding, medium gain distortion preset

**Distortion** - This is modern sounding, compressed, high gain distortion preset

**Crunch** – This is a vintage sounding, high gain distortion preset

**High distortion** – This is a modern, heavy sounding, very high gain distortion preset

## Mustard Amp Model


The Mustard Amp Model is a two-stage, highly customisable distortion & overdrive processor.

Both stages can be switched to **odd** or **even** harmonics independently of each other. Even harmonics can create a triode-style distortion whereas odd harmonics can create a pentode-style distortion.

The **drive** control alters the input level to the first stage of distortion.

A **bias** control between the two stages can create asymmetrical distortion if desired. The midpoint value of 11 is the most transparent. Turning on the '**saturate**' option increases the effect of the bias setting.

There is a **high frequency boost** after both stages which applies a shelving boost above 6kHz. This is followed by the output gain.



### 1.7.6 Mustard Equaliser

Mustard EQ operates in a similar manner to the standard SD channel EQ, with four fully parametric bands.

When used on a channel alongside the standard SD processing, this allows the user to have double the amount of fully parametric bands.

The top and bottom bands can be switched to act as high and low shelf filters respectively, rather than bell.

The middle two bands can be switched from bell filters to all-pass filters.

There are also high-pass and low-pass filters (both 24dB/8ve).

### 1.7.7 Mustard DYN1 & DYN2

The Mustard channel strip gives the user a choice of four different compressor models, which are modelled on classic analogue compressors.

All of the compressor types give the user an on/off button, a wet/dry **mix** knob, and an output **gain** control. Other controls vary depending on the type selected.

The **mix** knob controls the balance between the wet (compressed) audio and the dry (uncompressed) audio. If it is set to 100%, there will only be the compressed signal at the output.

On all but the Green FET Limiter, there is a **threshold** control, along with high and lowpass filters in the compressor's side chain controlled by the **low** and **high** rotaries. The effect of the filters on the sidechain signal can be monitored by pressing the **s/c listen** button.

An external sidechain, that is shared with the gate/ducker, can be used with the compressor by selecting a sidechain source in the box underneath the gate/ducker controls and then selecting to send it to the compressor sidechain.


**Classic - The Mustard classic compressor is a general-purpose feed-forward compressor design with multiple controls allowing flexibility.**

The **threshold**, **attack** time, **release** time, and **ratio** can be all controlled by the user.

A **hard** or **soft** knee can also be selected, and the sidechain's amplitude sensing can be changed between **RMS** (Root Mean Squared) level and **peak** (instantaneous) level.




**Vintage VCA** - The Vintage VCA compressor models classic VCA compressors, with a fixed attack time and an auto-release time. The user can set the threshold and ratio.




**Optical** - The optical compressor models classic opto-compressors, with a unique release characteristic that models the gain reduction provided by an optical compressor circuit. It has three options for attack time and recovery time, along with a ratio control.

The gain reduction also behaves uniquely by having a ratio-dependent maximum gain reduction value, with the compressor continuing to be linear above this value.




**FET Limiter** - The FET limiter has a fixed threshold like many classic FET limiters, however the input and output gain knobs can be adjusted accordingly in order to achieve the desired output level and gain reduction. The attack and release values can be adjusted and the ratio can be set at either 4:1, 8:1, 12:1 or 20:1.



**Gate/Ducker** - The gate/ducker works functions similarly to the gate and ducker found in the standard SD channel strip, however it has different attack and release shape characteristics.

An external sidechain source can be selected, which can then be sent to the sidechain of the compressor and/or gate/ducker



**Mustard Source Expander (V20xx+)** - In Quantum engines running V20+ there is a new processor type in Mustard Dynamics 2 known as the Mustard Source Expander.



The MSE reduces the level of a signal by a given amount when it is below a threshold. This works a bit like a gate but is better for non-transient signals, like vocals or brass. By reducing the level when the singer stops

singing, this can reduce the chance of feedback and generally reduce the level of stage noise spilling onto open mics. The controls available are threshold, depth (of up to 40dB) and release rate. There is also a sidechain available.


Press the **Type** button and the Mustard Dynamics 2 module and select MSE from the list of options.

## 1.8 LCD Functions

The LCD button/display is located above the channel fader and is included in every channel in both the centre section and side sections of the consoles. The channel number is displayed in the top half and the current function mode of the button is displayed in the bottom half of the display and is also indicated by its colour.



LCD buttons (SD5,7) or Select Buttons (SD8,9,10,11,12, Quantum consoles) are able to fulfil a number of different functions, and are even involved in selecting their own function. These functions are accessed by pressing the **LCD function** button, located above the **bank** buttons on each section of the desk. When this button is pressed, LCD displays for the channels associated with it turn yellow, indicating that they have become function mode selectors:



Selecting one of these options assigns that function mode to the LCD/select buttons for all the channels within the **banks** associated with that **lcd function** button. There are twelve different function mode options.

(1260+) The LCD function menu can be closed and have LCDs revert back to Solo function after a set period of time by turning on 'Auto-revert LCD menu to solo' and setting the duration in Options -> Surface.

### 1.8.1 Solo

When an **LCD function** button is pressed, the left-hand LCD display is labelled **SOLO**. When **SOLO** mode is selected, the LCD/select buttons become solo buttons. The bottom half of the LCD display indicates which solo busses are available to the channel, as defined in the channel **Setup** display and the **SOLO CHOICE** function mode (described below). The display also shows whether each buss is AFL or PFL, as defined in the top-left corner of the master solo display.

In **SOLO** mode, the LCD displays are coloured according to their channel type when not soloed, and coloured green when soloed.

*Note: this is the default mode of the LCD/select buttons, current when no other function modes have been selected.*

### 1.8.2 Solo Choice

When an LCD function button is pressed, the second LCD display from the left is labelled **SOLO CHOICE**. When this mode is selected, the LCD/select buttons are used to select the solo bus assignment for that channel, toggling between 1, 2 and 1+2. In **SOLO CHOICE** mode, the LCD displays are coloured cyan.

### 1.8.3 Gang

When an **LCD function** button is pressed, the third LCD display from the left is labelled **GANG**. When this mode is selected, the LCD/select buttons are used for linking together all channel controls. All LCD/select buttons which are then pressed will have their controls linked. In the case of currently ganged channels, the LCD/select button can be used to remove them from their ganging group. The colour of the **GANG** symbols in the bottom left-hand corner of the on-screen channel display indicates what ganging groups exist: All faders which are ganged together will share one colour. Each time the **GANG LCD function** is selected, a new ganging group is started, as indicated by the **GANG** symbols turning a different colour.

To gang channels across different surfaces of the console, activate the **GANG** LCD function on each surface before starting to build the gang. A single cross-surface gang can then be created using the LCD/select buttons in the usual way.

To stop adding channels to the current gang and start a new gang, simply reselect the **GANG** LCD function. When channels are ganged together, operating any of their channel controls will cause all other channels within the ganging group to replicate that movement. Pan and phase controls are not included in gangs.

*Note: it is the level change associated with the fader movement which is replicated, not the physical distance the fader is moved.*

*Note: that when a ganged channel is muted, those channels within the ganging group which were already muted will stay muted. When the channel is then unmuted, all channels unmute, irrespective of whether they had been initially muted.*

*Note: that when any member of a gang is Assigned, the Undo function will always take the faders back to their position when the channel Assignment was made. Channels can be temporarily isolated from Gangs by pressing the Option button.*

*Note: gangs cannot be edited once they have been created.*




1.8.4 Join CG (Control Group)

When an **LCD function** button is pressed, the fourth LCD display from the left is labelled **JOIN CG**. When this mode is selected, the LCD/select buttons can be used for assigning channels to Control Groups. Control Groups enable a number of channel output levels and mute functions to be controlled from one master fader. Control Groups can include any combination of channels from all four channel types. For more detailed information on Control Groups, please refer to the Master Section of this Manual.

1.8.5 Assign Faders


To assign channels to the worksurface, enter **ASSIGNFADERS** mode. The LCD displays will turn dark green and their lower halves will read **ASSIGN**. Press the LCD/select buttons for each of the channel strips to which you wish to assign new channels.

Press the **LCD function** button then **ASSIGN FADERS**



Press the LCD buttons for assignment

Go to **Layout > Channel List** on the Master Screen and expand the group of channels you want to assign and then click on the first channel you want to apply



To select the channels you wish to assign to those channel strips, open up the **Channel List** display, accessed by going to the master screen and touching **Layout > Channel List**. There you will find a list of all input, output and control channels that are present in the session structure, grouped by channel type. Open up the channel list for the channel type of the first channel to be assigned by touching the appropriate down arrow in the left-hand column.

The channel list can be scrolled using the scroll bar on the right of the display: To assign one of the listed channels to the channel strip, simply touch the channel name in the list. The remaining channels can now be assigned in the same way, the channels selected in the **Channel List** display are assigned to the selected channel strips in ascending order, starting with the lowest channel in the bank.

- Note: the assign function is restricted to the currently selected bank.*
- Note: that when new channels are added to a session, or when a session is created, all of the existing channels can be assigned to the worksurface using the rebuild banks function within the Session Structure display.*

### 1.8.6 Unassign Faders

To remove channel assignments from a channel strip, enter **UNASSIGN FADERS** mode. The LCD displays will turn dark green and their lower halves will read **UNASSIGN**. Press the LCD/select button for any channel strip you wish to clear, and the strip will go blank.

### 1.8.7 Swap Faders

To swap the positions of two channels, enter **SWAP FADERS** mode. The LCD buttons will turn dark green and their lower halves will read **SWAP**. Press the LCD button for the two channels you wish to swap, and they will swap places.

### 1.8.8 Move Faders

To move channels within a channel strip, enter **MOVE FADERS** mode. The LCD buttons will turn dark green and their lower halves will read **MOVE>>**. Pressing any LCD button will result in that channel moving one space to the right. If the bank is full all channels to the right of the moved channel will move right, and any channel which had been occupying channel-strip 12 will be lost from the layout. If there is a blank channel strip anywhere to the right of the moved channel, any channels further right than the blank will not move, and the moved channels will simply fill the blank space.

For example, if the bank is occupied by input channels 1 to 12, pressing **MOVE>>** on channel 6 will result in channels 6 to 11 moving one space to the right, leaving a space in channel strip 6, and channel 12 being removed from the layout. Pressing **MOVE>>** on channel 4 will then result in channels 4 and 5 moving one space to the right, filling the space that was in channel strip 6 and leaving a space in channel strip 4.

When blank channels are moved they simply swap positions with the channel to their right. Note that any blank channels immediately to the right of the one being moved will move as well, and the blanks will move by as many channel strips as there are blank spaces being moved.

For example, if channel strips 1 to 3 are blank and Input channels 1 to 9 are occupying strips 4 to 12, pressing **MOVE>>** on channel strip 2 will result in blanks 2 and 3 swapping places with Input channels 1 and 2.

### 1.8.9 Copy Bank From

To copy a different bank of channels to the current bank location, press **COPY BNK FROM**. The message '**PRESS | A BANK | BUTTON | FOR | COPYIN | FROM**' will be shown across the LCD displays. Simply press the **bank** button for the bank which you want to copy to the current location.

### 1.8.10 Copy Bank To

To copy the current bank to different bank location, press **COPY BNK TO**. The message '**PRESS | A BANK | BUTTON | FOR | COPYIN | TO**' will be shown across the LCD displays. Simply press the **bank** button for the bank to which you want to copy.

### 1.8.11 Clear Bank

To clear all channels from a bank, press **CLEAR BANK**. The message '**CONFIR | CLEAR | BANK: | YES | NO**' will be shown across the LCD displays. Press **NO** to cancel the action or **YES** to continue.

*Note: banks can be moved between layers, and also between sections of the console.*

*Note: also, that the Fader Banks display on the master screen can also be used for altering the bank layout.*

*Note: also, that there is no undo function for these actions. Proceed with care!*

1.8.12 Create Multi

The final LCD function, **CREATE MULTI**, is used to place new Multi channels onto the surface. When active, the LCD function buttons of any assigned faders will remain in their **SOLO** mode, whereas all unassigned faders will be available for creating new Multis. Once created, Multis can be configured in the normal way, as described below.


1.9 Multi Channels

If you are working in Surround, or using another multi-channel format, you can create LCR, LCRS and 5.1 busses in the Session Structure window described in Chapter 2.

1.9.1 Creating a Multi

Multi-channel inputs are controlled by routing each component through a mono channel and then linking those channels via a 'Multi' channel. To start with, use the normal input and output routing procedures to route each component through a channel. There are then two options for creating a Multi-channel: If you want to create the Multi in place of the channel strip for its first component, open the **Channel Setup** display for the first component and select **Multi** at the top. Alternatively, if you want to create a Multi in a previously unassigned location, use the **CREATE MULTI** LCD function described above.

Whichever procedure you use to create the Multi and assign it to a fader, you will now be presented with a **Setup Multi Channels** display. Select the format – **LCR**, **LCRS**, **5.1** or **multi-input** (which allows you up to 11 components) – and then press the LCD buttons for the remaining component channels, working down the displayed list in order. Channel names will appear against each component. Channels can then be left on the worksurface or removed using the buttons towards the base of the display. Finally, touch **OK** to close the display to link the channels together.



Multi's can be unfolded in order to access controls for each component. This is done by pressing the **Unfold** button in the channel strip. When unfolded, the normal channel assignments are hidden, each component is given its own channel strip, and a Multi master channel is displayed to their left.

*Note: if leave (channels on the surface) was selected when the Multi was created, the component channel strips are available whether or not the Multi is folded.*

In the top section of the unfolded Master channel, buttons for each component channel allow you to define which channel's elements are displayed in the Folded View, if any **Folded Controls** are activated (see below).

In the middle area of the unfolded Master channel, the links between component channels can be edited. Links function in the same way as Gangs, but are limited to the components of a multi-channel signal. To create or edit links, press the **Set Links** button so that it goes red, then press the **LINK** buttons below the channel names in the channels to be linked - each button will take on the same colour, indicating that they are linked. To remove a link, press the **LINK** button while **Set Links** is active. Note that if you start a set of links and then de-link and re-link another channel, a new link set will be started, as indicated by the introduction of a new link colour. When you have finished linking channels, deselect **Set Links**. You can also **clear all links** and **link all** using the buttons below **Set Links**.

Below the link buttons in the unfolded Multi Master, there are buttons for each element in the components' channels - **trim & delay**, **filters & eq**, **dynamics** and **faders & mutes**. Pressing one of these buttons will cause that element in all the channels to match those of the Folded channel. Once you have finished with the unfolded view, press the **FOLD** button to fold the channels back together.

In folded view, the channels included in the Multi are shown in the middle of the Multi channel strip. Touching the **Folded Control** button brings up four buttons which allow you to define which channel elements are displayed in the folded channel strip: **Input**, **EQ**, **Dynamics** and **Aux Sends**. These settings reflect the channel which has been set as the Folded View channel; the Folded View Channel is shown with a blue (as opposed to black) channel number in the list displayed in the folded channel, if any Folded Controls are activated. Adjusting any element in the Folded channel strip will affect all linked channels.

*Note: If channels have different settings when linked, changes in hidden, linked channels will be made relative to the change in the Folded View channel, but the display will only reflect the Folded View channel.*

*Note: that activating the Aux Sends Folded Controls will result in the channel components list becoming hidden.*

The fader and mute on the Multi channel strip will always affect all of the Multi members irrespective of the link settings and thus serves as a "Master" fader and mute for that multi's members. The on screen indicators for **Channel Mute**, **Hard Mute** and **CG Mute** at the bottom of the Multi strip give an indication as to whether any of the Multi members are Channel Muted, Hard Muted or CG Muted. If any member has any one of these types of mute active, the Folded Multi's indicator will show this.


In the Folded Multi view the worksurface Mute switch can have one of three different states:

- 1) Not lit (OFF) - the Multi Master Mute is not active - unmuted. Note that if any channels are muted individually, the **mute** indicator below the **unfold** button will be red.
- 2) Lit and red (ON) - the Multi Master Mute is active - muted.

3) Flashing from OFF to ON - the Multi Master Mute is active but at least one of the members has been unmuted (opened) thus overriding the Multi Master Mute on one or more of the Multi's Members.

### 1.9.2 Edit Multi

At the bottom of the Multi strip there is also an **Edit Multi** button which allows the members of the Multi to be changed or the Multi to be cleared or deleted. Pressing this button will open the **Setup Multi Channels** panel. To edit the members of the Multi, press one of the grey buttons on the left to select a member and then press one of the worksurface Channel Select buttons to assign a channel. To clear the Multi, press the **Clear All** button at the top of the panel and then either select a new type of Multi or delete the Multi completely by pressing the **Delete Multi** button at the bottom of the panel.



## **Chapter 2: The Master Screen**

This chapter describes all of the functions accessed from the Master Screen. The chapter focuses on the functions of the menu buttons across the top of the Master Panel, working through the buttons from left to right. Master Section worksurface elements are described within the context of the Master Panel display.


To open the Master screen, press the worksurface 'master screen' button (on relevant consoles).

## 2.1 System Menu

### 2.1.1 Diagnostics


The **Diagnostics** displays status reports for various elements of the console system.

*Note: Indicators displayed may differ according to console model.*



### 2.1.2 Oscillator

The oscillator is configured in the **Oscillator** display.



The frequency of the oscillator is controlled by the left-hand **frequency** on-screen rotary, and its audio level is controlled by the right-hand **level** rotary. The buttons below each rotary, can be used to set the oscillator to standard frequencies (**100Hz, 440Hz, 1kHz, 10kHz**) and levels (**-3dB, -6dB, -12dB, -18dB**). The current value of each parameter is displayed below its respective rotary.

For Stereo channels, the 1 kHz oscillator can be set to produce a pulsing ID signal on the left signal or a GLITS signal as indicated by the on-screen graphic.


2.1.3 GPIO Relays

Selecting **GPIO Relays** opens a panel displaying the current GPI and GPO states. The panel will show the GPIO configuration for your console. The numbered '**out:**' buttons allow GPOs to be triggered. If the **toggle** button above them is active (lighter), then touching a GPO button will switch it on (red) or off (brown). If the **pulse** button is active, touching a GPO button will send an 'on' pulse.

*Note: GPOs which are on when entering pulse mode will stay on. Touching them while in pulse mode will switch them off.*

The **GPI event** light in the top right-hand corner indicates when GPI messages arrive. Below the GPO buttons is a row of indicators (labelled '**in:**') showing the current state of each GPI.

The **GPI macro mode** can be selected, either 'ON and OFF' to trigger a macro on both a low to high and high to low voltage transition or 'ON only' to trigger only on low to high transitions.




2.1.4 Security

Security modes are selected in the system menu, with a choice of three levels of access:

**Setup:** Users have full access to every function on the console.

**Live:** Access to elements of the console can be limited, and password protected.

**Unattended:** The console worksurface is locked and cannot be operated.



User passwords can be defined for the Live and Unattended modes. To set a password, press the **Set Password** button. Enter the old password then the new one twice and press **OK**. By default, the passwords are blank.




Change Unattended Password

CLOSE

existing password

new password

confirm new password

 OK

*Note: If you should forget your password, call your Distributor to obtain a reset password. Entering the master override password will allow new passwords to be set.*

To modify restrictions in Live mode, press the Set Live Restrictions button in the Console Security Panel. A range of parameters are shown, with a tick indicating that access is allowed and a cross that the item will be locked out in Live mode. Each group list can be expanded for item-specific restrictions by pressing on the down arrow in the left-hand column, as shown for FX below:

Live Security Restrictions

CLOSE

	channel name	input/trim	delay	filters	eq	dynamics	inserts	sends	fader	mute	panner	to groups	outputs	external
▼	Local I/O	✓												
▼	Rack 1	✓												
▼	MADI													
▼	USB													
▼	Input Channels	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
▼	Aux Outputs	✓	✓	✓	✓	✓	✓	✓	✓	✓			✓	
▼	Group Outputs	✓	✓	✓	✓	✓	✓	✓	✓	✓		✓	✓	
▼	Matrix Inputs	✓						✓						
▼	Matrix Outputs	✓	✓	✓	✓	✓	✓		✓	✓			✓	
▼	Graphic EQ				✓									
▼	Control Groups								✓					
▼	Talkback Input	✓	✓	✓	✓	✓	✓		✓	✓			✓	
▼	Talkback Outputs							✓					✓	
▼	Solo	✓					✓		✓				✓	
▼	Multis								✓					
▼	Local I/O												✓	
▼	Rack 1												✓	
▼	MADI													

change Control Group members

✓

change Snapshots

✓

change Audio I/O devices

✓

change Gang members

✓

change Channel Presets

✓

change Audio Sync

✓

change Bank Layouts

✓

change FX Presets or types in use

✓

Quit to Windows

✓

change Session Structure or overwrite files

✓

2.1.5 Signal Over Indicators

Pressing this entry in the **System** menu opens the **Signal Overs** panel, showing details of any signals which have peaked. Touching an entry in the Signal Overs list brings the channel to the surface to be adjusted. The **Signal Overs** panel also duplicates the **Clear Over Indicators** button.

*Note: The Signal Overs panel can also be set to open automatically when a signal peaks. This is done in the Status tab in the Options menu.*

2.1.6 Overview Clear Screen


Some panels such as the information bar and the status indicators can be dragged with the trackball to an external overview screen. To quickly reset the position of these panels back to the Master screen, press the **Overview Clear Screen** button, and select **Yes** in the confirmation pop-up which appears.

2.1.7 Clear Master screen

[V1455+] A System Menu item and associated Macro “**Clear Master Screen**” has been added under the **System** Command Type. This closes all the panels which can be opened by the user using the master screen menu buttons, except for the Snapshots/Cues panel.

2.1.8 Keyboard Help

The Keyboard Help button opens up a display detailing the console control elements which are available via an external keyboard (useful when using offline software):



2.1.9 F10: Reset FX

Pressing this entry in the **System** sub-menu will reset the FX module audio. This allows, for example, lengthy delay and reverb tails to be killed. To complete the reset, select **Yes** in the warning pop-up which appears.

*Note: This will briefly bypass all of the FX units.*

### 2.1.10 F11: Reset Engine

Pressing this entry in the **System** sub-menu will restart the audio engine

*Note: that this will briefly interrupt the audio - do not use this function unless absolutely necessary.*

### 2.1.11 F12: Reset Surfaces

Pressing this entry in the **System** sub-menu will reset all of the worksurface controls. This function will briefly interrupt the audio on the Local I/O only.

### 2.1.12 Reset Computer

Pressing this entry in the **System** sub-menu shuts the console's control computer down and restarts it. If the session is not saved, pressing **Restart** will bring up a warning display. Press **Yes** to restart without saving, or **No** to cancel the restart.

### 2.1.13 Set Date & Time

Pressing this entry in the **System** sub-menu will open the Date and Time window for the console's operating system.

### 2.1.14 Enable Extensions

Some SD and Quantum consoles can be upgraded to include a theatre mode (SD7, SD9, SD10, Q7, Q2) and a broadcast mode (SD7, SD9, SD10, SD11, Q5, Q7) which can be purchased from DiGiCo or an authorised dealer.

Navigate to **System > Enable Extensions**, provide the dealer with your console's license number and they will provide you with instructions on how to complete the upgrade.

### 2.1.15 Quit to Windows/Home

Pressing this entry in the **System** sub-menu quits the console software but leaves Windows or Quantum Home running. If the session is not saved, pressing **Quit to Windows/Home** will bring up a warning display. Press **Yes** to quit without saving, or **No** to cancel the quit.

### 2.1.16 Shutdown

Pressing this entry in the **System** sub-menu shuts the console's control computer down. If the session is not saved, pressing **Shutdown** will bring up a warning display. Press **Yes** to shut down without saving, or **No** to cancel the shutdown.

### 2.1.17 Shutdown All

When consoles, engines or remotes are mirrored together in Full Mirror or expander mode, an additional **Shutdown All** button will appear at the bottom of the system menu. When pressed, it will shut down all SD/Quantum consoles or remotes which are in either Full Mirror or Expander mirroring modes.

## 2.2 Files Menu

### 2.2.1 Templates

Touching on **Templates** in the **Files** menu brings up the **Session Templates** display. This lists any ordinary session files which are located in the folder D:\Templates (or C:\Templates in offline), along with key session information.

*Note: If this folder doesn't exist, it should be created manually. The required template sessions can then be copied into it.*

**[V1455+]** A **Save as template** option in the **Save as New File** panel allows the user to save the entire session as a single template, the session template is saved into the templates folder, subsequent saves using the save session button or macro will save changes into the sessions folder not the templates folder.

[illegible]

To load a Session Template, simply select it in the list and touch the **Load** button.

### 2.2.2 Session Structure

Touching on **Session Structure** in the **Files** menu brings up the **Session Structure** display. This is where a session is named and where the channel allocation and sample rate for the session are configured. While changes to session structure can be made once a session has been started, it is best to try and set these parameters before configuring the session. Session Structure changes are not implemented until the **Restructure** button in the bottom right-hand corner of the display is pressed.

To name the session, touch the **session title** box, type the session name using the either the on-screen or external keyboard, and press **OK**.

Set the Session sample rate at the top of the panel.

Below the session title, each channel type has its own setup row, which includes **clear all** and **auto-route** buttons, and a display of the current number of channels in the session. To adjust any of the channel allocations, touch on the associated channel count box, and either enter a number using the pop-up number keypad or adjust using the assigned touch turn controller.

On some consoles, the matrix inputs, matrix outputs and control group allocations are fixed.

For specific console model information, please refer to Configuring Session page in the Getting Started Section.

*Note: That processing channels are reserved for the master buss, talkback channel and stereo solos.*

The screenshot shows the 'Session Structure' panel with various controls and their functions explained by annotations:

- Touch numbers to edit with pop-up keypad or TouchTurn**: Points to the 'channel count' box showing '108'.
- Select session sample rate**: Points to the sample rate selection buttons (48kHz, 96kHz, 96kHz, 96kHz).
- Enter Session title**: Points to the 'session title' input field.
- Set number of Inputs Channels**: Points to the 'input channels' row.
- Set number and type of Aux**: Points to the 'aux busses' row.
- Set number and type of Group**: Points to the 'group busses' row.
- Set number of Matrix Inputs**: Points to the 'matrix inputs' row.
- Set number of Matrix Outputs**: Points to the 'matrix outputs' row.
- Set number of Control Groups**: Points to the 'control groups' row.
- Total number of unallocated processing**: Points to the 'spare: channel processing' box showing '87'.
- Total number of spare busses**: Points to the 'busses' box showing '88'.

The panel also includes a 'DEFAULT ALL' button, a 'Restructure' button, and a 'Cancel' button. Two side panels are visible: 'Order of Group Busses' and 'Order of Aux Busses'.

The above figure shows the SD7 Session Structure Panel. Pressing the Default All button followed by the Restructure button will automatically configure a new session where the inputs from Audio I/O Port 1 are routed to input channels and the Master Buss is routed to Local outputs 1 & 2, also to Port 1 rack outputs 1 & 2. All input channels will be routed to the Master Buss and the console headphones will be fed by the Master Buss when nothing else is soloed.

If the **clear all** button is pressed, any non-default routing or processing (EQ, dynamics etc) will be cleared from the channels in the session when the **Restructure** button is pressed. This is especially useful when restructuring an existing session to make a new session.

The **auto-route** button automatically routes the physical inputs and outputs in the rack to the inputs and output channels in the session when the **Restructure** button is pressed, thus saving the operator from manually routing them in the channel **Setup** and **Output** displays. For example, auto-routing 48 inputs will route the first physical input (e.g. 1: Mic 1) to input channel 1, the second physical input (1: Mic 2) to input channel 2 until you either run out of inputs or channels. Auto-routes are as follows:

- Input Channels auto-route with physical inputs
- Aux, Group and Matrix Channels auto-route to physical outputs
- Matrix Inputs auto-route with group outputs

*Note: Auto-routing can only be used in conjunction with the Clear All button and is not available for input channel direct outs.*

*Important Note: Auto-routing overwrites any previous input and output routing.*

*Note: The outputs of Aux, Group and Matrix channels are auto-routed in sequence: Aux outputs followed by Group outputs, followed by Matrix outputs.*

The send point for input channel direct outs can be set globally using the **direct sends** button toward the top right-hand corner of the display. The button is made active by touching the input channels **Clear All** button. The **direct sends** button then toggles between **Post-Fader**, **Pre-Fader** and **Pre-Mute**.

Similarly, the send point for aux channel outputs can be set globally using the **aux sends** button to the left of the **direct sends** button. The button is made active by touching the aux busses **Clear All** button. The **aux sends** button then toggles between **Post-Fader**, **Pre-Fader** and **Pre-Mute**.

### Aux and Group Order

By default, the aux and group channels are ordered with the stereo channels following the mono channels. These orders can be altered in the **Order of Aux Busses** and **Order of Group Busses** displays, accessed by pressing the **Aux Order** and **Group Order** buttons on the right-hand side of the display.

Busses can be added using the buttons in the top-right of the display. To change a busses position or delete it, touch the buss in the display's list and use the buttons in the bottom-right of the display.

*Note: that only the mono/stereo format of the Busses and their display within the input channel can be reordered in this display. Channel settings are not reordered. The console layout can be reordered using the Rebuild Banks function described below.*

**(1272+) Channel Order** As with aux and group order, channels can be reordered in the session structure panel where mono or stereo channels can be quickly added, deleted or moved.

The Master buss is the first of the largest buss type (or first stereo buss on SD7/Q7), regardless of the order you place the busses in.

The **audio i/o** and **comms** rows beneath the standard channel-type rows allow the settings of the audio io cards and talkback function to be reset.

The **clear snapshots** and **clear macros** buttons towards the bottom-right of the window can be used to clear any existing snapshots and macros when making a new session.

**Rebuild Banks:** When changing the number of allocated channels in any section (input channels, busses etc), you can restructure the session without rebuilding banks, meaning that any additional channels you have allocated will not be “placed” on the worksurface, and need to be manually assigned to faders. If, however, you restructure a session with **Rebuild Banks** (either **Horizontally** or **Vertically**) enabled, the worksurface will be built with all channels available on the worksurface in a default layout. Rebuilding horizontally will result in input channels being spread across the top layer of both sides of the console, using as many banks as required, with output channels being assigned to Layer 2. Rebuilding vertically will result in input channels being assigned to Layer 1 on the left side of the console, and output channels to Layer 1 on the right. See the Session Structure section of Chapter 3 for more details.

*Note: that when Rebuild Banks is used, any non-default configuration of the channel layout is lost.*

To implement changes in the **Session Structure** display, touch the **Restructure** button in the bottom right-hand corner. To exit the display without implementing the changes, touch **Cancel**, located below the **Restructure** button.

To clear unimplemented changes from the display, touch **REVERT**, located in the top left-hand corner of the display.

### 2.2.3 Load Session

Touching this entry in the **File** menu opens the **Load Session** display. The left-hand column of the display shows the file directory. At the top of the directory are two buttons which switch the list of folders below them between the contents of the console computer’s **internal d:\Projects** folder and the contents of a **removable** USB drive. Each folder can be expanded by clicking the + symbol to its right. The list can be scrolled using the scroll bar to its right.

When a folder or sub-folder in the left-hand directory is expanded, a list of the session files contained within it appears in the list in the centre of the screen. The list displays the **Filename**, creation **Date & Time**, and **Description** of the session. In addition, the list also displays the number of **Inputs**, **Auxes** (mono, stereo), **Groups** (mono, stereo) and **Matrix** channels (ins/outs).

To load a session, touch the session in the list and press **Load**, located in the bottom right-hand corner of the display. To close the display without loading a session, press **Cancel**, located below the **Load** button and also found in the top right-hand corner of the display.

Once a session is loaded, a summary of the currently loaded session is displayed in the **Information Bar** which is normally found on the Master screen. Once any changes have been made to the session, the **File:** indication in this display will only show the folder of the most recently saved session, not the file name.


When active, keep old presets will add any existing console presets to the session being loaded. When disabled, existing presets will be cleared before session load.

*Note: If any of the buttons in the right-hand column of the window are active, sessions cannot be selected for loading from the list.*

Select Internal or  
removable USB, Internal  
files saved in D:\Projects

Select a file

File details



*Note: that column widths can be adjusted by dragging their borders within the title row. To return all columns to their default widths, press RESET WIDTHS, in the top left-hand corner of the window.*

### Partial Load

When a session file is selected from the list, the **Partial Load** button becomes available in the top right corner of the panel. Pressing this button opens the panel shown below where elements of the session can be selected for Partial Loading. Possible selections include ranges of Input channels, Matrix inputs, Matrix outputs and Graphic EQs, banks and layout, Presets and Macros.

There are also options to Partial Load all or some of the Snapshots from the selected session.

**Replace Snapshots** will remove the existing Snapshot list and replace it with the partially loaded one.

**Add Snapshots** will open a Snapshot list where snapshots can be selected to be imported into the existing session.

*Note: that if Snapshots are imported that contain data that the existing session is not capable of recalling (e.g. channels that don't exist) then this data will be ignored when the Snapshot is recalled.*

*The numbering of imported Snapshots will be the same as their original numbers so there may be duplication in Snapshot numbers after the import.*



REVERT

Partial Load Filters: session001.ses

CANCEL

channels to load...

input channels

from 1 to 56

matrix inputs

from 1 to 16

matrix outputs

from 1 to 16

graphic eqs

from 1 to 32

select to load...

replace snapshots

presets

add snapshots

custom names

macros

banks & layout

automation

Anything not included here for loading will be retained from the current session

Load

Select Snapshots to Add

CLOSE

select range

select all

num	name
1.00	1
2.00	2
3.00	3
4.00	3\$
5.00	35
6.00	8
7.00	8
8.00	3

2.2.4 Save Session

Touching this entry in the **File** menu saves the current session. Once the session has been saved, a confirmation pop-up appears displaying the location of the saved session file.

*Note: This function overwrites the most recently saved session. If you want to retain the most recently saved session, save the current session as a new session.*

### 2.2.5 Save As New File

Touching this entry in the **File** menu opens the **Save Session** display. At the top of the display are two text boxes showing a **file name** and **session title**. The **file name** will normally be 'sessionxxx.ses' where xxx is an auto-incrementing number and the **session title** is the same as the current session. If the session has not been changed since it was last saved, the file name will be the same as the current session. To edit the **file name** and **session title**, touch the relevant text box, enter the new name or title in the on-screen or external keyboard, and press **OK**. To overwrite another session, or to save the session in a new folder but with a previously used name, touch the session of that name and its name will appear in the **file name** box.

The location of the session file to be saved is defined in the directory in the left-hand side of the display. At the top of the directory are two buttons which switch the list of folders below them between the contents of the console computer's **internal** d:\Projects folder and the contents of a **removable** USB drive. Each folder can be expanded by clicking the + symbol to its right. The list can be scrolled using the scroll bar to its right. Touch the button and folder within which you want to save the session.

To create a new folder, select the location for the folder in the way described above, touch the **new folder** button in the right-hand side of the display, type the folder's name using the external keyboard and press the external keyboard's return button. To rename a folder, touch the folder within the directory, touch the **rename folder** button in the right-hand side of the display, type the folder's new name using the external keyboard and press the external keyboard's return button.

To delete a folder, touch the **delete folder** button in the right-hand side of the display, touch the folder to be deleted and touch **Yes** in the confirmation pop-up which appears.

*Note: This action cannot be undone.*

Once the session has been named and its save location has been selected, save the session by pressing **Save**, located in the bottom right-hand corner of the display. To close the display without saving, press **Cancel**, located below the **Save** button and also found in the top right-hand corner of the display. If you attempt to save the session under a file name which already exists within that folder, a pop-up appears, warning that continuing will cause the file with that name to be overwritten. Touch **Yes** to continue, **No** to cancel.

*Note: Overwriting the most recently saved session can be performed more quickly using the Save Session function described above.*

Once the session has been saved, a confirmation pop-up appears displaying the location of the saved session file.

To rename a file, touch the file to be renamed followed by **rename file**, located in the right-hand side of the display, enter the new name into the on-screen or external keyboard and press **OK**. If **rename file** is pressed without a file being selected, the first file in the list will be automatically selected for renaming.

*Note: The file name is the only file element that can be edited once the file has been saved.*

To delete files, select the folder containing the files to be deleted and touch **delete files**. To delete all files in the folder, touch **select all**, followed by **confirm delete**. To delete one file or a selection of files, touch the files you wish to delete followed by **confirm delete**. To delete a consecutive range of files, touch **select range**, touch the first and last files included in the range to be deleted, and touch **confirm delete**. To complete the deletion process, touch **Yes** in the confirmation pop-up which appears.

**[V1455+]** A **Save as template** option allows the user to save the entire session as a single template, the session template is saved into the templates folder, subsequent saves using the save session button or macro will save changes into the sessions folder not the templates folder.

Select Internal or  
removable USB, Internal  
files saved in D:\Projects

Enter file name

Enter description

Save As  
Template

*Note: Column widths can be adjusted by dragging their borders within the title row. To return all columns to their default widths, press **RESET WIDTHS**, in the top left-hand corner of the window.*

### Set Backup

Located on the right-hand side of both the **Load Session** and **Save as new file** panels, are the **Set backup** and **Copy Backup** Buttons. The backup function enables batch copying of session files to and from a connected removable drive. Press the **set backup** button and touch on the session files to copy to/from the removable drive. Once selected, an asterisk will appear in the "B" column of the panel. Now press the **copy backup** button and after the confirmation stage, the selected session files will be copied to/from the removable drive.

*Note: The Copy Backup button will not be available until a valid removable drive has been connected to the console's USB port.*

### 2.2.6 Load Presets

Touching this entry in the **File** menu opens the **Load Presets** display. This allows Channel, FX, Graphic EQ and Matrix presets created in other sessions to be imported into the current session. The left-hand column of the display shows the file directory. At the top of the directory are two buttons which switch the list of folders below them between the contents of the console computer's **internal** d:\Projects folder and the contents of a **removable** USB drive. Each folder can be expanded by clicking the + symbol to its right. The list can be scrolled using the scroll bar to its right.

When a folder or sub-folder in the left-hand directory is touched, a list of the Preset files contained within it appears in the list in the centre of the screen. The list displays the **Filename**, creation **Date & Time**, and **Description** of the preset file. In addition, the list also displays the number of **Input**, **Out** (fx), **GrEQ** (Graphic EQ) and **Matrix** presets contained within the preset file.

To load a set of presets, touch the preset file in the list and press **Load**, located in the bottom right-hand corner of the display. To close the display without loading a session, press **Cancel**, located below the **Load** button, also found in the top right-hand corner of the display.

*Note: A session's presets are also saved as part of the session file.*

*Note: If any of the buttons in the right-hand column of the window are active, sessions cannot be selected for loading from the list.*

### 2.2.7 Save Presets

Touching this entry in the **File** menu opens the **Save Presets** display. At the top of the display is a text box showing the **file name** of the most recently created presets file. It will normally be 'presetsxxx.pre' where xxx is an auto-incrementing number. To edit the **file name**, touch the text box, enter the new name or title in the on-screen or external keyboard, and press **OK**. To overwrite another file, or to save the file in a new folder but with a previously used name, touch the file of that name and its name will appear in the **file name** box.

The location of the presets file to be saved is defined in the directory in the left-hand side of the display. At the top of the directory are two buttons which switch the list of folders below them between the contents of the console computer's **internal** d:\Projects folder and the contents of a **removable** USB drive. Each folder can be expanded by clicking the + symbol to its right. The list can be scrolled using the scroll bar to its right. Touch the button and folder within which you want to save the session.

Once the presets file has been named and its save location has been selected, save it by pressing **Save**, located in the bottom right-hand corner of the display. To close the display without saving, press **Cancel**, located below the **Save** button, also found in the top right-hand corner of the display. If you attempt to save the set of presets under a file name which already exists within that folder, a pop-up appears, warning that continuing will cause the file with that name to be overwritten. Touch **Yes** to continue, **No** to cancel.


*Note: A session's presets are also saved as part of the session file.*

### 2.2.8 Global Set to Defaults

The **Global Set to Defaults** Panel, opened via the **Files** menu, allows certain settings to be applied globally to the console. Select the Channel type from the list on the left side of the panel, and then select the action from the list to the right. Most actions are self-explanatory, with the possible exception of the following: - **blend LR only** moves all the **LR/LCR** blend controls to **LR**.

- **blend LCR** moves all the **LR/LCR** blend controls to **LCR**
- **groups off** unroutes all sends to Groups

Note: that multiple channel types can be selected simultaneously.




The **undo** button in the top left undoes all changes since the panel was opened.

*Note: Once the panel is closed, changes cannot be undone.*

### 2.2.9 Session Notes

The **File** menu **Session Notes** button opens a panel in which can be used for saving any important session information:




### 2.2.10 Session Report

In the **Files** menu there is also a **Session Report** button. This lists the session details on the master screen in an RTF compatible format.

Across the top, the three **include** buttons can be used to define what optional extras are included in the report: **channels**, **audio i/o** and **snapshots**.

The **save to internal button** at the top right of the panel will save the report in the D:\Projects as the session file name suffixed with .rtf. The **save to removable** will save the report to any USB drive insert in the consoles USB port.




## 2.3 Layout Menu

### 2.3.1 Fader Banks

*Note: Not all the functions described in this section are available on all console models. The example below represents the full set of functions from an SD7.*

Touching on **Fader Banks** in the **Layout** menu brings up the **Fader Banks** display. This display allows the location of each fader bank to be altered. The bank buttons available within each layer of each section of the desk are displayed with their current fader set, with the left and right section banks on the left and right and the master banks down the middle. Towards the bottom of the display there are several grey function buttons which turn red to indicate that they have been selected.



To swap the locations of two fader sets, touch one set's bank so that it is highlighted in yellow, touch **swap** (located below the left fader bank's layer 1) and touch the other set's bank.

To move a fader set to a new bank location, highlight the fader set you wish to move, touch **move** (located to the right of the **swap** button) and touch the bank to which you wish to move it. If there is currently a fader set in the destination bank, the current fader set will shift down one, as will any other sets below it until there is a blank bank which can be filled. If a fader set located in the lowest bank of a layer is shifted down, it will move

to the first bank of the next layer. If there are no spaces between the selected destination bank and the end of the console section, a pop-up appears indicating that the move cannot be completed.

To copy a fader set to a new bank location, highlight the fader set you wish to copy, touch **copy to** (located to the right of the **move** button) and touch the bank to which you wish to copy it. If there is currently a fader set in the destination bank, it will be overwritten.

To clear a bank, highlight the fader set you wish to copy, and touch **clear** (located below the **copy to** button). Banks can be protected from being accidentally cleared by locking them: Touch the bank you wish to lock and touch **lock** (located below the **clear** button). On SD7, the **lock** button will turn light grey whenever a locked bank is highlighted. All banks can be locked by pressing the **lock** button to the right of the **all:** legend, underneath the right fader banks in the display.

*Note: Locked banks can still be moved and overwritten. If a locked bank is moved, the lock function stays with the fader set, not the bank location.*

The labelling within the bank LCD buttons can be edited using the text boxes in the bottom left-hand corner of the display. By default, the top row of the button displays a short version of the channel type (**Ch** for input channels, **Aux** for aux channels, **Grp** for group channels, **Matrix** for matrix channels and **CG** for control group channels) followed by the channel number range, and the bottom row displays the channel type in full. To edit the either row, touch its text box, type in the new name using the onscreen or external keyboard and press OK. The keyboard symbol to the right also activates the naming function for the top row.

*Note: This label affects the bank button displays, not the channel faders within the bank.*


On an SD7, the colour of the bank LCD buttons can be altered using the **button colour** buttons in the bottom right-hand corner of the display. By default, the LCD buttons are coloured to match the colour of their channel type: Light blue for input channels, purple for aux channels, red for group channels, light-green for matrix channels and dark blue for control group channels. The arrow buttons either side of the **button colour** legend can be used to cycle through the available colours, and the current colour selection is displayed in between them.

*Note: All of the default channel type colours are available for all bank buttons.*

The SD7's upper and lower master meter bridge rows can be locked to any of the eight banks on the master screen. This is done by pressing the **upper meters** and/or **lower meters** button which appear in the lower right-hand corner of the **Fader Banks** panel when a **master bank** button is selected. The **master bank** button will become outlined in red to indicate that it is locked to a row of the bridge.

Fader layer names can be customised on SD12, Q2, Q3, and Q7. These names will be displayed on the fader bank layer LCD displays.





**SD5, SD12 & Q3 re-assignable master faders**


In the fader banks display, the left and right master faders can be reassigned and un-assigned to any channel.

**2.3.2 The Overview Display**

A miniature graphic of each fader set can be displayed on the master screen, or on a separate screen connected to the **Overview** output on the back of the console. These graphics display the fader position, mute, solo status and insert status, and the meter for the channels within all displayed banks. The parameters displayed in this overview can also be adjusted on the overview screen using the external mouse. The **on overview** and **on master** buttons, located below the **Fader Bank** display's master banks, are used to include and exclude fader banks from the external overview display and the master panel respectively. All banks can be included in the overview display by pressing the **overview** button to the right of the **all:** legend, underneath the right fader banks in the display.


**(1272+)** A larger version of any bank overview graphic can be displayed on the master screen or an overview screen by pressing the **large** button under "view bank" after the bank has been selected. The standard size overview can still be displayed by pressing the **small** button. Faders and other controls on the large bank overview graphic can be controlled by touch.

All banks can be displayed on an overview screen at either small or large size by pressing the respective buttons next to "all:". Note that this will remove all bank overviews from the master screen. The **small overview** or **large overview** buttons will be lit red to indicate that all the banks are displayed in this size on an overview screen. To remove all bank overviews from an overview screen, press this button again.



2.3.3 Channel List

Touching on **Channel List** in the **Layout** menu brings up the **Channel List** display, containing a complete list of all the input, aux, group, matrix and control group channels which exist within the session. The channel list for each channel type can be expanded and collapsed by touching anywhere in the channel type row. Channel type rows can be distinguished from the specific Channel rows by their slightly darker colour.



If the **Edit** button at the base of the display is active (lighter), touching a channel will allow the name of that channel to be changed, the up/down arrows can be used to change multiple channels names in quick succession. Touching the **main input**, **alt input**, **insert A**, **insert B**, **groups** or **outputs** box for a channel will open up the appropriate **Setup** or **Routing** panel for that channel, allowing that routing to be edited. Touching the **safe** box will cause all of that channel's safes (and those of any linked channels) to be activated.

If the **Select** button at the base of the panel is active, the display can be used for adjusting the bank assignments of the session's channels. This function employs the **ASSIGN FADERS** LCD function mode. The channel's current assignment is shown in the layer/bank box: The surface (**L** or **R**; Master fader assignments are not shown), layer (**L**) and bank (**B**).


*Note: When new channels are added to a session, or when a session is created, all of the existing channels can be assigned to the worksurface using the rebuild banks function within the Session Structure display.*

In **Select** mode, the display can also be used for assigning a channel to the worksurface controls. This is done by touching a channel within the list and also results in the channel's bank being displayed in the appropriate side section of the console. If the channel appears more than once within the session layout, the lowest bank in which it appears is the one which will appear on the worksurface.

With either **Select** or **Edit** active, touching in a channel's **meter** box will cause a small meter panel for the channel to be displayed in the Master screen. This is meter display remains active regardless of whether or not the channel itself is currently on the worksurface. It is possible to permanently display up to 12 channels in this way. Pressing the **View** button at the bottom of any of these meters also allows them to be snapped to a grid, sized to either large or small, removed, and moved between the Master screen and Overview screen.

Touching channel can be used to change the name of channels. Using the up/down arrows on the keyboard, channels names can be changed in quick succession.

(1272+) Channels can be scrolled up and down using the arrows on the Channel Setup and Outputs Panels.



The most recent Preset used on the channel is also displayed, in the **last preset** box.

#### 2.3.4 Set Spill


Touching on **Set Spill** in the **Layout** menu brings up the **Set Spill** display, where channel Sets can be configured and spilled onto the console. A Set is simply a group of channels selected from across the console's layers, which can be 'Spilled' onto the worksurface together. They can be made up of a mixture of channel types and need not have anything else in common. The main part of the display is navigated in the same way as the **Channels List** described above.

To create a Set simply choose a Set column and touch the boxes in that column for each channel you wish to include, expanding the channel types as required. The boxes will all turn the same colour. The box in the channel type's parent rows will also turn the same colour, indicating that some channels of that type are included in the Set. the number of channels included in the Set is shown in the Set's **Spill:** box, above the channels display. Any channels which are included in a Gang are indicated by the Gang's colour being displayed on the right-hand edge of the channel's number box (at the left end of its row in the channel display).

To rename a Set, touch on its **Set Name:** box, type a new name on the on-screen or external keyboard, and press **OK**. To add all channels from a Control Group, touch the Set's **Add from CG:** box and touch the appropriate CG button from the popup which appears. The **Spill:** number will increment to indicate how many channels have been added. To clear a Set, touch its **Clear:** box and touch **Yes** in the confirmation pop-up which appears.

Sets can be spilt directly from this panel or assigned to a Macro. To spill a Set from this Panel, touch its **Spill:** box. A tick will appear by the spill number to indicate that the channels are spilt. To assign the Set Spill to a Macro, touch the Set's **Assign Macro:** box to bring up a display of the console's Macro controls; Now select a Macro button. The Macro's bank and position will be displayed in the Set's **Assign Macro:** box.

The Set Spill Direction entry in the Faders tab of the Options menu defines how Sets are spilt onto the control surface. Sets can be unsplit by pressing their Macro or **Assign Macro:** box, or by pressing the **Layer** button for the console section where the set is shown.




*The SD7 Set Spill panel*

2.3.5 Aux to Faders

This panel displays every aux buss in the current session and touching the buss will activate aux to faders. Macros are available for the additional panel controls.

(1272+) The Aux selection can be cleared when this panel is closed by pressing the **clear on close** button.



2.3.6 Aux Nodes

See Chapter 1

2.3.7 Join Groups

Touching on Join Groups in the Layout menu brings up the Join Groups display, containing a list of channel sets and a list of groups. Selecting individual or multiple groups allows individual channels or sets of channels to be assigned to those groups. To assign channel sets select the desired set from the list of sets, to assign individual channels use the LCD buttons of the desired channels.

(1272+) The join group function can be cancelled when this panel is closed by pressing the **cancel on close** button.

### 2.3.8 AMM Control (Consoles with DMI slots)

The DMI-AMM card automatically manages live microphones in unpredictable dialogue situations. When one person speaks, that microphone's gain level fades up instantly, while the other microphone gains are reduced. All microphone levels will adjust to medium gain to collectively match the level of one microphone at full gain. The resulting effect will be as if all speakers are sharing one microphone. When several people talk at once, the gain is shared.

Access to the AMM Controls (**Figure 1**) can be found in the Audio I/O window after conforming the DMI card (**Figure 2 & 3**) or by using the **Master Screen > Layout > AMM Control** button

The AMM Controls include a weight control and a group assign (Group **A** & Group **B**) for each AMM group for 64 slots within the card. The Floor control imposes a lower limit on the level detector for all microphones in the relevant AMM group to prevent a noisy microphone capturing a disproportionate share of gain. The weight should be left at the default value of 0dB and floors should be left at -130dB for normal operation.




Figure 2: Conform AMM

There are two ways to route channels to/from the AMM. The first is from within the AMM Control window itself. Touch the white box below each of the slots, this will open the AMM Routing window (Figure 4). Here you can ripple route channels to the AMM. The AMM is automatically assigned a Post-Fade Insert B. The AMM routing/assignment can also be ripple cleared and this will also force all insert Bs back to pre-fader mode regardless of its state prior to AMM assignment. It can also be assigned using the Insert B routing window, available by touching the bottom of a channel strip (Figure 5).

**NOTE:** The SD12 only provides a maximum of 32 Post-Fade Inserts but the AMM channels can also be routed via Pre-Fade Insert points if required. The Quantum 7 provides Post-Fade Insert options on all Input Channels.




Figure 3: Open AMM Control




Figure 4: Routing Within AMM Control




Figure 5: Routing via Insert B Routing Menu

When channels are routed to the AMM and assigned to AMM group A or B, a **Share %** bar is displayed in yellow on the right side of an AMM slot. This represents the gain Share that the channel is getting when the AMM is active. This meter is shown in terms of percentage, meaning that if 2 speakers are talking at the same time and at the same level then they will both get 50% of the gain share. The Weight control allows adjustment of the relative sensitivity on a per channel basis. When weighting controls are balanced (equal), each microphone has an equal opportunity to “take over” the system. Changing the weight will not have an effect on the overall level of the channel, just how easily it can take a share of the gain. Adding weight to one primary microphone ensures that the particular microphone (e.g. a chairperson) will get more of the share of gain (**Figure 6**).




Figure 6: AMM Share Percentage and Weights




Figure 7: AMM Master Controls

There are a set of master controls available at the bottom of the AMM Control window. These include a Floor control and a master group enable (active) switch for each AMM group within the card and a safe control. The Floor control imposes a lower limit on the level detector for all microphones in the relevant AMM group to prevent a noisy microphone capturing a disproportionate share of gain during quiet times. The Floor should be left at the default value of -130dB for normal operation. The safe option excludes these floor controls and the master group enables from snapshots.

All AMM parameters (both master and channel specific) are saved on a per snapshot basis and can be saved or removed from the global and recall scopes. Only input channels can be added to the AMM. It can be saved globally via the Input Devices option in the Global Scope menu on the Snapshots window. This is **NOT** enabled by default.




Figure 8: Global Scope > Input Devices



2.3.9 Transport Control

Touching on **Transport Control** in the **Layout** menu brings up a display of the transport control of an external playback device. Playback devices are controlled via the MIDI connector on the console's back panel. The incoming MTC is also displayed.



*Note: Control of external playback devices can be programmed within the Snapshots screen, as described later in this chapter.*

2.4 Snapshots Menu

Any number of Snapshots of the entire current console settings can be stored and recalled using the Snapshots panel. (This is only limited by system memory)

These Snapshots can be independent or grouped with other snapshots.

The recall scope of the snapshot (how many controls it will affect when fired) can be set by controller or by channel.

To display the Snapshots panel, touch the Snapshots button at the top of the Master Screen.

Worksurface controls are detailed in Getting Started.

Opens Global scope panel

Opens snapshot notes panel

Adds current snapshot to group

Lock prevents snapshot update

Snapshot under control of sequence

Removes snapshot from prev/next control

Shows individual snapshot option buttons

Opens individual snapshot recall scope

Opens group/auto-update scope

Opens snapshot crossfades panel

Opens snapshot recall times panel

Opens snapshot MIDI list

Opens snapshot MIDI program change

Opens snapshot GPO panel

Opens snapshot transport control panel

Opens control by MIDI panel

global scope

snapshot

notes

groups

locked

duration

current scope

fire at timecode

skip prev/next

scope

recall scope

group & auto-update scope

cross fades

recall times

midi list

midi program

gpo relay

transport control

control by midi

num	name	active scope	group
1.00	One	oooooooooooo	
2.00	Two	oooooooooooo	
3.00	Three	oooooooooooo	
+4.00	Four	oooooooooooo 1	Group 1
+5.00	Five	oooooooooooo 1	Group 1
+6.00	Six	oooooooooooo 1	Group 1

insert new

duplicate

update current

update group

update selected

edit range

move

rename

renumber

delete

fire prev

fire selected

fire next

undo

view options

auto-update

relative groups

*Note: The current snapshot appears in the panel as the highlighted entry in the list. The snapshot name displayed in green indicates that it is the selected snapshot on the worksurface and its name is indicated in the display. The Fire button recalls this selected snapshot and highlights it in the screen list as the current snapshot.*



*Note: An “update Waves only” button appears below the Scope buttons when Waves is active.*

If the current snapshot shows an asterisk next to the number (e.g. 001\*) this indicates that a controller has changed since the snapshot was fired.

If a Snapshot name appears in **black** in the list, it is a standard Snapshot and if it appears in **red** or **blue** then it is a member of a group of snapshots

#### 2.4.1 Storing a Snapshot

When a snapshot is stored all the console settings are saved but when the snapshot is recalled its effect can be limited to certain channels and controllers using the **Global** and **Recall Scopes**.

To store a snapshot of the current state of all the console controls, touch the Snapshot panel or worksurface **Insert New** button and a new snapshot will be inserted below the currently selected (green) snapshot.

Alternatively, if the **Touch to Fire** function is active, touch an unused button in the list and a new snapshot will be added to the end of the list, then type a name for the snapshot.

Another method of creating a Snapshot is to press the **Duplicate Selected** button and this will create a copy of the selected (green) Snapshot below it.

*Note: If Duplicate Selected is used, the Snapshot that is stored may not reflect the current state of the console's controls - it will simply create a copy of the Snapshot that was selected when the button was pressed.*

#### 2.4.2 Recalling a Snapshot

There are several ways to recall a snapshot:

1. Activate the **Touch to Fire** function using the button on the Snapshot panel and then touch the snapshot button you require.
2. The buttons on the Worksurface provide **Scroll Up/Down** buttons to change the selected snapshot named in the worksurface display and listed on screen in green.  
  
The **Fire** button then recalls the assigned snapshot.
3. The worksurface **Previous** and **Next** buttons can be used to step up and down the list firing snapshots in consecutive order.
4. Snapshot firing can also be controlled by specific events on MIDI channel 16 (See Snapshots and MIDI).
5. Assign a **Macro** button to fire the Snapshot.

#### 2.4.3 Replacing a Snapshot

To update or change a snapshot, set the console controls as required and then touch the one of the **Update** buttons (**Current**, **Selected** or **Group**)

*Note: The Current snapshot is not necessarily the one whose name appears in the display on the worksurface, this is the Selected snapshot. For a snapshot to be Current it must have been the last one that was fired and be highlighted in the on-screen panel's list.*

2.4.4 Editing Multiple Snapshots

Individual controller changes can be written to several snapshots simultaneously using the **Edit Range** button. This does not replace all of the data associated with the snapshot, just the elements that are changed at the time.

When the **Edit Range** button is pressed, a panel pops up allowing you to **Select Range**, **Select All**, or select individual Snapshots. You can now select the relevant snapshot(s) from the list.

If you press the **Select Range** button, touching the first and last snapshots in a range will automatically select all the snapshots in that range.

Once snapshots have been selected for editing, press the **confirm** button, or press **cancel** to cancel the **Edit Range** button.



With the **Edit Range** button active, pressing the Snapshot buttons does not fire the snapshots; it only selects them for editing. The selection may be changed by pressing and releasing snapshot buttons at any time during the operation of the Edit command, so a variety of controllers or routes may be changed in a variety of snapshots before completing the operation by pressing the **Confirm** button. The Snapshots window may even

be closed to gain access to other editable functions - In this case, a warning message will appear to advise the user that they are still in snapshot edit mode. While any Snapshot is selected, changes to any snapshottable controller, routing changes, and any changes to the Snapshot Scope controls can be written to every selected Snapshot, overwriting the previous settings. Pressing the **Confirm** button keeps the changes.

For example, if Snapshots 1 and 2 are selected and the input gain for channel 1 is changed, subsequent recall of Snapshots 1 or 2 will set channel 1's input gain to the new value.

Only channels which are altered while the Edit command is active will be affected and only in snapshots that are selected at the time.

*Note: Snapshot Scopes and Crossfade Times can also be edited for multiple Snapshots using the Edit Range function*

#### 2.4.5 Moving a Snapshot

If you wish the Snapshot list to appear in a specific order, you may change the order of the list by moving the entries. Touch the **Move** button and then touch the Snapshot that you wish to move. You then touch the point in the list where the snapshot should be moved to.

#### 2.4.6 Renaming a Snapshot

To rename a snapshot, touch the **Rename** button, then the name that you wish to change and enter a new name using the keyboard.

#### 2.4.7 Renumbering Snapshots

As snapshots can be inserted at any point in the list you may find that you wish to renumber part or all of the list.

Press the **Renumber** button at the bottom of the snapshots panel and a new panel will open. Enter the range that you wish to renumber using the touch turn control or by touching the entry and typing and then enter the steps to renumber to (1.00 is the default value). Then press the **OK** button and the list will be adjusted accordingly.

#### 2.4.8 Deleting a Snapshot

To delete snapshots, touch the **Delete** button and then **Select Range** or **Select All**. If you have pressed **Select Range**, touch the Snapshots in the list that you wish to delete and then press **Confirm**. If you have pressed **Select All**, the complete list of Snapshots will be highlighted and pressing **Confirm** will delete all Snapshots.

*Note: To cancel a Delete operation before it has been confirmed, press the Delete button again.*

#### 2.4.9 Snapshot Undo

When a snapshot is fired, a separate hidden snapshot of the complete console is stored before the fired snapshot has its effect. If the Undo button is pressed, the hidden snapshot is fired using the same scope as the previously fired snapshot to undo its effect.

### 2.4.10 Snapshot Groups

A standard Snapshot (black entry in the list) is an independent snapshot of the current state of all the console controls. A Snapshot can also be a member of a Group (red or blue entry in the list). Making Snapshots members of a Group allows all members of that Group to be updated together according to the Group Update mode that is selected. To make a Snapshot a member of a group, first select the **groups** button on the left of the snapshots panel. Create a group by pushing the new group button and then select the **change members** button. While the **change members** button is toggled, snapshots can be added or removed from the group by selecting them from the main snapshots panel. Once of the desired snapshots have been added or removed from the group, untoggle the change members button.

If a Snapshot is a member of a Group, the colour of its entry in the list is determined by the current setting of the **Relative Groups** button in the bottom right of the Snapshots panel. This determines how the Group of Snapshots will be updated when **Update Group** is pressed.

Red entry in the list = Relative Update mode selected

Blue entry in the list = Non-Relative Update mode selected.

#### Relative Group Update Mode (Red entries in the list)

If **Update Group** is pressed when the **relative groups** button is **active**, all dB controls such as faders and aux sends will be updated relatively. This means that if a fader is moved by +10dB in one snapshot, the same fader will be moved by +10dB in all Snapshots that are members of the same group, irrespective of the original level of that fader. So +10dB will be applied to the stored level of that fader in all of the Snapshots in the group.

Non dB controls such as Dynamics times, EQ Frequency & Q and Pans will only be changed in members of the group that had the same value for that control before it was moved. So, if one channel pan is in the same position in all the members of a group of Snapshots and you change one of them and press Update Group in Relative mode then the same channel pan will change in the same way in all the other snapshots that are members of that group. If, however, any one of the Snapshots in the group has that channel pan in a different position to the current Snapshot then this one will not be changed when you press Update Group.

#### Non Relative Group Update Mode (Blue entries in the list)

If **Update Group** is pressed when the **relative groups** button is **not active**, then all controls behave in exactly the same way. Changes are only applied to the other Snapshots in the group if the controls that are being changed had the same value as the current Snapshot before the change was made. This is exactly the same behaviour as non-dB controllers in Relative mode but in this case all controls are included.

Group & Auto Update Scope

The behaviour of the Group Update function explained above is also dependent on the **Global Auto Scope** and the **Group and Auto Update Scope** settings that can be set per Snapshot for different types of controls.

Pressing the **Global Scope** button at the top left of the **Snapshot** panel opens the following display:

Global Snapshot Scope

CLOSE

channel types	input/trim		delay		filters		eq		dynamics		inserts		sends		fader		mute		panner		to groups		outputs		external	
	recall	update	recall	update	recall	update	recall	update	recall	update	recall	update	recall	update	recall	update	recall	update	recall	update	recall	update	recall	update	recall	update
Input devices	✗	✗																								
Input Channels	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
Aux Outputs	✓	✓	✓	✓			✓	✓	✓	✓	✓	✓			✓	✓	✓	✓					✓	✓		
Group Outputs	✓	✓	✓	✓			✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓			✓	✓	✓	✓		
Control Groups															✓	✓	✓	✓								
FX	✓	✓																								
Matrix Inputs	✓	✓											✓	✓												
Matrix Outputs	✓	✓	✓	✓			✓	✓	✓	✓	✓	✓			✓	✓	✓	✓					✓	✓		
Graphic EQ							✓	✓																		
Video Link	✗	✗																								
Output devices																							✓	✓		

snapshot recalls  
TOTAL gain

✗

midi

☺

✓

gpo relays

☹

✓

Horizontal rows show the different sections of the console and the vertical rows show the Recall and Auto Update status for each of the different types of control. A red X indicates not included and a green tick indicates included. These settings can be changed individually by touching the X or tick symbols or by touching the name of a row or column to change all of its contents.

Recall Scope is dealt with in the next section but the **Auto scope** columns determine which controls will be included in the automatic group update. Any elements that have a red X will not be updated in any snapshots when **Update Group** is pressed.

In the picture above the Input Devices (rack and local input sockets) are not included in the Auto scope so none of their gains or phantom power can be updated using the **Update Group** function. All other elements are ticked and therefore can be included in the **Update Group** function.

*Note: If elements are included in the Global Auto Scope they can still be prevented from Group Updating by the individual Snapshot's Group and Auto Update Scope.*

Selecting a Snapshot in the list and pressing the **Group & Auto Update Scope** button opens the following panel:

Group & Auto-Update Scope: Snapshot 3.00 three															CLOSE	
	channel name	input/trim	delay	filters	eq	dynamics	inserts	sends	fader	mute	panner	to groups	outputs	external		
▼	Local I/O	✗														
▼	Rack 1	✗														
▼	Rack 3	✗														
▼	Input Channels	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓		
▼	Aux Outputs	✓	✓		✓	✓	✓		✓	✓			✓			
▼	Group Outputs	✓	✓		✓	✓	✓	✓	✓	✓		✓	✓			
▼	Control Groups								✓	✓						
▲	FX	✓✗														
FX1	Simple delay	✓														
FX2	Warm hall	✓														
FX3	Audio Enhancer	✗														
FX4	Percussion chorus	✓														
FX5	Vocal Unison	✓														
▼	Matrix Inputs	✓						✓								
▼	Matrix Outputs	✓	✓		✓	✓	✓		✓	✓			✓			
▼	Graphic EQ				✓											
▼	Video Link	✗														
▼	Local I/O												✓			

Press channel names to change whole row, column headings to change whole columns

control group members ☒ gangs ☒ ☒

copy update scope from...

The **Global & auto update scope** is similar to the **Global Scope** panel but represents the Group and Auto Update Scope for one individual snapshot which is indicated by its name and number at the top of the panel.

The down arrows on the left of the panel can be clicked to expand the list to show and edit the status of individual sockets and channels for each Snapshot.

Changes in Control Group membership and ganging can also be included or excluded using the tick boxes at the base of the panel.

In the picture above the Audio Enhancer input trim has been excluded from the Group Update in this particular Snapshot.

*Note: When using Snapshot Groups, it is advisable to set the Global Auto Update scope before attempting to change the update settings for each individual Snapshot. Use of the Global Scope alone probably offers quite sufficient control for most common applications.*

### 2.4.11 Global Recall Scope

When a snapshot is stored all the console settings are saved but when the snapshot is recalled its effect can be limited to certain channels and controllers.

*Note: All elements of console channels and several other features such as Graphic EQ and Effects have their own SAFE settings. If any of these SAFE settings are active, then the relevant controls cannot be affected by any Snapshots. This is in addition to the Global Scope settings described here.*

Pressing the **Global Scope** button expands the panel to display and edit the scope for all snapshots.

Global Snapshot Scope

CLOSE

channel types	input/trim		delay		filters		eq		dynamics		inserts		sends		fader		mute		panner		to groups		outputs		external	
	recall	update	recall	update	recall	update	recall	update	recall	update	recall	update	recall	update	recall	update	recall	update	recall	update	recall	update	recall	update	recall	update
Input devices	✗	✗																								
Input Channels	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
Aux Outputs	✓	✓	✓	✓			✓	✓	✓	✓	✓	✓			✓	✓	✓	✓					✓	✓		
Group Outputs	✓	✓	✓	✓			✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓			✓	✓	✓	✓		
Control Groups															✓	✓	✓	✓								
FX	✓	✓																								
Matrix Inputs	✓	✓											✓	✓												
Matrix Outputs	✓	✓	✓	✓			✓	✓	✓	✓	✓	✓			✓	✓	✓	✓					✓	✓		
Graphic EQ							✓	✓																		
Video Link	✗	✗																								
Output devices																							✓	✓		

snapshot recalls

TOTAL gain

✓

midi

☺

✓

gpo relays

✗

✓

Horizontal rows show the different sections of the console and the vertical rows show the Recall and Auto Update status for each of the different types of control. A red X indicates not included and a green tick indicates included. These settings can be changed individually by touching the X or tick symbols or by touching the name of a row or column to change all of its contents.

The **Recall scope** columns determine which controls will be included in the Snapshot recall. Any elements that have a red X will not be recalled in any snapshots.

In the picture above the Input Devices (rack and local input sockets) are not included in the Recall scope so none of their gains or phantom power can be changed by firing Snapshots. All other elements are ticked and therefore can potentially be changed when a Snapshot is fired.

*Note: If elements are included in the Global Recall Scope, they can still be prevented from recall by the individual Snapshot's Recall Scope.*

### 2.4.12 Individual Snapshot Recall Scope

Selecting a Snapshot in the list and pressing the **Recall Scope** button opens the following panel:

Recall Scope: Snapshot 4.00 Four															CLOSE	
	channel name	input/trim	delay	filters	eq	dynamics	inserts	sends	fader	mute	panner	to groups	outputs	external		
▼	Local I/O	✗														
▼	Rack 1	✗														
▼	Rack 2	✗														
▼	Rack 3	✗														
▼	Input Channels	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓		
▼	Aux Outputs	✓	✓		✓	✓	✓		✓	✓			✓			
▼	Group Outputs	✓	✓		✓	✓	✓	✓	✓	✓		✓	✓			
▼	Control Groups								✓	✓						
▼	FX	✓														
▼	Matrix Inputs	✓						✓								
▼	Matrix Outputs	✓	✓		✓	✓	✓		✓	✓			✓			
▼	Graphic EQ				✓											
▼	Video Link	✗														
▼	Local I/O													✓		
▼	Rack 1													✓		
▼	Rack 2													✓		
▼	Rack 3													✓		

Press channel names to change whole row, column headings to change whole columns

control group members gangs banks

copy recall scope from...

The controls that are included in each of the Recall Scope columns can be seen at the bottom of the panel when any of the entries are changed and are as follows: **Controllers**

**Input/Trim (Local I/O and Racks)** - analogue gains, switches and phantom power

**Input/Trim (Input Channels)** - input routes, digital trim, phase, channel name, Mustard input position

**Input/Trim (Aux Outputs/Group Outputs/Matrix Outputs)** - digital trim, phase, delays, buss name and tubes

**Input/Trim (Matrix Inputs)** - input routes, matrix input name and tubes.

**Delay (All channel types)** - Channel delay

**Filters (All channel types)** - HPF and LPF

**EQ (All channel types)** - all controllers except channel HPF and LPF.

**Dynamics (All channel types)** - all controllers except stereo link.

**Inserts (All channel types)** - Insert Send & Return routes and ON/OFF switch

**Sends (Input Channels)** - Aux send levels, ON/OFF & PRE/POST switches and Aux pans

**Sends (Matrix Inputs)** - Matrix send levels and switches **Fader (All channel types)** - channel fader. **Mute (All channel types)** - channel mute

**Panner (Input Channels)** - channel pan

**To Groups (Input Channels)** - Input Channel to Buss routing switches






The first snapshot can be fired manually in the main **Snapshot** window, if no specific **recall at** time is set. When this snapshot is fired, the next snapshot in the list will automatically be fired after the set time has elapsed and a progress bar in the snapshot's entry in the **Snapshots** panel will show the time remaining until the snapshot is fired. Pressing the **duration active** button while the progress bar is moving will halt the process. The **recall at** time overrides any active **duration** time.

Cancelling Crossfades

Once a snapshot containing a crossfade has be fired, a cancel crossfade button will appear on the snapshots panel. Pressing the cancel crossfade button will skip the crossfade and the snapshot will be recalled instantly.



2.4.14 Snapshot Crossfades

A crossfade time which is measured in seconds and frames can be applied to different controls in a Snapshot by adjusting the Crossfade Time in the Cross Fades panel. This crossfade occurs as you go into the Snapshot.


Select an individual time by touching it or select a column or row by touching its heading. Then enter a time in the Secs/Frames boxes at the bottom of the panel. Either touch and type or use the Touch Turn rotary to enter a figure.

Different Crossfade times can be applied to input trims, filters, EQs, dynamics, sends, faders and pans.

The down arrows on the left of the panel can be clicked to expand the list to show and edit the status of individual channels for each Snapshot so different Crossfade times can be applied to different channels as well.

A value of zero switches it off.

The faders & panners wait time field located in the crossfades times panel is used to insert a wait time before the crossfade begins.



### 2.4.15 Snapshots and MIDI

There are two separate areas of MIDI control:

1. A snapshot can have a MIDI Message attached to it and will output that MIDI when fired. The MIDI message must be created in either the **Scope>MIDI Program** panel or the **Scope>MIDI List** panel.
2. The firing of snapshots can be controlled by incoming MIDI messages on channel 16 and can cause these same messages to be output in addition to any MIDI List data contained in the snapshot.

The specific MIDI messages that are being responded to can be edited in the **Snapshot Control By MIDI** panel, accessed via the **Control By MIDI** button.

To change the default message for any particular snapshot, select the snapshot and press the **Change** button to select a specific available controller number. The **Clear** button will remove the existing message completely.

The **MIDI Received Fires Snapshots** button allows the Snapshot system to respond by default to the following incoming MIDI messages:

General Purpose Controller 16; Values 1 to 127 will fire snapshots 1 to 127 General Purpose Controller 17; Values 0 to 127 will fire snapshots 128 to 255

General Purpose Controller 18; Values 0 to 127 will fire snapshots 256 to 383.

General Purpose Controller 19; Values 0 to 125 will fire snapshots 384 to 509.

General Purpose Controller 19; Value 126 will fire the previous snapshot in list.

General Purpose Controller 19; Value 127 will fire the next snapshot in list.

When active, the **Fire Snapshot Sends MIDI** button causes the above messages 1 to 509 (or customised versions - see below) to be sent whenever a snapshot button is pressed. **Previous** and **Next** buttons do not output MIDI messages of their own.



### 2.4.16 MIDI Devices

If you intend to send MIDI to external devices, it is advisable to first define your receiving devices - this will make the programming of MIDI messages in Snapshots easier to achieve.

Press either the **Scope>MIDI Program** or the **Scope>MIDI List** button and then press the **Devices** button - the following panel will open:

port	chan	name	pc	chn
A	1	A1	1	
A	2	A2	1	
A	3	A3	1	
A	4	A4	1	
A	5	A5	1	
A	6	A6	1	
A	7	A7	1	
A	8	A8	1	
A	9	A9	1	
A	10	A10	1	
A	11	A11	1	
A	12	A12	1	

If chng = Y, Program Changes are only sent when they differ. Press this to ensure the next PC will be sent

clear PC

The SD and Quantum Console's built in MIDI port is referred to as Port A in the **Port** column. Set the receiving MIDI **channel** and **name** for each of your receiving devices and set 1 or 0 in the **PC** column according to whether the device uses 0-127 (0) or 1-128 (1) for its data values. If you don't know this piece of information, then leave the setting as 1.

The column marked **Chng** determines whether Program Changes are only sent when they are different to the last sent message (Y) or whether they are always sent irrespective of the last message sent. This would be useful if there was no need to change the program on the receiving device and if you did this it might interrupt the signal passing through the receiving device as its program changes.

The **Clear PC** button at the bottom of the panel ensures that the next message will be sent.

This has defined your devices for later use and the panel can now be closed.



#### 2.4.18 Snapshot GPO Relays

The Global Recall scope for each GPO can be set by touching the appropriate box at the top of the column.

#### 2.4.19 Surface Offline & Snapshot Editing (Not SD11)

Pressing the **RTN To Audio** button will reconnect the surface controls to the audio engine ignoring any worksurface changes that have been made since the surface was put Offline and returning the console to its state before the Surface was put Offline.

The main purpose of the **Surface Offline** and **RTN To Audio** buttons is to enable Snapshots to be edited with the worksurface offline so that any Snapshot can be previewed, adjusted and updated without affecting the current audio.

While **Surface Offline** is active, any of the Snapshot functions already described can be used.

For example, if you are currently in Snapshot number one and wish to check or edit Snapshot number two you should:

Press and hold the **Surface Offline** button and the audio will continue normally.

Scroll down and fire Snapshot two to see its settings on the worksurface.

Edit the settings for Snapshot two and Update either Current or Selected according to requirements.

Press the **RTN to Audio** button to automatically put the surface back online and back in Snapshot one.

Alternatively, pressing the **Surface Offline** button again applies the current state of the console *to the audio*, causing any changes made with the surface offline to be applied to the audio.

#### 2.4.20 Auto Update

The Auto Update button in the Snapshots panel activates automatic updating of the current Snapshot whenever a control is adjusted. The current Snapshot will be updated without using the Update Current, Selected or Group functions. While auto update is enabled, the background of the snapshots panel will be highlighted. The elements of the Snapshot that are automatically updated is dictated by the Group and Auto Update Scope settings that are described in the Group Snapshots section of this chapter.

*Note: In view of the potential for changing Snapshots without active manual intervention, it is probably advisable to leave this function OFF unless you are absolutely certain that you require it.*

#### 2.4.21 Snapshots & MTC .....

Snapshots can also be programmed to send MMC messages, allowing control of external playback devices. Within the snapshot **scope** section, press the **transport control** button. This opens the **Snapshot Transport Control** panel. The panel lists all current session snapshots and allows entry, per snapshot, of the following MMC commands.

**PLAY:** Basic Play command. External device will play from current location

**play from:** External device will play from specified time value

**play to:** External device will stop when the specified time is reached.

**locate to:** External device will Locate to specified time.

**STOP:** Basic Stop command. External device will stop.

Commands can be sent via MIDI, selected at the bottom of this panel.

*Note: Correct MMC operation relies on a correctly configured MIDI system, with MTC from the external device connected to the console MIDI Input. If this MTC connection is not present, the MMC snapshot system will not work.*


A Transport Control panel is also provided in the Layout Menu. This provides a MTC readout of incoming MTC and allows direct control of the external device.

[illegible]




### 2.4.21 Snapshot Notes

Pressing the notes button (towards the top left-hand corner of the main Snapshots panel) opens a notes panel, displaying any notes associated with the current Snapshot. This panel stays open whenever the notes button is active, switching to the next Snapshot when it is fired. The **selected** and **next** snapshots are shown below the text box.



To add notes, simply touch inside the notes space in the centre of the window and type your notes. To clear the text, touch the **clear** button in the top left-hand corner of the panel.

To format the text or background, touch the **style** button (next to the **clear** button) to open the **Notes Style** panel:



The text can be formatted using the **text size** controller and **bold**, **italic** and **underline** buttons in the left side of the panel. To change the colour of the text or background, select either the **text colour** or **background** button in the left side of the panel, touch inside the colour palette in the centre of the panel, and adjust the brightness using the **brightness** controller. The selected colour is displayed above the **brightness** controller.

*Note: that text defaults to minimum brightness (black), and the background to maximum (white). You may need to move the brightness controller towards the middle to see the colour content.*

You can save your selected colour as one of the twelve **custom colours** in the right of the panel. To do this, simply select the **add colour** button and touch inside the desired custom colour box.

You can also copy styles from other snapshots using the **copy from snapshot** controls beneath the main colour palette. Use the up and down arrows to move through the snapshot list – the snapshot whose style is currently displayed is shown in the **copy from snapshot** text box.

*Note: that copying a style from another snapshot will overwrite the current style.*

#### 2.4.22 Snapshot Locked

*Note: Only available on non-Theatre software versions*

To lock a Snapshot and prevent it from being updated, select the Snapshot and then press the **Locked** button on the right of the panel. It can be unlocked in a similar way.


When a Snapshot is Locked, it cannot be updated using update selected/current or deleted.

## 2.5 Options

The **Options** menu includes a variety of SD and Quantum system preferences, grouped into ten tabs. Most functions are described fully within the display. Each function's button displays purple to indicate that it is active or grey to indicate that it is inactive.

### 2.5.1 Surface

The **Surface** tab includes settings related to the console screen, buttons and encoders:



#### Touch Keyboard

This option defines whether or not the on-screen keyboard appears when a name box is touched. It is active by default.

#### Large LCD Names

This option allows the names in the LCD displays to be displayed in a larger font, either with the gain value and solo buss (with dBs) or as the channel only (name only). It is inactive by default.

#### Round to whole dBs

Fractional dB values are rounded to the nearest integer value.

#### Auto Expand EQ

This option defines if the EQ display opens when an EQ is adjusted. It is active by default.

#### Auto Expand Dynamics

This option defines if the dynamics display opens when dynamics is adjusted. It is active by default.

#### Auto Expand Time

This control, located to the right of the **Auto Expand EQ** and **Dynamics** options, defines how long the EQ and dynamics displays remain open after the parameters within them are adjusted. The current setting is displayed in seconds, below the control. Touching the control assigns it to the Touch-Turn encoder.

The Auto-Expand **Exclude Off** option prevents dynamics and EQ from auto-expanding when being turned off.

### Panner Type

Type 1 is the original SD console implementation. The new Type 2 panning applies a new interpretation of the Sine/Cosine Panning rules - Improved spatial positioning of channels within the stereo image.

*Note: This setting is global for all channels on the console.*

### Aux to Masters (SD7/Q7 Only)

This option allows all of the aux send levels for one channel to be assigned to the Lower Master faders by pressing that channel's lower aux button (the button in the third row of aux encoders below the Channel strip panel). This is useful if, for example, all of the fold-back sends from one channel need to be adjusted. The function is inactive by default. If there are more than twelve auxes in the session, the Lower **master bank** buttons are used to move between banks of twelve auxes.

*Note: If the number of auxes is not divisible by twelve, some faders within the last bank half banks will retain their original function, as indicated by their LCD buttons.*

### Selected 4 Aux Rotary Assignment (SD7/Q7 only)

This option defines whether the vertical four aux rotary controls stay assigned to the current four auxes within a gang/bank/layer/surface/all.

### EX-007 Touch Turn (EX-007 only)

This option allows the first of the four rotary controls to act as the Touch/Turn control when the Master Screen is visible.

### Display Snapshots Overview

This option allows a floating copy of the Snapshots list to be displayed in the overview screen, for the viewing or triggering of Snapshots.

### Global Quick Select (SD5, SD9, SD11, SD12, Q3, Q5)

This option defines whether the Quick Select selection will be the same for every bank on a Surface.

*Note: On the SD5/Q5, the selection will be different between the left and right surface.*

### Global 2nd Function

This option defines whether the 2nd function button affects just the current surface (**no**) or all surfaces on the console (**yes**).

### Auto-cancel 2nd Function

This option defines whether or not active **2nd Function** buttons are cancelled after the time defined in the **auto-cancel time** pot to its right. It is inactive by default. Touching the pot assigns it to the Touch-Turn encoder.


*Note: Both the auto-expand time and auto-cancel time values are set on the console and are not saved as part of the session file.*

**(1272+) Auto-revert LCD Menu to Solo**

When this option is turned on, after the set amount of time the LCD function menu will be cancelled and the LCDs will revert to Solo function. The number of seconds for the LCD function menu to display is set using the **auto-revert time** rotary.

**Engine A/B Switches Audio (SD7/Q7/Q8 Only)**

This option concerns the **Engine** button in the top left-hand corner of the SD7's master section, shown below, which is used for switching the SD7 to the redundant engine. When this function is inactive, the **Engine** button switches just the console controls; when this function is active, the **Engine** button also switches the audio processing. This function is inactive by default.

**2.5.2 Faders**

Note: Function replaced in v1445+ - see below

**Fader Assigns Channel**

This option allows a channel to be assigned to the worksurface channel controls whenever its fader is touched. It is inactive by default.

*Note: When this option is active, accidentally touching a fader will assign it to the worksurface controls.*

**Fader 0dB Detent**

This option defines which controls have a detent at 0dB. Options are Inputs, Outputs, Graphic EQ (default) and CGs.

### Fader Touch Control

This option defines whether or not a fader moves when it doesn't detect a touch. Options are Free (fader moves freely) and Protected (fader is protected from moving without touch).

*Note: This setting is set on the console and is not saved as part of the session file.*

### CG Faders Control Aux Sends

*Note: This function has been removed in V1445+ in favour of selectable control on each CG – see CG Aux Send Enable in CG section of the manual.*

If this option is set to Yes, whenever 'Aux to Faders' is activated (by any means), the Control Group faders jump to the middle and become +/-18dB trims for the selected aux send, on all channels which are members of the Group. The fader for Control Groups which have no members will simply close and do nothing. CG Mutes and Solos continue to operate as normal.

### (V1455+) Fader Response During Snapshot Recall option

A new option has been added in **Options>Fader** tab called **Fader Response During Snapshot Recall**. The option has a **Standard** and a **Fast** setting. When set to **Fast** the console avoids delaying the fader input when recalling snapshots/cues.



To avoid delaying fader input when recalling Snapshots/Cues select Fast option.

### Set Spill Direction (on relevant consoles)

This option defines the way in which Sets are spilled onto the worksurface: L Vert places them on the left side, creating as many banks as are required to spill all the channels in the Set; R Vert does the same on the right side; Horiz places the first 24 channels across both sides of the console before creating as many banks across both sides as are required to spill all the channels.

### 2.5.3 Solo

The **Solo** tab includes settings related to the console's solo functions:

Options

Surface Faders **Solo** Gangs Delays Disable Brightness Meters Console Status

**Solo Displays Insert and Output**  
When solo button pressed, display internal processing or plugin integration

**Solo Displays All Aux Sends**  
When solo button pressed, displays Aux Send Nodes on master screen

**Solo Assigns Aux to Faders**  
When Aux Master solo pressed, assign Aux Sends to channel faders

**Solo Assigns Aux to Rotaries**  
When Aux Master solo pressed, assign Aux Sends to channel rotaries

**Aux to Faders includes Pans**  
If stereo Aux Send is assigned to fader, any pan rotary is assigned to aux pan

**Solo Assigns Channel**  
When solo button pressed, channel is assigned to control strip

**Solo Assigns Channel also Assigns Screen**  
When solo button assigns channel, assign bank to screen

**Solo Displays Aux Nodal Processing / KLANG**  
Aux Master solo displays processing for currently selected channels

**Solo Reverts to Output**  
Revert to last soloed output when input solo cancelled (single only)

**Line Check Listen**  
Choose which Solo output to use for listening to input sockets

**Outputs AFL Only**  
PFL/AFL choice applies only to input channels

Options marked \* are not saved in session files, but remain set on the console

#### Solo Displays Inserts and Outputs

This option defines whether or not to display any internal FX or Graphic EQ on the inserts of direct outs of a channel when that channel's solo button is pressed. The Graphic EQ panel can only be displayed on the Master screen. It is active by default.

#### Solo Assigns Aux to Faders

This option defines whether or not the send levels to an aux channel are assigned to the channel faders when that aux channel's solo button is pressed. It is active by default.

#### Solo Assigns Aux to Rotaries

This option defines whether or not the send levels to an aux channel are assigned to the top row of aux encoders when that aux channel's solo button is pressed. It is active by default.

#### Aux to Faders includes Pans

This Option defines whether or not the pan assignment for the under-screen rotaries will become the stereo aux pan when a stereo aux is soloed if Solo Assigns Aux to Faders is active.

#### Solo Assigns Channel

This option defines whether or not a channel is automatically assigned to the channel worksurface controls when that channel's solo button is pressed. It is active by default.

#### Solo Assigns Channel also Assigns Screen (consoles with master screen button)

When a channel is selected using its solo button, the bank it's on is assigned to the screen.

### Solo Reverts to Output

This option defines what happens if an output channel solo is active when an input channel solo is then activated and deactivated. When this option is active, deactivating the input channel solo will return the solo buss to the output previously in solo mode. When this function is inactive, deactivating the input channel solo will leave all solos inactive.

The option is only available if the solo buss is in single mode. The option is inactive by default.

### Solo Displays Aux Nodal Processing (Quantum Only) / KLANG

If a channel is selected and an Aux Master that has a corresponding Klang or Nodal Processing (Quantum only) node is soloed, the expanded view of that node is displayed.

### Line Check Listen


This option changes which solo bus line check is routed to when listening to input sockets in the Audio I/O page.

### Outputs AFL Only

This option restricts the Solo PFL/AFL choice to input channels only, all outputs being fixed on AFL.

## 2.5.4 Gangs


The **Gangs** tab allows gang scopes to be specified for each channel type. Selecting/deselecting the controls under each of the channel types will dictate whether those controls will be altered by a gang.



## 2.5.5 Delays

This tab is used for defining the delay units used in the Setup panel of **Input channels**, **Output channels** and **fx channels** (fx units). The options are **seconds** (default), **feet**, **metres**, **bpm** and **frames**.


*Note that these options are also displayed to the right of the numeric keypad opened by pressing the delay's keypad symbol.*






### 2.5.6 Disable

This tab is used for disabling worksurface buttons, to prevent accidental changes if they are not being used. This function does not affect on-screen operation of the functions: If the Panel will show the options relevant to your console.



### 2.5.7 Brightness

The **Brightness** tab is used for adjusting the brightness of the console's **bridge, led lights, screens** and **surface LEDs**. Touching each pot assigns it to the Touch-Turn encoder.




The SD5 and SD7 console's LCD buttons are not controlled by the **surface LEDs** pot but by the **Dim LCD buttons** and **Invert LCD Image** options towards the bottom of the screen.

*Note: The dimming option only dims the brighter LCD colours.*

### 2.5.8 Meters

The **Meters** tab includes settings related to the console meters:



The four pots across the middle of the panel affect the attack and release reaction time (**attack rate** and **release rate**), the **peak hold time** and the **overs hold time**. The current setting for each is displayed in either milliseconds or seconds, below each pot. Touching each pot assigns it to the Touch-Turn encoder. The row of

buttons above the pots provide access to preset meter configurations, including the **SD default** and a number of PPM formats. The second row of buttons allows the system to compensate for changes in operating levels when viewing PPM meters so that all PPM meters are referenced to 0dBu. The default operating level for SD Series consoles and racks is set to +22dBu.

*Note: When the overs hold time is set to 0, the hold time is set to infinite, not 0. The overs lights will therefore remain lit until they are manually cleared.*

*Note: If you activate a metering preset and then edit it, the button for the preset on which the setting is based will still appear selected.*


The point being metered within the channel is set using the eight buttons in bottom left of the display. The input channel meters are adjusted using the buttons on the left, and the output channels are adjusted on the right. The options for each are **pre-trim**, **post-trim** (pre-processing), **pre-fader** (post-processing) and **post fader**. The default setting is **post-trim** for input channels, and **post-fader** for output channels. The currently selected button is displayed in purple.

The **Overview** area in the bottom right of the display allows the size of Input and Output Meters to be set: **small** or **large**.

*Note: The settings in the bottom half of the display affect the meters on the worksurface, not the onscreen meters.*

## 2.5.9 Console

The **Console** tab includes settings related to the console's start up procedure:



### Load Startup Session

This option allows the startup session to be automatically loaded on system start up. When not selected, the desk will always start up in the default state.

### Save Startup Session

This option allows the startup session to be automatically saved when quitting. When not selected, the desk will always start up in the same state.

### Auto-Save Recovery Session

This option enables an auto-save function, which saves the active .ses file regularly, in case it needs to be recovered. The time between auto-saves is defined using the **save every** pot to the right of the option's button.

### Default Positions

This option allows all windows to be set to their default positions on next launch.

### Enable External Waves

This option enables Waves features. Waves is an optional extra which provides a set of Waves plug-ins in addition to the console's own fx units.

For SuperRack SoundGrid V14.30+ (Legacy & ProLink)

DiGiCo console software V1742 for SD and Quantum series consoles will support both Legacy & ProLink modes


After applying the DiGiCo software update, the console will launch with Legacy console remote mode selected.

### How to set up ProLink:

1. On the console, go to Master screen > Options > Console.
2. Make sure Enable External Waves is set to Yes and that the console network port is selected.
3. The default selected mode is Legacy. Click on ProLink and power cycle the console.



4. Launch SuperRack SoundGrid.
5. In the Controllers pane, add ProLink Console Remote.



6. If you have previously used the console remote module, you will see **Legacy Console Remote** assigned in the Controllers pane. If that’s the case, you will first need to remove it, then assign **ProLink Console Remote**.

The correct network port is selected automatically.



7. Checkmark 'Assign' – status will change to 'Connected'.



A session load command will pass from the console to SuperRack. If there is no matching session in SuperRack’s integrated sessions folder, SuperRack will load an empty session.

SuperRack SoundGrid Integrated session folder location:

**Windows:** C:\Users\Public\Waves Audio\SuperRack SoundGrid\Integrated Sessions

**Mac:** Mac HD > Users > Shared > Waves Audio > SuperRack SoundGrid SoundGrid > Integrated Sessions

**ProLink features:**

- Automated discovery
- Sync to console global tempo
- Console unattended mode sync with SuperRack

To learn more about DiGiCo remote control integration features and console support, please refer to Waves' [DiGiCo Remote Control Integration and Mirroring](#) article.

We strongly advise Waves users to read the MultiRack for DiGiCo SD console user guide.pdf explaining the requirements to use Waves MultiRack/Superrack on an external PC and ensuring that all of the necessary equipment and licences are in place to do this.

Please visit <http://www.waves.com/downloads/digico> for more information  
Need further assistance? [Contact Waves Technical Support](#).

**Enable Fourier Integration**

See Section 2.6

**Enable Fourier Sessions and Snapshot Control**

See Section 2.6

**Enable Optocore**

This option allows Optocore connections to be switched off if not in use. You can have both Optocore loops OFF, or you can enable Loop 1, Loop 2 or Both.

**Enable Console Network**

This option activates networking for remote control PCs and consoles and is explained in the Network and Mirroring section

*Note: Enable External Waves and Enable Console Network both require a restart for changes to take effect.*

**Mirroring Mode**

This option defines the way control is assigned between networked consoles and is explained in the Network and Mirroring section.

**Single Engine Only (SD7 Only)**

When active, this option allows two SD7's with only one engine to be mirrored together.

2.5.10 Status

The **Status** tab defines whether console status notifications are displayed. All functions are active by default.



Display System Status Indicators

This option defines whether or not the Status display is open. This display provides constant monitoring of various elements of the console’s systems. The indication box to the right of each element displays a green OK when that element is running correctly, a red error when that element is malfunctioning, and a blank grey box when that element is not relevant. Touching any indication box will bring up the appropriate Diagnostics page, if there is one.

SD7 Dual engines

The status display on an SD7 will have two columns listing the same elements. Each column represents one of the SD7s engines, local being the currently viewed engine and the other being the other engine.

STATUS	local	SD7re
power supplies		
computer	OK	OK
audio engine		
local i/o		
madi devices		
opto devices		
opto loop 1		
opto loop 2		
surfaces		
timecode		
ethernet	OK	OK

**Display System Alerts**

This option defines whether or not system warnings are displayed. The time for which alerts are displayed is adjusted via the message display time pot, located towards the bottom of the window. The current setting is displayed in seconds, below the pot. Touching the pot assigns it to the Touch-Turn encoder.

**Display Overs Alerts**

With this option active, whenever an input or output over-indicator comes on, the Signal Overs panel is displayed showing details of the signals involved and their channels. Touching an entry in the Signal Overs list brings the channel to the surface to be adjusted. The Signal Overs panel also duplicates the Clear Over Indicators button.

*Note: The Signal Overs panel can also be opened using the Signal Over Indicators option in the System menu.*


**Display Messages until acknowledged**

With this option active, any system alert will remain on the screen until cancelled by the user.

## 2.6 FX & Processors

### 2.6.1 The Master FX Display

Selecting the **fx** menu button in the master screen opens the master **fx** display, which displays all of the currently assigned fx units in a single rack. Touching any control in this display allows adjustments to be made using the worksurface **Touch Turn** controls.



It is also possible to create and delete modules from this display:

To create a new module, click on the **New** button in the top left-hand corner of the fx window to bring up the **fx Presets** display, then select the appropriate preset in the usual way. Routing to fx modules is then performed in the channel **Outputs** display. To delete a module, click on the **fx presets** button on the module, and deselect the preset in the **fx Presets** display which appears.

Factory presets are provided, and these provide the basis for any user-adjusted presets. Factory presets are indicated by the presence of a red padlock in the **lock** column on the right and are described below. These include stereo FPGA reverbs and other effects such as delays, choruses, pitch shifters and audio enhancers. Once an effects preset has been adjusted, it can be saved, either as a new preset or as an updated version of the preset that has already been created.

To lock a preset, activate the **edit name** button and touch the preset's **lock** column. A grey padlock appears, indicating that the preset is now locked. Touching the lock again with **edit name** active unlocks the preset. All master presets are locked and cannot be unlocked. Master presets can be distinguished from user presets by the red colour of their padlocks.

*Note: Factory preset group names can be edited, even though the presets themselves cannot.*



Once an effects preset has been assigned, the **fx output** button in the channel strip recalls the preset's controller display. In the case of Input channels, once an effects preset has been assigned, the preset's display can be recalled by touching the pan area of the channel strip. The **fx Presets** display can then be recalled by pressing the **fx presets** button within the controller display.

Each fx unit can be safed by pressing the **safe** button at the top of its display. The channel's name and output are also shown at the top of the display, and each effect displays its input and output levels in meters in the left-hand side of the controller.

### (1272+) Global Tap Tempo

Delay effects can now join a global tap tempo so that a single controller can change the delay amount on all delays in the group. Delays can be set to different scalars. For example, if a delay unit was set to 'delay x 2', the delay amount would be set to double the current global tap amount. The options are: off (default, not part of the global tap), x 0.25, x 0.5, x 1, x 2, x 3, x 4.

The global tap can be set using the new macro command type 'Global Tap Tempo'.




Press to cycle through the options for global tap at various scalars.

The Global Tap value can be entered manually by touching the **keypad icon** in the Delay FX panel and typing a number.

### FX Graphs

All reverbs are editable via a graphical display, with each of the coloured adjustable sliders on the graph representing the rotaries on the fx unit below.



### 2.6.2 The Spice Rack (Quantum Engines only)

Spice Rack is the new audio processing rack on Quantum engines. It was released with the Chilli 6 Multiband Compressor and also now includes a 6 band Dynamic EQ called Naga 6.

The Spice Rack can be accessed by touching the Master Screen > **Processors** then **Spice Rack**.


**Soloing** a channel with a Spice Rack processor inserted will bring up the Spice Rack and the relevant slot.

### 2.6.3 Chilli & Naga 6 Overview

The screenshot shows the Spice Rack interface with the following annotations:

- List of current units in the Spice Rack slots. Inserted units display the channel name.** (Points to the left sidebar list)
- The channel and insert where the device is routed** (Points to the top header area)
- Safe the current Spice Rack processor** (Points to the 'safe' button)
- The user interaction type** (Points to the 'touch assigns' button)
- Open the presets window** (Points to the 'presets' button)
- Link two Chilli 6 units together** (Points to the 'mono' and 'stereo' buttons)
- Select the Spice Rack device type** (Points to the 'type' button)
- The current frequency response of the processed signal** (Points to the frequency response graph)
- The dB range that the compressor will act over** (Points to the 'Crossover Low' and 'Crossover Mid' sliders)
- These set the side chain source and type** (Points to the 'Side Chain' section)
- This sets the global Solo Mode.** (Points to the 'Solo 1' button in the bottom left)
- This sets the solo source** (Points to the 'Solo 1' button in the bottom left)


The Naga 6 can be accessed by selecting a Chilli 6 unit and pressing the type button, then choosing Naga 6.



Chilli 6 is a classic multiband compressor with four flat top filter type bands with shared crossover slope and two separate parametric bands. The Naga 6 is a Multiband Dynamic EQ with six parametric bands and no flat top filters. They both allow frequency specific dynamic control with compression or expansion applied to audio above a set threshold. When stereo channels are routed to the Spice Rack, two consecutive slots are automatically set to stereo, therefore ganged together. They can be set back to mono to allow the units to have different parameters. Before units can be stereo linked the pair of units have to be set to the same type, Chilli 6 or Naga 6. Pairs must be neighbouring units such as 1 and 2 ,3 and 4, 5 and 6 etc. Note that 2 and 3, 4 and 5 etc cannot be made into a stereo pair.

The green line represents the frequency response of the processed audio and reflects the compression or expansion applied in real time.

The **Release Shape** is used to alter the release characteristic with curve type exponential (0) through linear (0.5) to inverse exponential (1). Inverse exponential is a new feature which reduces sharp decays between peaks in signal, whilst maintaining the same overall decay time.



**Dynamic Angle** affects how far above the threshold the signal needs to be before the full range of EQ is applied, similar to a ratio with a smooth transition through the threshold. This can be set anywhere between 1 (default) equivalent to a higher ratio and 0, a lower ratio. Also similar to a knee, when the Dynamic Angle is set to a value less than 1, gain reduction will be applied to signal below the threshold however will always maintain a soft curve.

**Parametric (Bell) Filters.** The six bands on the Naga 6 and two of the bands (P1 and P2) on the Chilli 6, are parametric EQ type filters, which have a centre frequency range of 20Hz – 20kHz and Q of 0.35 – 60. When the band is set to “Split” mode, these bands also have their own independent flat top filter bands, which are used only on the side chain dynamic control and as isolating filters when soloing the band. The centre frequency of these bands follow the frequency control of their main parametric filter, and the width adjusts in sympathy with the main “Q” control. Setting the band to “Wide” bypasses the flat top filter in the dynamic side chain control such that the side chain is fed directly from the input signal, although these filters remain active as isolating filter when soloing.

**Flat top filters.** On the Chilli 6 only, bands 1 – 4 have three crossover filters which are used to position the bands over the desired spectrum. A global **Crossover Slope** adjusts the filter slope between second order (0) and true fourth order (1). When a band is set to split mode, the side chain control signal is fed post the filter and will respond only to audio within the band, but when set to “Wide” the side chain is fed directly from the input and will respond to the whole spectrum. Soloed signals will always pass through the filter regardless of the “Split”/“Wide” state.

**Gain** acts as a level adjustment for each band.

**Range** determines the limits of compression or expansion applied to a particular band. When activated, the dynamic range is shown by a blue highlight either above (expansion) or below (compression) the current gain in the graphical display.

**External Side Chain.** Pressing the “Side Chain Source Route” will allow you to select an external source to be used as a side chain. Each band can be set to use this one signal as its side chain source independently by pressing the “Int” / “Ext” buttons. Any band not using Ext reverts to using self (the input signal) as its source. “Ext” cannot be selected if no external route has been set up.

**Soloing Bands.** Only one band can be soloed at a time, by pressing the “listen” button in the band. With listen Source set to “Band” the solo will monitor the input signal passing through the bands filter controlled by the dynamics, and in the case of parametric filter bands, the signal will also be passed through a side chain isolating flat top filter. This is so that when notch filters (Bell cut) are used, the affected audio region will be isolated. When Listen source is set to “S/C Listen” the external S/C signal (if set to external) or the input signal, will be passed through its own flat top side chain filter. This filter will not be controlled by the dynamics as it is monitoring the source that is controlling the dynamics.

**Listen/Solo Destination.** The soloed band can be sent to the “Solo 1” buss, the “Solo2” buss, or both, without altering the normal signal going through the spice rack (non-destructive). Alternatively, Pressing the “Destructive” button will make the soloed band replace the spice racks normal output with the soloed signal. These controls are global to all the units in the spice rack.

**Attack** and **Release** determine the speed at which the compression or expansion acts on the signal.

**Threshold** sets the point where compression or expansion is applied.

There is an overall **Output** fader which can be used to make-up or reduce a post-effect gain difference.

Any of the bands can be set to **Bypass** which sets the gain and range for that band to 0dB, maintaining the overall phase. **Bypass All** applies a blanket bypass across all bands which keeps the state of the individual bypasses.

### 2.6.4 User interaction options

#### 1. Faders

Parameters can be touched on screen to determine which row of controls are assigned to the upper master faders (Q7) or centre section faders (Q3/Q5). Mute buttons act as bypass and solos act as listen in this option.

#### 2. Touch turn

Each parameter can be pressed individually to be controlled by the touch turn rotary. The touch turn button toggles the bypass state when on-screen rotaries for that band are selected and listen state when the on-screen faders are selected.

### 2.6.5 Presets



Presets allow the ability to recall and save parameters for a particular setup of a Spice Rack effect. **New** will create a preset with the current parameters in the effect, this will be stored under a group. **Default** will recall the default settings for the effect in the current slot.

When **edit name** is selected, the group name, preset name and notes can be altered. Factory presets are locked and cannot be altered or deleted.

A variety of factory presets are available as starting points for use on different audio sources.

### 2.6.6 Fourier transform.engine - Control Integration (V20xx)

The Fourier transform.engine can be controlled from Quantum consoles (Q8/Q7/Q5/Q3/Q2).

There are 2 aspects to the control integration.


- Transform Plugin Teleporting and control.
- Transform Session and Snapshot integration.

Teleporting is enabled with the console **Enable Fourier Integration** option and, if this is enabled, the **Enable Sessions and Snapshot Control** option is also displayed as an option.

Note that Fourier and Waves integration cannot both be enabled at the same time.

To enable this integration:

- Connect the console ethernet port to the transform.engine Control port with an ethernet cable.
- In the console **Options > Console** tab, set **Enable Fourier Integration** to **Yes**. Then press the **Settings** button to open the configuration panel.
- Enter the IP address of the Control Port on the transform.engine and specify the **console network adaptor** which is used for the ethernet connection. The console must be power cycled after any change of IP address.  
**Note** that the transform.engine must be in the same subnet as the console.
- Select the Audio IO port which will be used for the **Transform audio interface** which typically will be either a DMI-Dante 64@96 card or an internal Fourier Interface Card. A Fourier Audio logo will appear next to the selected port in the **Audio I/O** panel.



### 2.6.7 Fourier transform.engine - Session and Snapshot integration (V20xx)

Note that on the transform.engine, there will be 2 versions of the showfile related to a particular console session.

One has the suffix `_autosave` and the other does not.

The version of the showfile labelled "*session name*\_autosave" is automatically created on the transform.engine when it performs an autosave and is continuously updated as changes are made.

The version simply labelled "*session name*" is saved whenever the console itself saves a session provided that the console **Option > Console > Enable Fourier Sessions and Snapshot Control** is set to **Yes**

If you wish to save the Transform showfile on a removable USB drive for backup/transfer to another transform.engine, please ensure that you **Export** the version of the showfile without the `_autosave` suffix. This will then be associated with the console session that has the same name.

In the transform.client application running on the standalone computer, navigate to **System**, select a showfile from the list, press **Export Showfile**, select a destination and confirm.

The following situations should be considered:

#### **If you don't have either an existing console session or a Transform showfile**

Assuming that the console has had a Default All Session Restructure, before saving the new console session, the Transform engine will create a blank showfile named "`_default`".

When the session is saved on the console, the Transform engine will also save a file of the same name and make that its current showfile. The displayed showfile name will be "*sessionname*\_autosave".

#### **If you have a console session but no matching Transform showfile**

If a console session is loaded and the transform.engine does not have a showfile with the same name then it will create a default showfile on the transform engine with the same name as the console session, and create a DiGiCo Cuelist. This cuelist will be populated with snapshots to match the snapshots in the console session file.

#### **If you have a console session on the console or removable drive and a matching Transform showfile**

Import the transform showfile onto the transform.engine. Make sure that the showfile name exactly matches the name of the console session file. If it does not, then this must be changed using **Rename Showfile** within the transform.client, not in a standard file browser. Note that if the showfile has previously been used with DiGiCo console integration and gained the "`_autosave`" suffix, this will need to be removed from the showfile name in order to synchronise with the console again. Once it has been imported to the transform.client and the session names have been checked, load the session on the console. When the session is loaded onto the console, it will look for the transform showfile of the same name and load this onto the transform.engine.

Note that for console sessions made with Fourier Integration turned off, if it is subsequently enabled then by default, console individual Snapshot Recall Scope is not active for the Fourier Transform until the user chooses to enable it. This can be quickly enabled for all snapshots by using the Edit Range function in the **Snapshots** panel.

Since it is possible to load different sessions and make changes to the snapshot list on the transform.engine from the transform.client, it is possible to get out of sync between the console and the transform.engine. If the console detects that the transform.engine session and snapshots are no longer in sync with the console, it will pause the session and snapshot integration. When paused, a message will appear at the top of the **Fourier** panel. To resync and resume session and snapshot integration, the console session must be reloaded or the **Re-synchronise Snapshots** button in **Fourier > Settings** must be pressed.

### 2.6.8 Adjusting plugin parameters from the console interface

For plugin teleporting (display and control of the plugin interface on the console), the routed console Transform audio interface socket numbers (typically Dante audio) are associated with the same numbered sockets used with the Transform plugin chain. Note that patching to and from the transform.engine in Dante Controller must be done 1:1.

If, for example, console channel 1 has insert send and return routing assigned to the Transform interface sockets input 1 and output 1, selecting/soloing this channel will display the Transform plugin chain with the same numbered socket routes. By default, this would be plugin chain 1.


Once all routing to and from the transform.engine has been set up, the Fourier panel can be opened in 3 ways.

- Press **Processors > Fourier** to open the Fourier panel.
- Tap the insert routed to the transform engine on the channel strip
- Solo a channel that has an insert or output routed to the transform.engine. Note that this will depend on the **Solo Displays Insert and Output** option found in **Options > Solo**.

Plugin parameters can be controlled by the touchscreen or a mouse connected to the console. For compatible plugins, control can also be achieved by touching a control in the console Fourier plugin interface and using the console worksurface touch turn encoder. If a plugin is not touch turn compatible, this will be indicated at the top of the console plugin list display. In this case, controls should generally still be controllable with on screen touch.

Along the left side of the panel is a list of all of the plugins in the chain. Tap on a plugin to display it. Icons may appear next to plugins in the list to show different states such as bypassed or reloading.

The plugin list on the left can be collapsed and expanded using the Collapse or Expand button at the bottom. This increases the size of the plugin viewer and therefore the size of the plugin.





2.6.9 Sharing a transform.engine between multiple consoles

It is possible for multiple consoles to connect to the same transform.engine. If one transform.engine is being shared by multiple consoles (for example FOH and Monitors each using their own chains) then only one of the consoles should be in charge of sessions and snapshots on the transform.engine. This console should have **Option > Console > Enable Fourier Sessions and Snapshot Control** set to **Yes**. All other consoles should have this option set to **No**.


If a mirrored set of consoles or engines (for example engine A and B in a Quantum7 or Quantum852) are connecting to the same transform.engine, then both consoles or engines can have **Enable Fourier Sessions and Snapshot Control** set to **Yes**. In this setup, the transform.engine will listen to the audio master for session and snapshot commands. If one of these engines can no longer talk to the transform.engine then it will listen to the only console connected, regardless of audio master status.

2.7 Matrix Menu

2.7.1 The Matrix Panel

Touching the **Matrix** menu opens the **Matrix Inputs** panel, which allows matrix inputs to be selected and the level of each input to each output to be set. Each column of the display represents an input to the matrix, and each row represents an output. Each pot within the display trims the signal coming from the input for that column, going to the output for that row.

The SD12, SD/Quantum 5 and SD/Quantum 7 Matrix panel includes buttons on the top left which can be used to set which surface screen the Matrix is viewed on.



The top of each input column displays the input's name, and the label above each trim pot displays the pot's output. Touching any trim pot assigns it to the **Touch-Turn** encoder; pots lighten and are ringed green to indicate that they have been assigned. Multiple pots can be assigned simultaneously, in which case the encoder alters all assigned pots by the same amount, regardless of each pot's position. The value of each pot is displayed in dB to its right. Sends are switched on using the Touch Turn control's button; the display shows **OFF** in grey when it is off, and **ON** in red when switched on. Turning a pot automatically switches it on. There are three **Touch-turn assignment** buttons at the bottom of the display. The **all** button assigns all the trim pots to the **Touch-Turn** encoder; individual pots can then be deselected by touching them. The **clear** button clears all the pots from the **Touch-turn** encoder. Activating the **single** button prevents multiple trim pots from being assigned to the encoder simultaneously.

*Note: The all function can still be triggered when the single function is active.*

The **Enter Gain Value** field allows the gain of single or multiple matrix nodes to be set via the on-screen or physical keyboard.


**[V1455+]** When entering a gain value into the text box at the bottom of the panel, the value now defaults to a negative value. Two new options have also been added to the panel:

**Abs:** enter the numerical value in the box using a keyboard or the on-screen numpad, all selected "knobs" will have their gain set to that value.


**Rel:** the value entered in the text box will increase or decrease the level of all selected "knobs" by the entered amount.

Matrix input signals are selected in the **Setup** display, accessed by touching the text box at the top of each matrix input column. At the top of the **Setup** display, there is a text box which can be used for renaming the matrix input. Below that, there is a matrix input routing button which opens up a routing display. Routing displays are described in the Getting Started Section.

Below the routing button, there is a scrollable list of buttons displaying the names of all the other matrix inputs, under the heading **copy settings from**, used to copy matrix settings between input columns. To copy the level and on/off status of each send from one column to another, simply touch the button for the input column from which you want to copy settings.



The **Matrix Input Presets** panel is opened using the **presets** button located at the bottom of a matrix input **Setup** display and at the bottom of the **Matrix** panel. Preset panels are described in full in the Getting Started section. To include input routes in the preset recall, make sure the **input route** button at the base of the screen is active. To include trim pot levels and on/off buttons, make sure the **sends** button at the base of the screen is active. The **chs** column of the display indicates the number of channels included in the preset, and presets can be named – by default, Presets are named after input signal 1.



The **safe** button at the bottom of the **Matrix** panel protects the matrix settings from being overwritten by a snapshot recall. Similarly, the **safe** button in an individual matrix channel’s setup panel will safe that particular channel.

2.7.2 Matrix Output Copy


There is a **Copy Setting** function in matrix output channels in **Matrix Setup** panel. Pressing **Copy Settings** will display a list of other matrix outputs, selecting one will copy mix settings. Default **0db** and **Off** settings have been included at the beginning of the **Copy Settings** list.



## 2.8 Graphic EQ Panel

The left-hand side of the expanded display includes metering of the EQ's **IN** and **OUT** signals, a  $\pm 12$ dB gain **trim** pot with value indication to its right, and an **on** button which is ringed red to indicate that the EQ is on. Touch the **trim** pot to assign it to the Touch-Turn encoder. To the right of these controls, the 32 EQ band faders are displayed. The label located beneath each fader indicates the frequency of each band in Hertz, and the gain scale associated with each line on the display is indicated to the left of the lowest band. Each band can also be altered within the miniature display (using a mouse).

The display consists of miniature representations of all available graphic EQ's, one of which is also shown expanded in the bottom of the display:



The settings on each graphic EQ are accessed via the expanded display, though some settings can also be adjusted in the miniature display. Touch any of the graphic EQs to assign it to the expanded display. The EQ assigned to the expanded display can also be scrolled using the scroll bar to the right of the expanded display. The EQ currently assigned to the expanded display is indicated in the top left-hand corner of the expanded display, along with indication of the EQ's **source**. The miniature display can be opened and closed by pressing the expand button (a down-arrow when opened, and an up-arrow when closed) to the left of the expanded EQ **close** button.

The left-hand side of the expanded display includes metering of the EQ's **IN** and **OUT** signals, a  $\pm 18$ dB gain **trim** pot with value indication to its right, and an **on** button which is ringed red to indicate that the EQ is on. Touch the **trim** pot to assign it to the Touch-Turn encoder. To the right of these controls, the 32 EQ band faders are displayed. The label located beneath each fader indicates the frequency of each band in Hertz, and the gain scale associated with each line on the display is indicated to the left of the lowest band. Each band can also be altered within the miniature display.

*Note: For Q8 only, there is an additional **Touch to adjust** option available which allows the faders on the expanded display to be adjusted by dragging on screen.*

### 2.8.1 A Ganging Graphic EQs

The grey **GANG** and **build gang** buttons above the band faders are used for ganging together different graphic EQ's. When EQs are ganged, their band faders, **on** buttons and trim pots are locked together.

*Note: Ganging of faders is relative: EQs can have different shapes when they are ganged, and each EQ will move by the same amount when a band is adjusted.*

*Note: If faders are moved within the miniature display, any other EQs ganged to them will also move.*

When a set of Graphic EQs are inserted on a stereo or surround channel, those EQ units are automatically ganged together and are then automatically un-ganged when the insert route is removed.

*Note: It is the Insert Return routing, not the Insert Send routing, which gangs EQ units.*

To start building a gang manually, touch one of the graphic EQs to be included in the gang to assign it to the expanded display, and touch **build gang**. The button turns red to indicate that it is active. The **GANG** button to its left will also become coloured, indicating that it is included in the gang being built. To add further EQs to the gang, touch the relevant small Graphic EQ display on the other Graphic EQs to be included, and they will change colour to match the expanded EQ's **GANG** button. To deselect any EQs from the gang, touch their **GANG** buttons again and they will return to grey. Touch the **build gang** button to complete the ganging process. EQ gang assignments can be adjusted by reselecting the **build gang** button.

*Note: To temporarily isolate a Graphic EQ band from a gang, press and hold the mute button above the band's fader and then make the adjustment to that fader - this move will only be made to that band on the Graphic EQ that you are currently adjusting.*

### 2.8.2 Graphic EQ ALL Button

To adjust all graphic EQs at once, select the **all** button to the right of the **build gang** button. It turns red to indicate that it is active. Adjusting any band in the expanded EQ will cause that band in all EQs to jump to that position

*Note: The all function is absolute: Once a band is altered, any variations on that band between the EQs is eliminated.*

*Note: The all function does not affect the normal operation of faders in the miniature display - they still operate independently.*

To return all 32 bands within one EQ to 0dB, touch the **flat** button to the right of the **all** button, and touch **Yes** in the confirmation pop-up which appears.

*Note: that the flat function affects any EQs which are ganged to the expanded EQ.*

Activating the **safe** button, to the right of the **flat** button, protects the graphic EQ settings from being overwritten by a snapshot recall.

### 2.8.3 Graphic EQ Presets

Touching the **preset** button, to the right of the **safe** button, opens the **Graphic EQ Presets** display in which current settings can be saved and pre-created settings imported. The positions of the **trim** pot, **on** button and all 32 faders are included in an EQ preset. To reset the channel to the default settings, press **default**.

## 2.9 Control Groups

### 2.9.1 The Master Control Groups Display

An overview of all the Control Groups within a session can be access via the **Control Groups** menu button in the master panel.


Control Groups												CLOSE
cg 1 members	cg 2 members	cg 3 members	cg 4 members	cg 5 members	cg 6 members	cg 7 members	cg 8 members	cg 9 members	cg 10 members	cg 11 members	cg 12 members	
spill	spill	spill	spill	spill	spill	spill	spill	spill	spill	spill	spill	
join / leave	join / leave	join / leave	join / leave	join / leave	join / leave	join / leave	join / leave	join / leave	join / leave	join / leave	join / leave	
clear	clear	clear	clear	clear	clear	clear	clear	clear	clear	clear	clear	
CG 1	CG 2	CG 3	CG 4	CG 5	CG 6	CG 7	CG 8	CG 9	CG 10	CG 11	CG 12	
all mute	all mute	all mute	all mute	all mute	all mute	all mute	all mute	all mute	all mute	all mute	all mute	

This display contains basic channel strips for each Control Group. Each channel strip includes a list of channels that are assigned to that control group and few basic controls that can be adjusted from within the control group view, including **spill**, **join/leave**, **clear** and **all mute**. The Control Group naming controls are also available within the display’s channel strips.

Any number of input channels and output channels can be assigned to one or more of the Control Groups. Channels assigned can all be adjusted from a single worksurface control assigned to that control group. This means that changes to the Control Group fader, mute or solo will be applied to all of the channels assigned to that Control Group.

There are 2 methods to set up Control Groups:

- 1) Press the **LCD Function** button on the CG fader bank followed by the **JOIN CG** button, then press the channel select button for the CG that you want to use, then press the channel select buttons for each of the channels to be included in the CG, finally deselect the **JOIN CG** button:







2) Press the on-screen **JOIN/LEAVE** button for the required CG channel;

Press the channel select buttons for each of the channels that you want to make members of the CG;

Release the **JOIN/LEAVE** button:



Press join/leave button on required CG channel



Press channel LCD buttons to assign members

A list of all the connected channels and their names is displayed above each Control Group display.

You can also clear all the channels from a Control Group by pressing **Clear**.

When a channel is a member of a Control Group, its own controls can still be adjusted independently of the other Group members. Adjustments to fader levels are transmitted to the Group members as dB changes, so that a level increase of 2dB on the Group fader will increase all the member levels by 2dB, irrespective of the relative levels of the individual channel faders.

*Note: Control Group channels function completely differently from Group channels: Group channels mix together the audio from any channels routed to them, whereas Control Group channels simply move the channel faders of any channels assigned to them, irrespective of any audio routing.*

The number of control groups available is defined in the console **Session Structure**. Control Groups can be named using the standard naming tools. The **safe** button, located at the bottom of the on-screen channel strip, can be used to protect the assignments and settings of the Control Group from being changed if a new Snapshot is fired.

All of the Control Groups to which an input or output channel belongs to are displayed immediately above the **GANG** and **SAFE** buttons in the Channel strip panel.

*Note: Only the first two to three Control Group assignments within a channel can be displayed in the channel strip.*



All of the channels included in a Control Group are listed in the top half of the Control Group channel strip display. To clear all of the channels currently assigned to a Control Group, touch the Control Group's **clear** button, located below the **join/ leave** button, and press **Yes** in the warning display that appears.

### 2.9.2 Control Group Fader Modes

There are three modes in which the Control Group fader can interact with the faders of the channels assigned to it, and the button below the **clear** button in the channel strip display toggles between them:

In **moving fader** mode, all assigned faders will move to replicate any Control Group fader movements.

*Note: It is the level change associated with the fader movement which is replicated, not the physical distance the fader is moved.*

In **VCA style** mode, moving the Control Group fader affects the output level of all assigned channels without moving their faders. In **mute only** mode, the Control Group only controls the mute buttons of assigned channels, not the output level.

*Note: In all three modes, moving the fader of a channel assigned to a group does not impact the output levels of other channels within the group.*

### 2.9.3 Control Group Mute Functions

The mute buttons within a Control Group interact in the same way, regardless of the current fader mode:

The mute button above the LCD display on a Control Group fader can be used to mute all of its assigned channels. Its function is duplicated by the **all mute** button below the channel's scribble strip. When a channel is muted by its Control Group mute button, the channel's mute button lights in the normal way. The channel's **CG mute** button goes blue to indicate that the Control Group mute button (rather than the channel mute button) is responsible for the mute. When deactivated, the Control Group mute button returns all assigned channels to their mute state before the Control Group mute button was activated.

CG Mutes are treated as "in series" where a channel is a member of more than one group. All CG mutes must be off for a channel to be unmuted; any CG muted always mutes all of its members.

If a channel is CG muted by single or multiple CGs, the worksurface channel mute button will override all CG mutes for that channel. The channel will not however be removed from CG membership so if the relevant CG is muted again, the channel will also be muted.

The auto-mute function, activated by touching the **auto-mute** button located above the Control Group name in the Channel Strip panel, automatically mutes any channel which is removed from that Control Group and unmutes any channel that joins the Control Group.

### 2.9.4 Control Group Spill (1272+)

Members of a control group can be spilled directly rather than adding them to a spill set. They can be spilled by using the **Spill** button on the CG channel strip and the Control Groups panel, or by firing a “Spill Control Group” macro under the Layout command type.




### 2.9.5 Control Group Aux Send Enable (v1445+)

The **aux sends** button in the Control Group channel strip allows individual CG faders to control Aux send levels when the Aux to fader function is active. The Control Group fader acts as a trim for all Aux sends on the selected (soloed) Aux buss.

An **Aux Send Enable** macro is included in **Setup>Macros** under the **Control Group** command type.

Include/exclude CG  
from CG controls Aux  
Sends.




*Note that the **CG Fader Controls Aux Send** global setting in **Options>Faders** has been removed in V1445.*

## 2.10 Solos Menu

### 2.10.1 The Solo Panel

Touching the **Solos** menu opens the **Solo 1** and **Solo 2** displays. These displays are used for configuring the console's solo busses. Solo buss 1 is configured in the left-hand display, and solo buss 2 in the right. Both displays function in exactly the same way:



*Note: The in-channel solo functions are described in the Channel Types Chapter*

At the top of each display is a black box containing the solo meter(s), three buttons, and an input trim encoder. These controls are duplicated on the console worksurface. The first button selects which point in the channel feeds the buss, and toggles between PFL and AFL, as indicated by the **pfl** or **afl** labelling above the button turning green. The button is also ringed green on the worksurface when **afl** is selected.

The second button toggles the two solo button modes: **multi** in which multiple channels can feed the solo buss at once, or **single** in which only one channel can feed the buss. In **single** mode, when a channel is feeding the solo buss, pressing the solo button on a different channel will cause the originally selected channel to be deselected from the solo buss. The solo button mode is indicated by the **multi** or **single** labelling above the button turning red. The button is also ringed red on the worksurface when **single** is selected.

All feeds to the solo buss can also be cleared by pressing the **clear** button. When there is a feed to that solo buss somewhere on the console, the button is ringed blue on the worksurface.

The level of the solo buss can be adjusted using the trim encoder on the worksurface. The on-screen **trim** pot is always assigned to this worksurface encoder, as indicated by the presence the green ring around it. The signal can be trimmed by  $\pm 18\text{dB}$ , and the trim value is indicated to the right of the on-screen **trim** pot.

In the centre of the **Solo 1** or **Solo 2** display, there is an **auto solo** area which lists all the channels which are selected for the **auto solo** function. This function automatically routes selected channels to that solo bus whenever another channel is soloed, and the selected channels can be scrolled if necessary, using the scroll bar on the right of the list. The **auto solo** channels are selected in the Channel Setup display. This **auto solo** function is enabled and disabled by touching the left-hand blue button below the **auto solo** list. The button label displays whether the **auto solo** function is **enabled** or **disabled**. The channels in the **auto solo** list can all be removed by touching the clear all button below the **auto solo** list.

**Tip:** If you are using effects returns, selecting auto solo will allow soloed tracks to be auditioned with their effects returns - this function only works in Multi-Solo mode.

The solo buss signal can be delayed using the **delay** pot to the right of the **auto solo** area. Switch the delay on using the **on** button below the pot. Touch the pot to assign it to the Touch-Turn encoder. The delay value has a range of 0 to 2.7 seconds and is displayed above and to the right of the **delay** pot.

The **mono**, **stereo** and **surround** buttons to the left of the **auto solo** area select the size of the solo buss. Each button is red when selected and grey when not selected. The selected format is also indicated by the number of meters displayed in the top left corner of each display.

### 2.10.2 The No Solo Setup Display

Below the **mono**, **stereo** and **surround** buttons, is a button marked **no solo**. This button defines what signal (if any) is present on the buss when no channel solo is active. By default, the master buss is selected as the no solo source. Pressing this button opens the **No Solo Setup** display:



At the top of the display, there is a text box which can be used for renaming the solo buss. Touch the box or the keyboard symbol to its right, type the new name on the on-screen or external keyboard and press **OK**. The **Channel Name** display containing commonly used words for quick insertion can be accessed for buss naming by touching the down arrow immediately to the right of the text box. The solo buss name will then appear at the top of its master solo display, and in any solo-assigned master faders (See below for details).

Below the naming area, there are two columns of buttons used for selecting the audio source for the **no solo** function from among the **group**, **aux** and **matrix** channels. The left-hand column contains the following buttons: the **groups** buttons (**mono** or **stereo**), the **auxes** buttons (**mono** or **stereo**) and the **Matrix** button (**mono**). Touching one of these buttons causes it to lighten to indicate that it is selected, and results in a list of those channels appearing in the right-hand column. A scroll bar appears in the right of the display if the channel list is too long for the window. Touching one of these signal buttons assigns it to the no solo function, as indicated by the lightening of the signal's button and by the labelling immediately beneath the no solo button displaying the signal name. If a stereo signal is selected here, only the left-hand signal is displayed beneath the button. Signals can be deselected by touching them again. When no signal is selected for the no solo function, the labelling beneath the button displays **none**.

To close the **No Solo Setup** display, press the **CLOSE** button in the top right-hand corner.

The area below the **auto solo** area concerns the solo buss outputs. In the centre of the output area, there is an output level pot. Touch the pot to assign it to the Touch-Turn encoder. The buss output level trim ranges from **OFF** to +10dB, as indicated to the right of the pot.

### 2.10.3 Assigning Solo Busses to Faders

The solo buss output level can also be assigned to the master fader(s) by pressing the **assign level to master** button(s) to the right of the **level** pot. Each button is highlighted in gold when it is selected. When a solo buss is assigned to a master fader, the master fader LCD button displays green, and the button lightens to indicate when any channels are assigned to the solo buss.

The top half of the LCD buttons displays the solo buss number along with any name given to it in the **No Solo Setup** display. When the fader is moved, the bottom half of the LCD button displays the fader level.

When a solo buss is assigned to a master fader, the fader's LCD button becomes a solo clear button, as indicated by **CLEAR** being displayed in the bottom half of the button when the fader is stationary.

Solo Busses can also be assigned to channel faders by using the **LCD Function>assign faders** and selecting the solo channels from the **channel list**.

### 2.10.4 Solo Outputs Routing

Each solo buss includes an insert send and return, and a direct output, both of which are routed in the **Solo Outputs** display. This display is accessed by touching the **insert** button below the **no solo** button, or the **direct outs** button in the top left of the solo buss output area.

This insert point only applies to the Solo buss Direct Output, not to the headphone signal.

At the top of the **Solo Outputs** display, the buss naming function described above is duplicated. Towards the bottom of the display, there are two buttons marked **output** and **insert A**. Selecting one of these buttons assigns that send (or send and return) to the signal routing area above it: When the insert is assigned, the **ins A send** routing button appears in the left-hand column, and the **ins A return** routing button in the right-hand column; When the output is assigned, the **outputs** routing button appears in the left-hand column and the right-hand column is left blank. Pressing any of these routing buttons opens a routing display. Insert and output routing can then be routed as described in the Getting Started section.

An extra button labelled **send+return** is included above the **ports** list in the **Insert Send Route** display button. When this button is activated, the send and return routing is linked for all signals within the **INTERNAL** port: If the **Graphic 1** input is assigned to the insert send, the **Graphic 1** output is automatically assigned to that insert

return. Similarly, if it is the return which is manually assigned, the send automatically copies that send assignment. The **send+return** button is grey when inactive and brown when active.

Once the insert send and return signals have been selected, level trim pots appear in the bottom half of the **Solo Outputs** display. To the left of both pots there is a meter (or pair of meters, in the case of stereo channels) displaying the send or return level, and to the right of both pots there is a numeric display of the level trim in dB. Below the send level trim there is an **on** button which switches the send on and off. Below the return level trim there is a reverse phase button which inverts the phase of the returning signal. Both of these buttons become ringed in red to indicate that they are on.

Once any insert or direct out has been routed, the route is displayed below the button in the **Solo 1** or **Solo 2** display.

### 2.10.5 Headphone Outputs

Touching the **headphone** button in the bottom left-hand corner of the display sends the solo buss signal to the headphone socket(s). The button turns blue to indicate that it is active.

The headphone output(s) receive both solo buss signals, and the headphones will be silent when neither buss is routed to them, unless a **no solo** signal has been assigned.

The headphone level is controlled by the output **level** pot in the output area, and also by the headphone level encoder located on the surface. The headphone signal can be muted by pressing the **mute** button next to the worksurface headphone level encoder, and the button is ringed red to indicate that the headphone send is muted.

### 2.10.6 Solo Meters

Solo meters can be displayed on the Master or Overview screen by pressing the **floating meters** button below the solo **delay** area in either side of the **Solo** panel.

*Note: Floating meters are described in the Channel List section of this chapter.*

### 2.10.7 Solo as an Input Source

Both Solo 1 and Solo 2 are available as input sources for all channel types. A warning confirmation will appear on screen before the route is made.

**WARNING: Soloing a channel that has a solo buss as its source will result in a feedback loop being created and dangerously high audio levels at any output routed from the solo buss or channel**


## 2.11 Network and Mirroring

### 2.11.1 Network Configuration

Any two SD Series consoles of the same type can be mirrored together to provide a fully redundant audio system. The SD7, Q7 and Q8 consoles are fitted with two separate engines, and as such, offer built in redundancy.

In order to take advantage of this redundancy, you need to verify the console networking is working and synchronise your session between the two consoles/engines.

Before the consoles/engines can be mirrored, you should ensure that a standard crossover network (Ethernet) cable is connected between the two consoles/engines (a standard network cable will also work with Quantum consoles). Without this connection, the two consoles/engines will not “talk” to each other. To open the Network window, touch the **Network** button at the top of the Master Screen. The following window will open...



### 2.11.2 Mirroring for the first time

If the consoles are physically connected, but do not see each other, then you may need to enable Networking.

There is an option in the **OPTIONS/CONSOLE** tab to **ENABLE CONSOLE NETWORK** (YES/NO). This must be set to YES on both Engines. After doing this, shutdown and restart both consoles/engines and when the sessions are loaded go to the NETWORK window and you should see yellow OK lights against A & B. This indicates that the network has connected the two consoles/engines, but they are not yet mirrored.

To mirror the two consoles/engines, they need to be running the same session. The way to achieve this is to load the session into the A console/engine, then transfer it to the B console/engine using this Network window.

1. Ensure you are switched to the A console/engine.
2. Load your session into console/engine A
3. Open the Network Window
4. Press the **Select** button for console/engine B and then press the **Send Session to Selected** button.

This will copy your current console/engine A session and load it into the B console/engine. Once this is done, the console/engine B detail section will change to reflect the new loaded session.

You can now press the **Mirror** button. The Mirror buttons will turn green, and the console is now mirrored. Audio mastership can be switched between console/engine A and console/engine B using the **Audio Master** button and, if the racks are correctly connected, you will not hear the switch of between the two engines.

There is also an option to **Receive Session from Selected** which allows a session file to be brought into one engine from another.

When the **Mirror from Selected** or **Mirror to Selected** buttons are pressed, the current worksurface mix settings like fader positions are transferred from one device to another. If you have sent or received a session and then made some simple changes, the additional adjustments are normally transferred when you activate the Mirror mode. If there is a significant difference between the two devices' settings at that point, you will be prompted to resync the session.

On an SD7, the ENGINE A/B switch at the top of the centre worksurface will switch the entire worksurface from one engine's control computer to another. It will not (by default) switch the audio processing from one engine to the other. This is achieved by pressing the relevant **Audio Master** button in the network window on either engine. When the button is orange, the engine is active. There is an option in **OPTIONS/SURFACE** tab that enables the switching of both control computer and audio mastership at the same time with the worksurface ENGINE A/B switch. When first configuring the system, we do not recommend running in this mode.

### 2.11.3 Mirroring Mode

This option determines how the console will behave when Mirrored via a network to another console, engine or Offline PC. This option is saved for console not in the individual session.

There are 4 modes of operation:

**Full Mirror** - all functions mirrored from one device to the other - this mode should be used on both engines in an SD7.

**Expander** - intended for use with an SD7 console and an EX007 Expander unit. The second device mirrors most functions from the first device but, significantly, allows different banks to be selected on the different devices.

**Remote** - intended for use with a PC being used as a Remote Control for a console. Allows different banks to be selected and different setup options on each device.

**One Way** - this mode is intended for remote monitoring of what another device is doing. If a device is in this mode, it can "see" what the other mirrored device is doing but cannot control the other device. This mode is only likely to be used in exceptional circumstances.

When mirroring 2 single engine consoles, the correct mirroring mode will depend on the operational requirements of the system.





#### 2.11.4 Mirroring with a laptop PC

Any SD or Quantum Series console can also be connected to a laptop PC running the Windows operating system in similar way to achieve remote control of the console.

When running SD or Quantum software on a PC, the software will appear in a number of "floating" windows, each of which represent a console section. A screen touch on the console is simulated by a right click with the PC mouse. To switch between console sections, use the small toolbar buttons that also appear on the screen marked Master\Left\Right etc.

The DiGiCo website has downloads available for all current versions of "Offline" software.

The SD and Quantum software on the PC is identical in operation to the console software and the USB key that is provided with the console will contain the offline software installation package.

Run the Installer from the USB Key. It will create folders in the root directory of your PC's C:\ drive and place a shortcut to the Offline Software on the desktop.

**IMPORTANT NOTE:** When mirroring a console to a PC you are required to set a static IP address on your PC which is in the same subnet as the console itself. The console's subnet mask is 255.255.0.0 255.255.255.0 (SD7 only) and its IP address can be seen next to its entry in the Network panel - in the picture above it is 192.168.2.146 for Engine A.

The IP address of the PC must start with 192.168.2.xxx. and must be different to that of the console.

The setup of network addresses on a PC may differ from one operating system to another so if you are in doubt, please consult the documentation for your PC's operating system before proceeding.

As an example, on Windows 10, the IP address and subnet mask can be changed by:

- 1) Opening the **Control Panel>Network and Internet>Network and Sharing Centre**.
- 2) Left click on **Change adapter settings** in the side panel.
- 3) Double click on the on connection that is connected to the same network as the console.
- 4) Double Click on **Internet Protocol (TCP/IP)** from the list to show its properties.
- 5) Set the radio button to **Use the following IP address**
- 6) Type the **IP Address** and **Subnet Mask** as detailed above
- 7) Confirm the changes and restart the computer

## 2.12 Setup Menu

### 2.12.1 Audio I/O

The **Audio I/O** display is used to configure the physical I/O connected to the SD/Quantum console, including identifying and naming the sockets of the option cards installed in racks, and the setting of pads and phantom power.

The screenshot shows the **Audio I/O** configuration window. Annotations point to various features:

- Select the port to be configured:** Points to the **Audio I/O Ports** list on the left, where **1: Rack 1** is selected.
- Edit the Port Name here E.g. Stage Rack:** Points to the **Port Name** field, which currently shows **Rack 1**.
- Copy Rack Audio to MADI:** Points to the **Copy Audio To** dropdown menu, which is set to **MADI 1/2**.
- Auto Conforming for all ports, individual racks, or individual cards:** Points to the **conform rack** button at the bottom of the main grid.
- Select the contents of the bottom-right:** Points to the **Card Setup** and **Socket Setup** panels at the bottom right.
- Select Card Type manually or using Auto-Conform function and edit Group Name:** Points to the **Card/Slot Type** dropdown (set to **Mic**) and the **Group Name** field (set to **Mic 1-8**).
- Sets the selected racks gains, pads, SRCs and phantom power to default:** Points to the **conform card** button.
- Selected Socket Properties:** Points to the **Socket Setup** panel, specifically the **Socket Name** field (set to **1: Mic 1**) and the **Socket Options** section, which includes **+48V** (phantom power) and **listen safe**.

### 2.12.2 Port Selection

Each port relates to a set of physical audio connections:

<b>Local I/O</b>	The I/O installed in the rear of the console.
<b>Rack</b>	A remote I/O rack connected via MADi or Optocore.
<b>Con</b>	A separate console connected using MADi or Optocore.

To select which port is currently being configured, touch the name of desired port under the Audio I/O port column in the top left corner of the window. Once a port has been selected, the connections contained within it are displayed in the socket's graphic.

New ports can be added to the session by touching the **add port** button, below the Audio I/O port column. A drop-down list of predefined port configurations will appear, allowing you to select the appropriate device. These user created ports can be deleted by pressing the **remove port** button, below the **add port** button.

### Copying Audio and Listening to Copied Audio (MADi Recorder Setup)

Any incoming MADi or Optocore connected rack stream can be copied to any other MADi Output by selecting the incoming port in the ports list and using the **Copy Audio To** drop down menu. For example, if you want to copy Rack 1's Audio Inputs to a MADi equipped recorder connected on port 2, select port 1 in the ports list and then select MADi 2 from the **Copy Audio To** drop down menu. The console will send the 56 or 64 channel MADi stream to MADi Output 2 and it can be recorded as necessary. In addition, by connecting the recorder's MADi Output to the console's MADi 2 Input, the playback can be monitored in the same channels as the original source material. Just press the **Listen To Copied Audio** button to monitor playback and press it again to return to monitoring the live sources from the rack. When Listen to Copied Audio is active, "Listening to Copied Audio" is displayed in the session status panel of the master screen.

*Note: More complex inter port routing is possible using the Copy Audio Panel, please see the COPY AUDIO section of this manual.*

*Note: KLANG Konduktor has been added as port and device type in v1528*


### 2.12.3 Port Hardware Configuration

The port is named automatically according to its connection type, as displayed to the right of the **ports** selection area. However, the name can be edited by touching the **Port Name** box or the keyboard symbol to its right, typing the new name into the QWERTY keyboard which appears, and pressing **OK**. The type of device connected to the port can be altered by touching the down arrow next to the **Device Type** box, located next to the **Port Name** box, and selecting the appropriate device from the drop-down list that appears. The physical port being used to connect the device can be altered by touching the down arrow next to the **Connection** box, to the right of the **Device Type** box, and selecting the appropriate connection port from the drop-down list that appears. The status of the connection is displayed below the **Connection** box as either **connected** (in green) or **not connected** (in red).

*Note: The configuration of the Local I/O port is fixed, so no hardware changes are possible. You can, however, change the Port Name, the Group Names (relating to the name of each physical card) and the Socket Names (the name of each physical connector on a card).*

### 2.12.4 Port Control

Normally, the input gain, phantom power and pad of each DiGiCo Rack input is controlled remotely from the SD/Quantum console. However, in multi-console systems where Racks are shared between two DiGiCo consoles with MADi Connections, only one of the consoles can remotely control these rack settings. With Optocore connections any console can have control. Therefore, the level of control given to each console must be defined. Control options are displayed in the bottom-right area of the **Audio I/O** panel when the **Splits & Sharing** button towards the base of the panel is pressed:



There are three levels of control:

**isolate:** The SD/Quantum console will not exchange any control data with the rack. This means that the console will neither be able to adjust rack settings, nor adjust its own settings according to returning control data.

**receive only:** The SD/Quantum console will receive the rack's existing settings but not send control data back. This means that the console will not be able to adjust rack settings but will be able to adjust its own settings according to returning control data.

**full control:** The SD/Quantum console will receive the rack's existing settings and will send control data back. This means that the console will be able to adjust the rack's settings and receive tallies back from the rack

Under the **Selected Rack** column, control can be defined as shared by pressing the **Shared** button. Individual racks can also be controlled using the **isolate**, **receive only** and **full control** buttons beneath the Shared button - these buttons will only affect the selected port.

### 2.12.5 The Socket Display

When a port has been selected from the **ports** list on the left, the individual connections within that port are displayed in the Sockets graphic, which makes up most of the rest of the **Audio IO** display. For Rack or Console ports, each column in the graphic represents an IO card, and the type of IO card is displayed at the bottom of each column. For the **Local I/O** port, each row represents a type of I/O socket.

Each individual socket displays the following information: the current socket name is across the middle, and the socket number within the card is in the top left-hand corner.

For analogue input sockets, the current gain is at the bottom, and the top right-hand corner displays a red **48** symbol if the socket's phantom power is switched on. For analogue rack output sockets, there is a **-10** symbol in the top right-hand corner which is yellow to indicate that the 10dB pad is switched in, and white to indicate that no pad is present.

For digital inputs the status of Sample Rate Conversion On/Off is displayed.

Touching a socket within the graphic assigns that socket and its card to the area below the graphic for configuration, as described below. The number in the top left corner of an output socket will change colour if the socket is being used by the Copy Audio Function.

### 2.12.6 Socket Conforming

In order to use a rack, the on-screen contents of the rack must match the cards physically installed in the connected rack. There are two ways of achieving this:

#### Manual Conforming

Select each card (column) and manually select the appropriate card in the **Card/Slot Type** drop down menu in the lower section of the window. Once the correct card type is selected, the card type name at the bottom of the selected card will turn green, indicating the card type matches the card installed in the rack. If there is a mismatch, the card type name will be red, and the error should be corrected by selecting the correct card type.

#### Automatic Conforming


The audio I/O can be automatically conformed for the whole console (using the **Conform All Ports** button in the bottom left of the panel) or the currently selected rack (using the **conform rack** button below the socket display). Pressing these buttons will correctly select the correct card for each slot. Once complete, all of the card labels beneath each slot should turn green.

The default rack button below the socket's graphic can be used to reset the gains, pads, SRCs and phantom power settings for the selected port.

It is also possible to auto-conform on a card-by-card basis: With a single card selected (by touching any of the sockets on that card), press the **Cards & Sockets** button towards the base of the screen, followed by the **conform card** button which appears in the area to its right.

### 2.12.7 Group and Socket Names

Cards and sockets are named automatically, according to the **Device Type**, **Card/Slot Type** and their position within the port. To edit these names, press the **Cards & Sockets** button towards the base of the **Audio I/O** panel to bring up the **Card Setup** and **Socket Setup** displays to its right:



Touch either the **Group Name** or the **Socket Name** box (or the keyboard symbols to their right), type the new name into the QWERTY keyboard which appears and press **OK**. Touching the down arrow in between the **Socket Name** box and keyboard symbol opens the **Channel Name** display which enables commonly used words to be inserted quickly without the use of the keyboard.


A range of sockets can be named with the same label and an incrementing number by using the **auto-name** function below the **Socket Name** box: To define how many sockets will be auto-named, touch the numeric display, turn the **Touch-Turn** encoder to the right of the screen until the numeric display below the keyboard symbol displays the correct number. Alternatively, touch the numeric display, type in the number of sockets to auto-name into the keypad that appears, and press **OK**. Once the number of sockets has been defined, the auto-name button becomes active. Pressing it will cause the name of the assigned socket to be replicated for all the sockets selected for auto-naming. If the assigned socket's name does not end in a number, a '1' will be added to it and incremented for the remaining sockets. If the assigned socket's name already ends in a number, that number will be incremented for the remaining sockets.

### 2.12.8 Socket Options

Depending on the socket type, further **Socket Options** are displayed below the **Socket Name** area. E.g. if an input card is selected, and option for phantom would appear.

#### Line Check

When line check mode is active, any input connected to the console whether it is routed into a channel or not, can have its socket parameters adjusted. Touching any input socket will show the available controls in the socket setup area. Gain is controlled via the touch turn control. When listen is pressed, any audio from the selected socket will be sent to the solo assigned to **Line Check**, this can be changed in the solo tab in the options panel. There is also a drop-down list of inputs using this socket.



### 2.12.9 Copy Audio

The Copy Audio Matrix, located in the Setup Menu, has been designed to serve 2 purposes: -

- To provide a flexible system for routing input sources from multiple racks to a recording system.
- To route inputs from one rack to the outputs of another rack without using up console processing resources.


Any input socket connected to a console port can be copied multiple times to any output port socket. One of these “copies” can be nominated as your “Listen Source” for when **Listen to Copied Audio** is activated.

It is also possible to place a copied input socket in “**Listen Safe**” so that when **Listen to Copy Audio** is activated; the original source will be heard rather than the copy source.

Copy Audio settings are not snapshottable and remain constant throughout a session unless they are manually changed by the user.

## Setting up the system

In Audio IO, conform all your ports, make any required Optocore output allocations and map your system.



Open the Master Screen / Setup / Copy Audio panel and you will see the collapsed matrix with input ports listed down the left side and output ports across the top.

The input port list on the left shows all available input ports that have been configured in Audio IO including Local IO, MAD1 and Optocore connections. Touching on any of these ports will expand the list to show the individual sockets. If a socket has been routed into an input channel, the channel name will be shown in the “Channel” column.

The output port list across the top shows all available output ports that have been configured in Audio IO. When expanded, any output socket that is already in use or is not allocated to your console is shown in blue and its column highlighted. Existing routes from channels/busses cannot be overwritten in Copy Audio.

If a port is expanded, touching anywhere in the sockets list will collapse that port.

To make a copy route, expand an input port and output port and touch/drag on the grid. You will see the selected cells turn red. This first copy, by default, is defined as your **Listen Source**. Any subsequent copies of the same input socket are shown as orange cells. You may copy an input socket to as many locations as you wish but only one can be defined as your listen source. You can change the defined **Listen Source** by first pressing the “**Set Listen Source**” button in the top left corner of the panel and then touching on cell in the matrix. This cell will turn red, and any previously selected listen source cell will turn orange.

If you have used the “**Copy Audio To**” function in the Audio IO Panel and then open the relevant ports in the Copy Audio panel, you will see a diagonal line of red cells between the source port and the destination port.


If an output socket is being used as a copy destination, this will be indicated in the Audio IO page by card socket number showing red (for a Listen Source) or orange (for a copy). You will also see a red/orange square next to any sockets in use in any channel/ buss output routing panel. Please note the copy routes CAN be overwritten by output routes.




## Listen Safe

Listen safe is designed to allow the user to “Safe” a channel from the “Listen to Copied Audio” selection. This means that when listen to copy audio is toggled on, sockets that are safed will be excluded. This can be activated from the Copy Audio Panel, the Channel List (when in Edit mode) or any Input Channel Setup Panel. When active, the Input Channel Name box will turn red. As the Listen safe is associated with the input socket, Main and Alt inputs have independent listen safes.

## Copy Audio Presets, Move and Copy Outputs functions



The **move outputs**, **copy outputs**, and **presets** buttons can be found at the top of the copy audio panel, which can be accessed from **Setup > Copy Audio**.



**Move outputs** allows the output routing to be moved from one place to another. For example, there is a selection of channels sent to the local IO in copy audio, but instead these need to be sent to a rack output.


Press **move outputs**, select the source output device and then select the destination output device and the copy audio routing will be moved.

**Copy outputs** allows the copy audio routing from one output device to be copied to another output device.



Press **copy outputs**, select the source output device and then select the destination device and a copy of the copy audio routing will be created.


**Presets** can be used to save routing made in **Copy Audio**, saving time.



In the presets panel, presets can be created and updated, their names can be edited and presets that are no longer wanted can be deleted. All presets can also be cleared.

**2.12.10 Audio Sync**

Selecting **Audio Sync** from the **Setup** menu opens the **Audio Sync** display. This is where the clock source is selected:



An SD/Quantum console will operate at Sample Rates of either 48000Hz (48kHz) or 96000Hz (96kHz), as configured in the **Session Structure** panel.

By default, the console will be set to clock internally (master). The console can also be clocked to external sources including: Word Clock, AES/EBU, Video Reference (SD/Q5, SD/Q7), MADI & Optocore.

*Note: The Audio sync settings of a console are saved to the session file.*

*Note: When a valid clock is detected on an external sync input, the corresponding Green OK box will light, even if that input is not selected as the clock source for the console.*

In standard operation, all Optocore connected console engines should be set to **Audio Sync = Optocore**. In this situation the Optocore device with the lowest Optocore ID will automatically become the Master Sync source for the Optocore system. An Optocore system can be synced to an external Word Clock sync source by connecting that Word Clock source to any SD/Quantum engine Word Clock Input and selecting Word Clock as the Sync source in the Setup/Audio Sync panel.

*Note: If 2 SD engines have Word Clock connected to them, the system will sync to the Word Clocked engine with the lowest Optocore ID*

An Optocore system can also be synced to a Word Clock source connected to the Word Clock input on any SD Rack. Connecting the Word Clock to the rack automatically sets this as the Master Sync Source. If any SD engine has a Word Clock sync source and is set to Word Clock sync, this will be used as the Master Sync Source instead of the SD rack.

## 2.12.11 Timecode &amp; Transport

When the SD/Quantum console is used in typical live sound applications there will often be no time related control systems (timecode) or motion control (tape transport) connected. Synchronisation and machine control does not need to be considered.

This panel can be accessed by touching the Setup button on the Master screen and then touching the Transport & Timecode button.

**Frame Rate**

This must be set up for the frame rate used by your other equipment. You can select from four different basic frame rates, with a **drop-frame** option available for 29.97 and 30fps.

**Timecode Source**

You can choose the Console option to make the console generate the master timecode for the setup, or you can choose to make the console "chase" timecode which arrives at one of the external sockets - SMPTE (LTC) (SD/Q7 & Q8 Only), MIDI (MTC), or 9-pin. These external sockets are located on the console rear panel.

The **9-pin Eavesdrop** option requires a special 9-pin cable. The option is provided for installations where the 9-pin connection runs between two other pieces of equipment (for example, a video machine and DAW), but the console is required to chase this timecode. 9-pin does not normally allow more than a single direct connection between two machines, but using the Eavesdrop cable, you can make the console "listen" to the timecode passing between two other machines, and to sync to and display this timecode on the worksurface.

*Note: If you are using 9-Pin Eavesdrop mode, you cannot use any of the options for direct 9-pin connection.*

### Timecode Output Enable

Whether the console is operating as timecode master or deriving its timecode from another device, you can choose to route a timecode signal out from the MIDI (MTC) and/or SMPTE (LTC) sockets. If timecode is being received from another device, it is regenerated before being routed to the output.

### Machine Control Enable


The console can only send Control signals if you have enabled a Machine Control output. This can be MIDI Machine Control (MMC) and/or 9-pin Disk or Tape. Note that you cannot output 9-pin control if you are using the Eavesdrop option to read timecode. **MIDI Machine Control** has limited transport features, supporting only the Play, Record, FF, Rewind, Stop and Locate functions. 9-pin control supports Shuttle and Jog functions.

### Off-line Buttons

The configuration panel allows you to temporarily disable all timecode and transport control to any combination of outputs. The ALL button disables all timecode and machine control output - this is especially useful to prevent external machines trying to chase the console timecode.

#### 2.12.12 Macros

Selecting **Macros** from the **Setup** menu opens the **Macros** display. This display is also opened by pressing the **assign** button in the **macros** area of the worksurface.



This is where macro commands can be assigned to the smart keys or Macro buttons in the **macros** area of the console surface, as well as to the function (F) buttons on the external keyboard and to the console's GPIs. Macros can also be fired directly from this list by touching the macro when none of the right-hand buttons is active.

The **macros** area has capacity for either 8 or 40 macros, arranged in one bank of eight, four banks of 10 or eight banks of five depending on the console. If the console has bank buttons, pressing any of the bank buttons across the top of the **macros** area assigns the smart **keys** below them to that bank. The bank currently assigned to the smart keys is indicated by its button being ringed green.

The **Macros** display includes a list of all the macro commands which have been created, along with the button to which they have been assigned, if this has been selected. The list is scrollable using the scroll bar to the right of the list. **Note that this list therefore includes macros which have been created but have no trigger.**

Pressing the **Transport** Button will automatically assign the console transport controls to the macro buttons overwriting any existing assignments.

On SD8,9,11, pressing the **floating labels** button opens a panel on the console's master screen that shows the worksurface macro buttons and their name label if macros have been assigned to them. Touching either the button or the label will fire the macro.



To create a new macro, touch the **new** button, in the top right-hand corner of the display. To create a macro based one that already exists, touch the **duplicate** button below the **new** button, followed by the macro you wish to duplicate. When either button is touched, a macro is created with the default name **macro n** where n is an auto-incrementing number, and the **Macro Editor** display (described below) is opened. A duplicate macro will contain all of the settings of its parent, apart from the name.

To edit a macro, touch the **editor** button below the **duplicate** button, followed by the macro you wish to edit. The **Macro Editor** display (described below) will then open.

Macros can be assigned from the main **Macros** display without opening the **Macro Editor** by touching the **assign** button below the **editor** button, touching the macro you wish to assign, and then pressing the button to which you wish to assign the macro.

Macros can be deleted by touching **delete files**. To delete all the macros in the list, touch **select all**, followed by **confirm**. To delete one macro or a selection of macros, touch the macros you wish to delete followed by **confirm**. To delete a consecutive range of macros, touch **select range**, touch the first and last macros included in the range to be deleted, and touch **confirm**.

### 2.12.13 The Macro Editor

The **Macro Editor** is where macros are defined, including the commands included in them and the control used to trigger them. Virtually any command within the console can be assigned to a macro, ranging from opening master panels to adjusting in-channel signal processing.

*Note: that fx parameters are only available once fx units are in use in the session.*



The name of the macro being edited is shown at the top of the display. To switch to a different macro in the list, touch the new macro in the Macro display list (You may need to move the displays around the panel to access the list). To rename the macro, touch the **macro name** text box, type the new name using the on-screen or external keyboard, and touch **OK**. This name will be used in the Macros display and also in the LCD display within a smart key assigned to that macro.

*Note: A line break can be inserted into the smart key macro name by typing a comma within the macro name text.*

The list beneath the **macro name** text box, lists the commands currently included in the macro. When there are multiple commands in the included commands list, they are triggered in the order in which they are listed. New commands are added to the selected row in the list, overwriting any command previously in that row. To insert a row for a new command in between two adjacent commands, touch the row above which you want to insert the command, then touch the **insert** button to the right of the included commands list.

There are two ways of adding a command to the included commands list:

1. Touch the row in the list in which you want the command to appear, then touch the **capture** button, located in the top righthand corner of the display. The button turns light blue to indicate that it is active. Any commands now actioned on the console will then be added to the included commands list. Once all the desired commands have been actioned, deselect the **capture** button.

2. Touch the row in the list in which you want the command to appear, then touch one of the command types in the scrollable **command types** list to the left of the display. This brings up a list of the commands within that command type in the scrollable **commands** list in the lower half of the display. Touch the desired command to bring it into the included commands list.

For commands associated with worksurface controls (all command types above **System** in the **command types** list), the included commands list displays the command type (in the **channel type** column), the scope of channels included in the command where appropriate (in the **from** and **to** columns), the command's name (**controller**) and any value associated with the command. For command types associated with the master panel (from **System** down), the included commands list displays the **command**, along with any **filename** or **value** associated with it. The list can be scrolled if necessary, using the scroll bar to its right.

The values in the **from**, **to** and **value** columns can be adjusted by using the Touch-Turn encoder and **value +** and **value-** buttons to the right of the included commands list. Touch the box to be adjusted to assign it to the encoder and value buttons. The present value is shown in the display in between the value buttons. If the **value** column displays something other than numeric values, the options are cycled using the Touch-Turn encoder and **value +** and **value -** buttons (cycling for example, between **on**, **off** and **toggle**). Values can also be typed in by touching the value box, typing the new value using the external or on-screen keyboard, and touching **OK**.

To remove a command from the list, touch the command to be removed and touch the **remove** button to the right of the included commands list.

The bottom-right of the **Macro Editor** is used to define what triggers the macro. The **action** buttons below the **smart keys / macro buttons** are used to define whether pressing the button triggers a macro **on** or **off** command. Selecting a new trigger for a macro automatically deselects any old trigger than might have been assigned.

On SD7, SD5, SD10 and SD12 and Quantum consoles, Smart keys are selected by touching one of the bank buttons (the number of bank buttons will depend on the console) below the **assigned to** legend (causing the button's ring to light green, indicating that it is selected) followed by one of its **smart keys**. The smart key will then display the first command from the included commands list. The colour of the smart key can be chosen using the arrow buttons in the **colour** area below the smart keys. The selected colour is displayed between the arrow keys.

On SD8, SD9 and SD11, Macros are assigned in a similar way but directly to one of the 8 Macro buttons.

Whenever a macro button is pressed, it performs an 'On' action. This is the first press of the macro button. The next press of the same macro performs an Off action.

These On and Off actions can be the inverse of each other, so instead of having alternative presses of the macro button just toggle the state of a controller, the macro can be programmed so that first press is always a mute on command and the 2nd press of the macro button is always a mute off command.

This has the advantage of being able to provide an indicator on the Macro button of the state of the controller. On and Off states can have different colours and different text.

Macros can be tested by touching the **fire macro** button, located in the top left-hand corner of the display. Once the macro has been fully configured, close the **Macro Editor** display.

2.12.14 Advanced Macro Triggers (V19xx+)


The Macro Editor has been expanded to include new options for triggering Macros. Existing options have been retained but laid out slightly differently on screen in tabbed sections. Macros can now also be triggered as part of Snapshot recall.

*Note – only one trigger type can be selected for each Macro.*

The **selected**, displayed tab will be underlined in **orange** and the **active trigger** will be displayed with a **green circle**.


Smart Keys

The **smart keys** tab allows assignment of the Macro trigger to the console’s worksurface Macro buttons. Where relevant, select a **Macro bank** number and then the required button in that bank. The Macro can be assigned to the **ON** or **OFF** action of the button and a background colour selected.



External

The **external** tab allows assignment of the Macro trigger to a GPI, an incoming OSC command or a MIDI Program change message. Other relevant options are displayed when the external device type is selected.






Snapshots


A console snapshot can also be defined as a Macro trigger by pressing the **edit** button in the **snapshots** tab which displays a list of available snapshots. Single or multiple snapshots can be added to the list of triggers for any particular Macro.

*Note - Any snapshot can only trigger a single Macro so, if a snapshot is required to trigger more Macro functions than those included in the existing Macros, create a new Macro which includes all of the required commands for that specific purpose.*



Other

The **other** tab allows assignment of the Macro trigger to **keyboard F keys**, the console **Audio Mastership switch** A or B and the worksurface **prev** and **next** snapshot buttons.



Advanced


The **advanced** tab allows conditional triggers for Macros whereby the status of certain channel controls and meters can be used to trigger a Macro.

Single or multiple triggers can be specified for one or many channels.

Required channels can be chosen by touching the **ADD** button and selecting from the channel list.

Each channel touched will be added to the list. Channels can be removed from the list by selecting them from the list and touching **REMOVE**.

If multiple channels are selected, the Macro can be triggered when either **ANY** or **ALL** conditions have been met.



Choose the required **trigger** and **state** for each of the entries in the list.

Options for potential triggers are **fader** level, **mute** state, **solo** state and **meter** level.

For mute and solo, either **on** or **off** states can be selected.

For faders, a value can be set and the trigger assigned to a level **greater than** or **less than** that value.

When the relevant fader passes through that value, the condition will be met.

For meters, first select the required meter position from **pre-trim**, **post-trim**, **pre-fader** or **post-fader** and then enter a value and a state in a similar way to faders.


To change the meter position, touch the current selection to display the meter position choices again.

*Note – for meters, a value of sp represents “signal present”.*

For any given channel, each trigger and state combination can only be used once.

For example, for Channel 1, a fader greater than state can only be used once but fader greater than and fader less than is a valid combination.

If the same trigger/state combination is entered twice for the same channel the following warning will be displayed.




## OSC Macros

There is also a Macro type called **MacroOSC** which allows a Macro to transmit an OSC message via the console's ethernet port.

In the **Master Screen > Setup > External Control** panel, a new **Device Type** is used to define the details of the external device which will receive the OSC commands.


Touch the **add device** button and select **Macro OSC** from the list of device types, enter an IP address for the receiving device and a **Send port** number.

Multiple Macro OSC devices can be defined and each should have a unique **DevID** automatically assigned by the console.




In the **Macro Editor**, there is a command type called **MacroOSC** which offers options of **Integer, Float, String and Address Only** (no data value required) OSC commands.

Define the required **OSC command** and **data value** and then, using the **value +/- buttons**, specify a destination **Device ID** in the right-hand column.



Macro list search function

The Macro command list for each **command type** can be searched by entering text in the **commands search** box at the top of the list. A search can be performed for whole or parts of words.



### 2.12.15 Talkback

The **Talkback** display, where the talkback busses can be configured, is opened by selecting **Talkback** from the **Setup** menu.



In the right-hand side of the **Talkback** display, there is a mic **input** gain pot which is always assigned to the **gain** encoder in the worksurface talkback area. The pot's gain value is indicated in the box above the pot. The talkback signal level is shown in the meter to its right. Touching the white box below the gain pot opens the **Talkback Input** display which consists of an **input route** button. The current route is displayed below the button. Pressing the button opens the **TB Input Route** display, which functions in the same way as all other input routing panels.

To the left of the input section of the display, there are talk buttons with text boxes beneath them. Touching each button enables and disables the corresponding talkback button on the worksurface. The button rings red to indicate that the buss is active. Touching the text box beneath the button opens the **TB Outputs** display for that talk bus. This consists of a naming area and an **outputs** button. The first output currently selected is displayed below the button.


Pressing the button opens the **TB Output Routes** display which functions in the normal way. The first selected route appears in the text box below the talk button.

The three blue coloured text boxes above the buttons provide access to a panel allowing the selection aux busses. Once selected, the Talkback button will automatically activate the talk To Aux functions on those busses. This enables you to talk to multiple Auxes of your choice at the press of a single button.

### Talk to Auxes

To talk to individual or multiple of Aux outputs there is an assignable row of controls on Aux channels, controllable independently or from the **Talkback** panel which has a **Talk to Aux Setup** list for each Talk button.

This is implemented as a Talkback Input channel which uses a single engine processing channel to provide the aux sends. This channel appears, in a default session, on its own in the last bank on the left of the console.




On the Aux Output channels, hold one of the **Assign** buttons next to the row of assignable controls and then touch the **talk** area of the screen. This will assign the selected rotary control and switch to the talk level and talk on/off. These are used to switch Talk to Aux On/Off, control the level of talkback signal and set the level of dim when the talk is active. A **dim** function is available for reducing the level of aux programme while the talk function is active. This is set using the 2nd Function of the assigned controls.

The worksurface **talk** buttons can also be programmed to activate the Talk function on single or multiple user defined channels. Open the **Setup/Talkback** panel and touch the label above the **talk** button, then select any combination of Mono and Stereo Auxes to activate with that button.


### 2.12.16 Text Chat

Text messages can be sent from console to console on any MADI Port that is defined as "**Console**". This definition uses the last 8 audio inputs and outputs on the port to send text or video communications. The default setup of the SD/Q7 defines MADI Port 4 as "Console". With MADI connections from one SD/Q7's Port 4 In/Out to another SD/Q7's Port 4 In/Out, open the **Setup>Text Chat** panel, press the **4:Con** button to activate the link on that port and then type a message. When you press the keyboard **Enter** key, the message will be transmitted and will appear in the other console's Text Chat panel. This process is bidirectional meaning the other console can send messages back in a similar way. This communication can also be achieved across an Optocore connection.



### 2.12.17 Video Link (SD7 & Quantum 7 Only)

The **Setup>Video Link** panel allows the routing of one of several different video signals to the console video screen. The worksurface buttons to select between these 3 sources can be found at the top of the console's centre section and are duplicated at the top of the on-screen panel. There is also a **Self** button to send the console's own camera signal to the screen.



To define the source associated with each button, touch the white label box below the on-screen label and a drop-down menu will appear.

Potential sources include the console's two external video inputs (**Ext 1 & Ext 2**) located on the back panel and any Optocore equipped SD7 engines that are connected. Optocore engines are identified by their Optocore Loop number (normally 1) and their Optocore ID which can be seen and set at the top of the console's **Network** panel).

The lower part of the Video Link panel determines which video source is fed from the console to the video network. Only one source can be sent at one time and this is done by pressing the **Feed** button beneath the required source.

Select the appropriate video format using the **NTSC** and **PAL** buttons, ensuring that all connected consoles are using the same format.

The console's camera feed can also be sent as a **Mirror** image using the on-screen buttons.

## 2.13 External Control

### 2.13.1 iPad Control

The DiGiCo SD/Quantum app allows remote, wireless control of any DiGiCo SD or Quantum mixing console from your Apple iPad.

**To activate iPad Control:**

1. Navigate to **Setup > External Control** from the menu on the main screen
2. Enable External Control by pressing the button at the top of the panel - please disable this function when External Control is not required
3. Press the Add Device button and select DiGiCo Pad
4. Enter a Device Name (user choice) for the device and then enter the IP Address of the iPad 4)
5. Enter Send and Receive Port numbers for the console e.g. Send = 9000 and Receive = 8000 **Note:** If you enter multiple devices in this panel, they must all have unique Send and Receive ports.
6. Tick the Enable column for this device.
7. Press the Load button in the bottom right corner of the panel and select the commands button for the relevant console. There are several different sets of commands, one for SD8, SD9, SD11 and SD12 another for SD5, SD7 and SD10 and others which are specific to Quantum console models.

***NOTE:** Only one set of commands should be loaded at one time and if in doubt about which one is loaded, please press the Clear All button and then reload the relevant commands for your console.*

8. Take note of the console Local IP Address at the bottom of the panel as this information will have to be entered on the Connect page of the DiGiCo iPad App.



Enable External Control

Add device type – DiGiCo Pad

Enter iPad details

Load iPad commands for relevant console (only required on first setup)

The 'External Control' dialog box contains the following sections:

- Enable External Control:** A dropdown menu set to 'YES'. Buttons for 'HUI sensing' and 'Suppress OSC retransmit' are to the right.
- Channel Controllers:** Buttons for 'OSC generic', 'L-ISA', 'd&b', and 'Recall with session'.
- Klang interface:** Buttons for 'KLANG enabled', 'KLANG disabled', 'Recall with session', and 'Load Presets and MIDI events'.
- External Devices:** A table with columns: Type, Name, IP Address, Send, Rcv, Enabled, Bundles. Above the table are 'add device' and 'remove device' buttons. A dropdown menu is open, showing options: 'DiGiCo Pad', 'other OSC', 'KLANG', 'MIDI', 'HUI MIDI', and 'Ross Audio'.
- Local:** A text input field.
- commands allowed:** 'clear all' and 'load' buttons.

The second screenshot shows the 'DiGiCo iPad' entry in the 'External Devices' table with the following details:

Type	Name	IP Address	Send	Rcv	Enabled	Bundles
DiGiCo	iPad	192.168.2.100	8000	9000	✓	

The third screenshot shows the 'Bundles' column of the 'DiGiCo iPad' entry with a dropdown menu open, displaying 'ipad sd7q'.

### 2.13.2 Generic OSC

This feature allows any device that can transmit and receive OSC messages to be connected a desk. The Generic OSC control has 8 rotary and 8 switch controllers that can have their names, values and operating ranges defined in the Generic OSC customise section of the External Control panel.

#### To activate Generic OSC Control:

1. Navigate to **Setup > External Control** from the menu on the main screen.
2. Enable External Control by pressing the button at the top of the panel - please disable this function when External Control is not required.
3. Press the Add Device button and select Generic OSC Device.
4. Change the Input Channel Controller to OSC Generic.
5. Select Other OSC from the drop-down list and then enter a device name, the IP address and Send/Receive ports for the Generic OSC device.

*Note: If you enter multiple devices in this panel, they must all have unique Send and Receive.*

6. Tick the Enable column for this device.
7. Press the Customise button and enter a label, required OSC message, min, max and default values for the relevant control. Press rotaries or switches to view the settings for the 2 sets of 8 controls.

*Note: The first four rotaries can be controlled by the graphical touch controls within the expanded panel.*

8. OSC messages should contain an asterisk (\*) to represent the channel number Eg. /MyDevice/MyParameter/\*

The screenshot displays the 'External Control' panel with the following sections:

- Enable External Control:** YES (selected), HUI sensing, Suppress OSC retransmit.
- Channel Controllers:** OSC generic (selected), L-ISA, d&b, Recall with session. A 'Customise' button is below.
- Klang interface:** KLANG enabled (selected), KLANG bypassed, Recall with session, Link Aux to KLANG levels.
- External Channel Controllers OSC:** A sub-panel with a table for 8 controls.

The 'External Channel Controllers OSC' sub-panel includes a 'RESET WIDTHS' button and a 'CLOSE' button. It features a table with columns for 'rotaries', 'switches', 'rotaries', 'switches', 'Min', 'Max', and 'Default'. The table lists 8 controls (Level, Pan, C, D, E, F, G, H) with their respective OSC messages and ranges.

	rotaries	switches	rotaries	switches	Min	Max	Default
1	Level				0	100	0
2	Pan				-100	100	0
3	C				0	1	0
4	D				0	1	0
5	E				0	1	0
6	F				0	1	0
7	G				0	1	0
8	H				0	1	0

At the bottom of the sub-panel, there is a 'commands allowed:' section with 'clear all' and 'load' buttons.

### 2.13.3 L'Acoustics L-ISA


External Control for an L'Acoustics L-ISA system can be added via this menu, this allows OSC commands to be sent to L-ISA from channel strip controls.

#### To activate L-ISA Control:


1. Navigate to **Setup > External Control** from the menu on the main screen.
2. Enable External Control by pressing the button at the top of the panel - please disable this function when External Control is not required.
3. Change the Input Controller to L-ISA.
4. Press the Add Device button and select L-ISA.
5. Select Other OSC from the drop-down list and then enter a device name, the IP address and Send/Receive ports for the L-ISA device.

*Note: If you enter multiple devices in this panel, they must all have unique Send and Receive*

L-ISA control can be activated on a channel by pressing 'L-ISA Control' at the bottom of the output panel. This will display a small plot of L-ISA pan position on the channel strip itself, this area can be pressed to open L-ISA Source Control panel (right) where L-ISA parameters can be adjusted. This can be hidden by pressing the 'view' button.



Stereo channels can also have L-ISA control, in which they gain another row of rotary controls on the Source Control panel, plus 'pan spread rotary' and 'link' button.




L-ISA groups can be pressed in the 'L-ISA groups' selection to allow them to be controlled from the L-ISA panel.



### 2.13.4 d&b Soundscape Control

Bi-directional control of d&b Soundscape is also available. For remote control to work, a DS100, a computer running d&b ArrayCalc/R1 and a computer running En-Bridge are required.

There is a d&b button in **Setup>External Control**. Adding an **other osc** device will allow communication.



Once enabled in the **External Control** panel, **d&B Control** and **view** buttons will appear in the bottom of Input Channel and Group Output **Output Setup** Panels. When activated for a specific channel, the buttons will have a red background and a Soundscape control will replace the standard channel Pan controller. When the Soundscape control on the channel strip or the **d&b** button on a group is pressed, the Soundscape Control panel will open.



The controls are:-

- Sound Object x Position (rotary)
- Sound Object y Position (rotary)
- Sound Object Spread factor (rotary)
- Sound Object En-Space Send Gain (rotary)
- Sound Object Delay Mode (3 toggle buttons)
- Touch the small x/y position display in the expanded view to further expand the display.
- Touch on the Object Number button to select which sound object that the channel strip shall control.
- Touch on the Mapping button to select which mapping area shall be targeted from the channel strip's controls.

Full details of the integration can be found at [www.dbaudio.com](http://www.dbaudio.com)

2.13.5 KLANG Control

Transmit all stored KLANG parameters to the controller on session load

The KLANG level and aux send level will be stored as the same value (if KLANG is bypassed or disabled, the aux send level will be the KLANG level).

Bypass all KLANG nodes – temporarily reverted to normal aux sends

Enable KLANG control and nodes

Enter the details of the KLANG controller

External Control

Enable External Control: YES

HUI sensing

Suppress OSC retransmit

Channel Controllers: OSC generic L-ISA d&b Recall with session

Klang interface: KLANG enabled KLANG bypassed Recall with session Link Aux to KLANG levels

External Devices

add device remove device

Type	Name	IP Address	Send	Rcv	Enabled	Bundles
KLANG	Klang	192.168.1.4	9111	8200	✓	✓

Local:

commands allowed: clear all load

The KLANG automated setup process can be automated to some extent - Please follow this link for more information - <https://www.klang.com/product/console-integration/>

2.13.6 Spacemap Go control (V17xx+)

DiGiCo and Meyer Sound Laboratories, Incorporated have worked in partnership to provide integrated control of a **Spacemap Go** immersive loudspeaker system from the console interface. Spacemap Go Channels can be associated with console Channels or Groups, with full control of:

**Spacemap Go Panner, Crossfade, Spread** and **Trajectory** transport controls are available from the console for each Spacemap Go Channel. The control view also provides the **Channel name**, both **Spacemap names**, and the **trajectory name** if active.


The Spacemap Server runs on the **GALAXY** network platform processor, and the Spacemap Go iPad app, as well as all external controllers are connected as clients to the server.

This feature is available when using the following software and firmware versions, or more recent releases:

- DiGiCo Console software V1742
- Meyer Sound Compass version 4.13.1, which includes Meyer Sound GALAXY firmware version 2.8.1

- Meyer Sound Spacemap Go version 1.2.2, available at the Apple App Store

Spacemap Go Control will be configured in the DiGiCo console’s **EXTERNAL CONTROL** options tab (**MASTER SCREEN > SETUP > OPTIONS**). In the Channel Controllers panel, select **SpaceMap**.  
Select **Add device** and **other OSC**, then enter the required **IP Address** and **Send/Rcv** port numbers as required. Confirm by pressing in the **Enabled** column.




Control of a Spacemap Go Channel can be enabled on any of the console’s Channel or Groups. Navigate to the channel and open the Controller view by tapping on **CHANNEL > OUTPUT SETUP**, at the bottom of the popover window enable Spacemap Controller, then View. Close the popover and touch on the **2D XY Panner**, the external controls will appear.



The assigned Spacemap Go channel can be changed by clicking on the blue box with the currently assigned Spacemap channel in white.






### Available Controls from the Console Channel or Group.

When the Spacemap Go Control is enabled on a Channel or Group, the path's SPACEMAP CONTROL VIEW of each Channel or Group presents the Spacemap Go control interface. This provides control of the following parameters for the associated Spacemap Go Channel:

- X/Y of Spacemap Panner
- Crossfade
- Spread
- Trajectory Rate
- Trajectory Transport Controls

A 2D panning interface is provided for touch control of the X/Y position of the Spacemap Panner for the assigned Spacemap Go Channel that can be expanded to reveal all of the details.



For more information and connections details please visit <https://spacemap-go-help.meyersound.com/digico/>


### 2.13.7 Adamson AFM control (V17xx+)

Bi-directional control of Adamson's FletcherMachine is also available. This connects via ethernet to the computer running the FletcherMachine Remote.

External Control of an Adamson's FletcherMachine can be added via this menu, this allows OSC commands to be sent to the AFM from channel strip controls.

Select **AFM** Channel Controller in **Setup>External Control**. Select **XY** (cartesian) or **DA** (polar) coordinate mode. **Select Master:** choose a console fader to control the engine's master fader and mute (optional). Select the additional **Layer** that can be controlled from the AFM control panel. Choose whether you want Layer **Recall with session**.

Add **other OSC** device (5321 and 5001 are the default Send and Rcv ports respectively) and make sure the IP address is correct (and in the same subnet as the console) and it is Enabled to allow communication.



When enabled, **AFM Control** and **view** buttons are available in the Channel and Group output setup panels.



When activated, the FletcherMachine Controller will replace the regular pan controller. Touch the trackpad on a channel or the AFM button on a group to open the FletcherMachine Controller, with an expanded view available when touching the trackpad in the controller.

The following controls are available:

- Object X and Y position (rotaries) – XY mode only
- Center object X and Y position (buttons) – XY mode only

- Object Distance and Azimuth values (rotaries) – DA mode only
- Zero object Distance and Azimuth values (buttons) – DA mode only
- Object Amplitude Width factor (rotary)
- Object rendering Mode (3-way toggle button: MIN, FULL, NONE)
- Additional Layer Send Gain (rotary)
- Additional Layer Send On (button)
- FletcherMachine Reverb Send Gain (rotary)
- FletcherMachine Reverb Send On (button)

The following additional controls are available from the expanded controller panel:

- Object number selection (touch)
- Rendering Space selection (touch)

The following additional controls are available for stereo channels and groups:

- Pair (button) to link/unlink object positions of the stereo pair
- Spread factor (rotary) for linked object positions of the stereo pair




For further details please visit [www.adamson-fletcher-machine.com](http://www.adamson-fletcher-machine.com). Please email [fmsupport@adamson.ai](mailto:fmsupport@adamson.ai) in case of questions and/or support requests.


### 2.13.8 Sound Devices Astral Control (V20xx+)

The Sound Devices transmitters have an innovative set of control options, with magnetic switches on their A20 TX belt packs and various control rings for the new A20-Handheld transmitter. With the Astral External control device option, Macros can be programmed to be triggered directly from the transmitter, no matter which of the three receivers are in use.

To configure an Astral controller on the console, first navigate to external control, then select **add device -> Astral**




Check the IP addresses of the Sound Devices hardware and the console.  
You can see console IP in the External Control panel, and the Astral IP in Network menu, under the Control IP header.  
In console External Control, input your IP Address. Note that Send and Receive ports are fixed when using Astral integration.



On the Astral device, enter your Console IP(s).  
This can be done by navigating through:

**Menu -> System -> Macros -> DiGiCo Console List**

Next, set your Device ID. You can have up to 5 pairs of redundant boxes, or 15 single boxes on your network.  
For example, in a system with two Nexus boxes and two consoles/engines, configure the relevant IP addresses on all devices, and set each Nexus box to 1-A and 1-B on both consoles.



## HUI Sensing (Not implemented)

This button blocks the same OSC message from being sent until a new command is sent.

Selecting Bundles in External Devices will enable the transmission of OSC bundles.

## **Chapter 3: Connections & Multiple Console Setups**

3.1 Console Audio Connections

SD/Quantum console external audio connections can be made using either BNC MADI (AES10), Optocore or the DiGiCo Cat5e Connection. There are 2 types of MADI connection available. A DiGiCo Stage rack can be connected to a console via a bi-directional MADI connection will have up to 112 channels (56 in, 56out) of audio plus the control data for the Rack (located on CH57). A Bidirectional standard MADI stream will contain up to 128 channels of Audio (64in, 64out) and can be connected to any 3rd party device that has MADI connection.

A DiGiCo Cat5e connection is a Bidirectional up to 64 Channel I/O interface that uses STP Cat5e Cable with interference suppressors fitted on each end used to connect D-Racks and SD9 and SD11 Consoles, along with MADI-C DMI cards.

3.1.1 Optocore V221

**Card status for Optocore:**

Green tick = this console

Red cross = available

Red cross greyed out = unavailable

System Overview

The V221 DiGiCo Optocore fibre system provides users with a highly flexible system. For correct and safe operation of the system, the basic principles need to be understood.

A DiGiCo fibre loop supports up to 10 SD Engines (5 Redundant Consoles) and 14 Racks. These are identified as follows.

*Note: For more information on Dual Loop Optocore systems please refer to the relevant section of this document*

SD Engines are allocated ID's between 1 and 10. SD/Quantum consoles with 2 Engines are allocated ID's in consecutive pairs; 1&2, 3&4 etc. Consoles with only one engine such as the SD8 only have a single ID. If 2 SD8s are to be configured as a redundant pair, then their ID's should be allocated consecutively, in the same way that SD/Quantum redundant Engines are paired.

SD Racks (and Optocore enabled D-Racks) are allocated ID's between 11 and 24

*Note: SD Racks can be set to Optocore IDs 1 to 10 but the racks will not work on the Optocore loop if set to these values. These values are used for factory testing only.*

As with previous Optocore systems, each device must have a unique ID. Additionally, each device must also be set to run at the same speed. The previous Optocore system was fixed at 1G. The default speed for the Optocore V221 system is 2G.

Each Optocore loop (running at 2G) is capable of 504 channels of audio at either 48k or 96k. On an SD7, up to 2 loops can be operated, providing up to 1008 channels of Optocore I/O

The Optocore Interface card (between Optocore connected devices and the SD/Quantum Engine) supports 496 Input and 496 Outputs. Inter-console IO is also catered for, allowing the transmission of Audio and Video between SD Engines.

This Optocore system allows for many more channels of audio than can be simultaneously routed into and out of the console. The limit of simultaneously routed signals is 384 inputs and 384 outputs, including routing to local IO and MADI connected devices.

The V221 Optocore implementation provides additional functionality and features over the original Optocore system, as follows.

All inputs (to racks) are available to all consoles. However, it is possible for any console to opt-out of inputs, on a per-input card basis. This means that when the channel routing panel is then opened, only the relevant inputs are accessible. This is particularly in a larger shared system.

Output cards can be allocated / assigned to individual consoles. In practice, this means multiple consoles sharing a single SD Rack to have an output card each.

The Optocore system can be “locked” by any console and reconfiguring of the system is then not possible until all consoles have been placed in an unlocked state. Within a large shared system, this protection mechanism ensures that audio cannot be disrupted by another console on the loop.

To configure these allocations, the Optocore system must be mapped. This map tells each device on the loop which fibre channels it is accessing – Racks insert audio onto the loop and consoles extract audio from the loop or vice versa. For this to operate correctly, a map is built telling each device where it inserts signals onto the loop, and where it extracts audio from the loop.

The process of building this map has been made as simple as possible and can be reduced to a few basic steps.

Connect the Consoles and Racks together, as required.

Input cards on the racks must be installed in a single block with no gaps between input cards. (So, if your SD Rack only needs 5 input cards, they must occupy the first 5 slots in the rack)

On every console (SD/Quantum Engine), open Audio IO and press the “Conform All Ports”. This then will populate the Audio IO panel with all the connected devices. Every console must have the same Audio IO panel configuration.

Allocate Rack output cards to consoles as required.


Press the “Remap All Optocore” button.



3.1.2 FOH & Mons sharing a Stage Rack (MADI)

It is possible for 2 SD/Quantum consoles to share the inputs from a remote rack by using the 2 sets of MADI ports on the rack. In this situation, only one of the consoles can control the rack functions such as the analogue gain of the mic pre-amp and the phantom power switching.

The suggested setup for two SD/Q7 consoles which are sharing the same racks is as follows:



When using racks on MADI, because each SD/Q7 & Q8 has 2 engines there is a requirement to split the rack's MAIN and AUX MADI OUT signals to feed the second console's MADI IN ports.

The recommended connection between the Monitor console and Stage Rack is a single MADI OUT from the Stage Rack's AUX MADI connected to the console's MADI 1 IN.

The FOH (Master console) is connected via MADI IN and OUT to the stage rack.

A similar method can be used if the Monitor console requires gain control and the FOH console will track the gain changes.

MADI OUT from the Stage Rack's AUX MADI connected to the FOH console's MADI 1 IN.

The Monitor (Master console) is connected via MADI IN and OUT to the stage rack.

1. Open the **Setup>Audio I/O** panel, select the shared rack port from the port's list (eg Port 1) and then press the **Shared** button for that rack. Do this on both consoles and the rack control functions **Isolate/Receive Only/Full Control** will become available.
2. One console should be fully connected to the racks using the **Setup>Audio I/O** panel's **Full Control** button for the **Shared** racks.
3. The operators should agree on and set a level of analogue gain that provides enough headroom for the required application.
4. The second console should connect to the Shared racks in **Receive Only** mode
5. Gain Tracking (the **Track** buttons at the top of the Input channel screen) can be switched on for the console that is in **Receive Only** mode for all the channels that are being shared.
6. When an analogue gain control is changed on the "Master" console, the "Slave" console's analogue gain should reflect the changes and the digital trim control should compensate for this change by moving by the same amount in the opposite direction.

#### Relative Gain-Tracking - Snapshot Recalls Total Gain

"Relative Gain-Tracking" is implemented as a "Snapshot Recalls Total Gain" option at the bottom of the Snapshot Global Scope panel. When a snapshot recalls an input channel trim, it compares the snapshot's stored analogue gain against the current gain on the channel's input socket. If there's a difference it offsets the value recalled by the trim. This only happens when the socket's rack is in Receive Only, or the analogue gain is not in Recall Scope.


#### 3.1.3 FOH & Mons sharing a stage SD Series Rack (MADI)

When using SD Racks, the setup is very similar, but the rack split from an SD Rack can be achieved without an external splitter. The SD rack has two built in split outputs which can each provide a 56 channel MADI stream at 48KHz. The added advantage of the SD rack split is that it can be set to provide an automatically gain tracked MADI stream. This can be set on the rack itself or from the Audio I/O panel on the console. This means that the receiving console does not need to provide the gain tracking facility.

*Note: The console that is controlling the gains should be set to setup/audio sync = Master and the console that is tracking should be set to setup/audio sync = MADI 1.*

### 3.1.4 FOH & Mons sharing DiGiRacks (Optocore V220)

If 2 SD7's and DiGiRacks are connected via optical fibre, a similar setup can be achieved in the following way:



In this setup, you are limited by Optocore firmware Version 220 to four SD7 engines (2 consoles) and four Optocore connected racks. The system can only run at a sample rate of 48KHz.

Only one of these consoles will be able to use the outputs on Optocore connected racks and this console must be set to Optocore ID1 (Engine A) and ID2 (Engine B), The other console should be set to ID3 (Engine A) and ID4 (Engine B).

These IDs are set from the Network panel in the Master screen.

The four racks can have any Optocore ID in the range ID30 to ID33. In the above example they have ID30 and ID32. These IDs are set on the racks themselves.

The connections that should be made are shown in the diagram, as follows:

The fibre optic cables connect between each device on the optic loop and connect an "A Port" to a "B Port". You should not connect the optic cables in A-A or B-B configurations. The cables connect between each device to form a closed loop. This is necessary for the redundant loop to operate correctly.

The diagram also shows each console having a local MADI connected DiGiRack using BNC MADI cables.

The DiGiRack Main MADI Port is connected to one of the MADI Ports on Engine A and the Aux MADI Port is connected to the same numbered port on Engine B.

Open the **Setup > Audio Sync** panel and set the Sync source to be Optocore. Do this on both engines of both consoles. Save and Send the Session from the A engine on each console to its B engine and Mirror each pair of engines.

Now open the **Setup > Audio IO** panel on the A engine of both consoles and press the **Conform All Ports** button in the bottom left corner. The console will “look” down the connected optical fibre cables and auto discover and conform all the racks it can find. In this example, they will find 2 optic stage racks. This function will be automatically mirrored to the B engine on each console.

In its default setup, none of the Optocore connected DiGiRacks will be defined as shared. This means that either console will be able to control the rack and adjust Mic Amp Gain, Phantom Power, output pads etc.

If you are happy for either desk to control the racks, then you can leave the sessions with these default settings. Making changes to this default state allows you to define the shared status of each rack. If you set a rack to be in full control, then that console will have full control of the rack.


If you set a rack to be in receive only mode, then that console will not be able to make changes to mic amp gain etc but will “see” the changes made by the other console. This is necessary for Gain Tracking to function. The third option is isolate, and when in this mode, the console will not be able to make changes, nor see changes made by someone else. Gain tracking will not work if the rack is set in isolate mode.

To set a console as the master controller for the racks: In the Audio IO Panel, select the appropriate stage rack. Press the **Splits and Sharing** button. In the section titled **Selected Rack**, press the **shared** button. It will default to the Isolate setting. Then press the **full control** button. A warning will remind you that going into full control may affect the live audio. then press **Yes**. If required, repeat this process for the second stage rack.


To set racks to be in receive only mode: In the Audio IO Panel, select the appropriate stage rack. Press the **Splits and Sharing** button. In the section titled **Selected Rack**, press the **shared** button. It will default to the Isolate setting. Then press the **receive only** button. A warning will remind you that your session will change to correctly reflect the actual settings on the rack. then press **Yes**. If required, repeat this process for the second stage rack.

## 3.1.5 FOH &amp; Mons sharing SD Series Racks (Optocore V221)

### CONNECTION WITH OPTICAL FIBRE using SD Racks on Optocore V221



### MONITORS OPTO ID 3 and 4 Audio Sync = Optocore



### FOH OPTO ID 1 and 2 Audio Sync = Optocore

It is possible for up to 5 DiGiCo consoles to share the inputs from remote stage SD Racks using optical fibre cables. It is also possible for the output cards in the SD Racks to be allocated to the consoles on a card by card basis.

The following example describes how to set up 2 consoles with a pair of stage racks in a Front of House & Monitors configuration. The connections that should be made are shown in the diagram, as follows.

The fibre optic cables connect between each device on the optic loop and connect an "A Port" to a "B Port". You should not connect the optic cables in A-A or B-B configurations. The cables connect between each device to form a closed loop. This is necessary for the redundant loop to operate correctly.

The diagram also shows each console having a local MADI connected SD Rack. These are connected using pairs of BNC MADI Cables between one of the MADI ports on the console and the Main MADI ports on the SD Racks. Additional redundant MADI cables can be used, connected the redundant MADI ports on the console to the Aux MADI Ports on the SD Rack.

## Console Setup & Operation

To ensure correct operation of this system, it is necessary to ensure that the console and session settings are correct.

Each optically connected device must have a unique ID. On each console, open the **Network** panel on the Master Screen. From the drop-down list at the top of the panel, set the ID of each console. We would recommend setting the FOH console to ID1 and ID2 and the monitor console to ID3 and ID4. Even numbered IDs are used for Redundant engines in Mirrored engine setups therefore if you were mirroring two single engine consoles, they should be set as ID1 for the FOH console and ID3 as the Monitor console.

Similarly, each SD Rack should have its ID set. Rack ID's start from 11; this example uses Optocore ID's 11 & 12 for the 2 connected racks.

On each console, ensure that the session sample rates are the same. The sample rate is set in the **Files > Session Structure** panel. Open the **Setup > Audio Sync** panel and set the Sync source to be Optocore. Do this on both engines of both consoles. Save and Send the Session from the A engine on each console to its B engine and Mirror each pair of engines. Then open the **Setup > Audio IO** panel on the A engine of both consoles and press the **Conform All Ports** button in the bottom left corner. The console will "look" down the connected optical fibre cables and auto discover and conform all the racks it can find. In this example, they will find 2 optic stage racks.

If the conformed racks in each of the engine's Audio IO panels do not match the other console, then the system will not map correctly. Before the system is mapped, you should allocate any SD Rack output cards. Press the **Setup Optocore** button select / deselect output cards as required. Once this is complete, press the **Remap All Optocore** button.

[For more detailed information on the Optocore Setup, please refer to Optocore\_221\_User\_D.pdf which is available for download from the Support section of the DiGiCo website).

In its default setup, none of the Optocore connected SD Racks will be defined as shared. This means that either console will be able to control the rack and adjust Mic Amp Gain, Phantom Power, output pads etc.

If you are happy for either desk to control the racks, then you can leave the sessions with these default settings. Making changes to this default state allows you to define the shared status of each rack. If you set a rack to be in full control, then that console will have full control of the rack. If you set a rack to be in receive only mode, then that console will not be able to make changes to mic amp gain etc but will "see" the changes made by the other console. This is necessary for Gain Tracking to function. The third option is isolate, and when in this mode, the console will not be able to make changes, nor see changes made by someone else. Gain tracking will not work if the rack is set in isolate mode.

To set a console as the master controller for the racks: In the Audio IO Panel, select the appropriate stage rack. Press the **Splits and Sharing** button. In the section titled **Selected Rack**, press the **shared** button. It will default to the Isolate setting. Then press the **full control** button. A warning will remind you that going into full control may affect the live audio. then press **Yes**. If required, repeat this process for the second stage rack.

To set racks to be in receive only mode: In the Audio IO Panel, select the appropriate stage rack. Press the **Splits and Sharing** button. In the section titled **Selected Rack**, press the **shared** button. It will default to the Isolate setting. Then press the **receive only** button. A warning will remind you that your session will change to correctly reflect the actual settings on the rack. then press **Yes**. If required, repeat this process for the second stage rack.

To set racks to be in receive only mode: In the Audio IO Panel, select the appropriate stage rack. Press the **Splits and Sharing** button. In the section titled **Selected Rack**, press the **shared** button. It will default to the Isolate setting. Then press the **receive only** button. A warning will remind you that your session will change to correctly reflect the actual settings on the rack. then press **Yes**. If required, repeat this process for the second stage rack.

### 3.1.6 4REA4 I/O Control (Optocore V221 and MADI)

An SD/Quantum console can control the IO of a DiGiCo 4REA4 over either MADI or Optocore.

This enables a 4REA4 to be used similarly to a Rack, and as part of an Optocore loop configuration.

***NOTE:** In this configuration the SD/Quantum console must be running at 96KHz to match the sample rate of the 4REA4*

Connect any SD/Quantum console to a 4REA4 with MADI or Optocore and have Rack audio and parameter control of up to 64 IO sockets on Racks connected to the 4REA4.

With an external Rack connected via MADI to the 4REA4, the MADI Mode Selection should be set to “Rack Control” and Rack Control Mode to “Full Control” in order to send control data to the connected Rack.


This is found under the relevant DMI port I/O settings in Engine -> Audio on the 4REA4 controller. A168 Racks can also be controlled in this manner when connected to the 4REA4 via an A3232 port.



With an SD/Quantum console connected via Optocore to the 4REA4, the Input Channel Count and Output Channel Count should be set to the number of channels that need to be controlled. The SD/Quantum console can also be connected via MADI to the 4REA4 with the MADI Mode Selection set to “SD console.”




Tie Lines connecting the MAD1 Rack inputs to the Optocore outputs, Tie Lines can be set up in the other direction to allow output socket control. This creates a link for audio and control data. The whole IO or specific sockets can be tie lined up to a total of 64



Once the 4REA4 has been set up with the correct DMI card settings and Tie Lines are in place, in the SD/Quantum console Audio IO window, a “4REA4 Port” can be added from the Add Port drop down menu and then using the Conform Port function or by using the Conform All Ports function.





This will populate that port with the relevant socket types that have been declared and “tie-lined” in the 4REA4.

When 4REA4 Rack input sockets are subsequently routed into channels on the SD/Quantum console, the relevant analogue gain and +48V controls will be available in those channels. For output sockets, the output pads can be toggled (if applicable) and SRC can be turned on or off on AES outputs.

3.1.7 MADI DMI (SRC) (for consoles with DMI slots)

Sample rate conversion (SRC) is available for DMI MADI cards running V167+. The settings for this are managed in the **audio I/O** panel.

Three sample rates are available to select - **48kHz**, 96kHz **smux** and 96kHz **hispeed**.

The selected sample rate must match the sample rate of the connected device. There is no auto SRC function.

The internal console sample rate and the sample rate of the **connected device** will determine the SRC state shown. It will either show as **SRC active** or **SRC inactive**.

Port Name

MADI

Device Type

MADI 64

Connection

DMI 1

Copy Audio To

listen to copied audio

not connected

1	9	17	25	33	41	49	57	1	9	17	25	33	41	49	57
4:MADI 1	4:MADI 1	4:MADI 1	4:MADI 2	4:MADI 3	4:MADI 4	4:MADI 4	4:MADI 5	4:MADI 1	4:MADI 1	4:MADI 1	4:MADI 2	4:MADI 3	4:MADI 4	4:MADI 4	4:MADI 5
2	10	18	26	34	42	50	58	2	10	18	26	34	42	50	58
4:MADI 2	4:MADI 1	4:MADI 1	4:MADI 2	4:MADI 3	4:MADI 4	4:MADI 5	4:MADI 5	4:MADI 2	4:MADI 1	4:MADI 1	4:MADI 2	4:MADI 3	4:MADI 4	4:MADI 5	4:MADI 5
3	11	19	27	35	43	51	59	3	11	19	27	35	43	51	59
4:MADI 3	4:MADI 1	4:MADI 1	4:MADI 2	4:MADI 3	4:MADI 4	4:MADI 5	4:MADI 5	4:MADI 3	4:MADI 1	4:MADI 1	4:MADI 2	4:MADI 3	4:MADI 4	4:MADI 5	4:MADI 5
4	12	20	28	36	44	52	60	4	12	20	28	36	44	52	60
4:MADI 4	4:MADI 1	4:MADI 2	4:MADI 2	4:MADI 3	4:MADI 4	4:MADI 5	4:MADI 5	4:MADI 4	4:MADI 1	4:MADI 2	4:MADI 2	4:MADI 3	4:MADI 4	4:MADI 5	4:MADI 5
5	13	21	29	37	45	53	61	5	13	21	29	37	45	53	61
4:MADI 5	4:MADI 1	4:MADI 2	4:MADI 2	4:MADI 3	4:MADI 4	4:MADI 5	4:MADI 5	4:MADI 5	4:MADI 1	4:MADI 2	4:MADI 2	4:MADI 3	4:MADI 4	4:MADI 5	4:MADI 5
6	14	22	30	38	46	54	62	6	14	22	30	38	46	54	62
4:MADI 6	4:MADI 1	4:MADI 2	4:MADI 2	4:MADI 3	4:MADI 4	4:MADI 5	4:MADI 5	4:MADI 6	4:MADI 1	4:MADI 2	4:MADI 2	4:MADI 3	4:MADI 4	4:MADI 5	4:MADI 5
7	15	23	31	39	47	55	63	7	15	23	31	39	47	55	63
4:MADI 7	4:MADI 1	4:MADI 2	4:MADI 2	4:MADI 3	4:MADI 4	4:MADI 5	4:MADI 5	4:MADI 7	4:MADI 1	4:MADI 2	4:MADI 2	4:MADI 3	4:MADI 4	4:MADI 5	4:MADI 5
8	16	24	32	40	48	56	64	8	16	24	32	40	48	56	64
4:MADI 8	4:MADI 1	4:MADI 2	4:MADI 2	4:MADI 3	4:MADI 4	4:MADI 5	4:MADI 5	4:MADI 8	4:MADI 1	4:MADI 2	4:MADI 2	4:MADI 3	4:MADI 4	4:MADI 5	4:MADI 5

conform rack

SRC inactive

Connected device at:

48kHz

smux


hispeed

clear all copies

unroute all outputs

3.1.8 Dante 64@96 (for consoles with DMI slots)

The Dante 64@96 DMI card allows the console to route 64 channels to and 64 channels from a Dante network at either 48kHz or 96kHz. The console can have a different internal sample rate to the Dante network by turning ‘Auto SRC’ on. This feature will automatically detect a difference in sample rate (either 48kHz or 96kHz) and activate sample rate conversion.



The current sample rate of the Dante network and console

Toggle Auto SRC on and off      State of Sample Rate Conversion

Clocking

All control and configuration of the Dante interface is done externally by the Dante controller software. A separate control computer must be provided to do this.

The Dante network can be set to use the console as the network system clock (in the Dante Controller software) or the Dante card can be selected as the console clock source.


In the picture below, the Dante Controller software displays a Dante 64@96 DMI card and an A168D rack.


In the Dante Device Config tab, the A168D rack must be set to match the Dante 64@96 DMI card sample rate at 48kHz or 96kHz.

Example 1 - Console is Master clock for Dante Network

In the Dante Clock Status tab, the Dante 64@96 DMI card is set to “Sync To External” and “Preferred Master”. This setup enables the DMI card to take its Audio Sync Source from the console itself and in turn provide sync to the rest of the Dante network. The console would typically be set to sync **MASTER**.

Sample Rate





Display Preferred Master

Set Preferred Master

&

Sync To External


&

Sync To External

Example 2 - Dante Network is Master clock for console

If the console is required to use the Dante network as its sync source the following settings should be applied.

Enable Sync to External = OFF



Sync To  
External = OFF

**Dante IO (V1280+)**

Socket parameters on A168D and A164D IO racks can be controlled in the same way as other DiGiCo I/O racks when connected to a Dante 64@96 DMI card and routed in Audinate's "Dante Controller" software.

With a Dante DMI 64@96 card installed in a console, access to 64 channels of IO to/from the Dante network is provided.

A Dante IO box can provide a specific number of IO on the Dante network according to the rack's capability.

168D = 16 analogue In and 8 Analogue Out

Any Dante network may have many more devices on it than just a single console and rack.

There might be multiple Dante equipped consoles, multiple racks and other Dante devices.

When a console has a Dante DMI fitted, it "sees" that DMI as a 64 channel interface device to/from the Dante network.

The source device of the audio signals it is receiving across that interface and the destination device of any signals that it is sending out across that interface are generally "unknown" to the console.

The critical component in determining where the audio is going to/from is the Dante network controller which is responsible for setting up audio paths (routing) on the network.

As an example, using just a single console and a single rack, the console could use its Dante DMI channel 1 as an input signal to its own console Input Channel 1 but the audio signal which appeared on that DMI Dante channel could be any signal from the Dante IO rack and is determined by the routing in the Dante Controller.

With the following routing in place, a console that selects any of the DMI card channels 1-16 as an input source will receive the signal from the same numbered Rack Input socket – this is a logical setup.

3.1.9 DQ-Rack (for consoles with DMI cards) [V1455+]

*PLEASE NOTE that for the connection and use of the DQ-Rack, there is a requirement for the following firmware updates to the Dante 64@96 DMI card:*

- 1. DMI Dante 64@96 firmware update (v103) which is included in the update package.*
- 2. A Dante firmware update (4.0.20) for the DMI card which can be updated using Dante Updater in Dante Controller.*


Socket parameters on the DQ-Rack can be controlled in the same way as other DiGiCo I/O racks when connected to a Dante 64@96 DMI card and routed in Audinate’s “Dante Controller” software.

With a DMI Dante 64@96 card installed in a console, access to 64 channels of IO to/from the Dante network is provided.

DQ-Rack can provide access to 48 analogue Inputs and 24 analogue outputs.


If the DQ-Rack AES outputs are active, these are accessed using Dante Channels 49-56.

Select DMI DANTE64 device



A168D Rack is a Transmitter in this case.

Each of the 16 Rack input sockets are routed to the same numbered DMI 64@96 channel



Network Switch

Console 1




DMI 64@96 is a Receiver in this case.

Each channel receives the same numbered input socket from the rack

In this example, a console that routes signal to DMI card output channels 1-8 will be sending them to the same numbered Rack Output socket.

Console 1 DMI is a Transmitter in this case.  
Each of the DMI 64@96 outputs 1-8 are routed to same numbered Rack output sockets







3.1.10 MQ-Rack [V1528+]

Socket parameters on the MQ-Rack can be controlled in the same way as other DIGiCo I/O racks when connected to local console MADI or DMI MADI card.

MQ-Rack can provide access to 48 analogue Inputs and 24 analogue outputs.

MQ-Rack provides interchangeable AES outputs on output sockets: 6, 12, 18 and 24. Output sockets can be changed to AES Outs in **Audio I/O** panel found in **Setup>Audio I/O**. Changing an analogue socket to AES will give access to two 2 AES Outs. Changing socket type makes the other type inactive. Audio can be routed to an inactive socket, but no audio will pass until socket type is active.




*Note analogue and AES outputs are switchable from the **Audio I/O** panel on SD/Quantum consoles as of the V1528 release.*

## **Chapter 4: Q8 Specific Features**

## 4.2 Q8 Specific Features

### 4.2.1 Channel Macros (Q8 Only)



Above every channel LCD on the three lower sections of the console, there are two buttons labelled 'a' and 'b'.

These trigger channel macros, which are macros that can be triggered from specific channels. To create a channel macro, go to **Master Screen > Setup > Channel Macros**. This will open the '**Channel Macro Editor**'.

Add a new channel macro from the top left corner of the panel and use the list of commands in the middle to define the functionality of the channel macro. This can also be done by using the '**capture**' command in the top right corner of the panel. On a new channel macro, toggle '**capture**', manually carry out the process that the channel macro is meant to trigger, then toggle '**capture**' again to complete the process. Make sure that the range of channels that the channel macro effects is correct before assigning it to a channel.

To assign a channel macro, select the desired channel, then tap one of the black rectangles labelled 'a', 'b', 'c', and 'd' in the Channel Macro Editor panel. These represent the available slots for channel macro assignment. The selected slot will turn the colour of the assigned channel macro and will display its name. Tapping the same slot again will unassign the channel macro. It is possible to assign the same channel macro to all four slots on a single channel, and to slots on different channels. The name of the selected channel is displayed clearly in the middle of the Channel Macro Editor panel.

There are two ways to trigger channel macros. The worksurface buttons above channel LCDs will trigger any channel macros assigned to slots 'a' and 'b' on that channel and are thus labelled. To trigger channel macros in slots 'c' and 'd', select '**Macros**' from the display options in the top left corner of the screen. This will change the meter view to a channel macro view, where the channel macros in all four slots can be triggered by touch.

*Note: always ensure the correct channel is selected before assigning a channel macro.*

### 4.2.2 Expanded Channel Control Area (Q8 Only)

The Expanded Channel Control Area, positioned between the channel strip and the channel meters, can be used to view and adjust various processing controls for any selected channel. If no channel is selected, it will appear blank, only displaying the DiGiCo logo. Once a channel has been selected, the buttons along the left-hand side of the expanded channel control area can be used to select different '**views**'. These are:

'**Proc**', which displays input processing controls such as gain, trim, DiGiTube, Delay, and Stereo width.

'**EQ**', which displays parametric EQ and Dynamic EQ controls.

'**Dyn**' which displays dynamics such as comp, gate, or ducker.

'**KLANG**' which displays KLANG controls when an aux send is selected.

'**Aux**' which displays controls for Aux send nodes.

At the top of each of these views, there are icons to turn controls on and off, copy processing values, and open the presets panel.

A scrollable list of auxes is displayed at the top of the Expanded Channel Control Area. If there are more than twenty-four auxes, an '**Expand**' button appears on the left-hand side. Pressing it will expand the aux list to occupy the entire Expanded Channel Control Area.


To access the Expanded Channel Control Area on either the centre upper or centre lower sections, select a channel on either section, then press '**Select**' in the top left area of the channel view. Pressing '**Bank**' will toggle back to the channel strip view.

The information displayed in the Expanded Channel Control Area is different based on the type of channel. For instance, output channels will have the option on the right-hand side of their '**EQ**' view to control bands 1-4 or 5-8, and stereo inputs will have additional stereo processing controls in their '**Proc**' view.

On the left-hand side of the Expanded Channel Control Area, there are two side-by-side buttons labelled '**SD**' and '**M**'. These can be used to toggle between SD processing, and Mustard processing. When '**M**', or Mustard, is selected, the top and bottom of the Expanded Channel Control Area will turn yellow to denote that Mustard processing is being viewed. In this instance, '**Proc**' view will display Mustard Tube controls, '**EQ**' will display Mustard EQ controls, and '**Dyn**' will display Mustard dynamics.

The Expanded Channel Control Area can also be used to display Nodal Processing EQ and Dynamics. To do this, select an aux with nodal processing active from the list at the top of the Expanded Channel Control Area. The top and bottom of the Expanded Channel Control Area will turn purple to denote that nodal processing is being viewed. '**EQ**' view will display nodal EQ, and '**Dyn**' will display nodal Dynamics. To exit nodal processing view, select either '**SD**' or '**M**' from the left-hand side of the Expanded Channel Control Area.


SD Input Processing



SD EQ



SD Dynamics




KLANG



Auxes




Mustard Input processing



Mustard EQ



Mustard Dynamics



Nodal EQ



Nodal Dynamics



4.2.3 The Master Faders (Q8 Only)


By default, the left-hand faders in the centre of the workspace are assigned to the Master buss, which is the lowest stereo group output by default.

Also, by default, the right-hand faders are assigned to Matrix 1 and Matrix 2.

In addition, these faders can be reassigned to control any input channel or buss of your choice using the **Layout>Fader Banks** panel

Press the **Assign L1/L2 or Assign R1/R2** buttons and the **Channel List** will be displayed.



Select a channel by touching its entry in the Channel List and it will be assigned to the relevant Master Fader. These faders can also be unassigned (set to empty) by pressing the **Unassign L1/L2 or Unassign R1/R2** buttons





#### 4.2.4 Macroders (Q8 Only)

On every worksurface section, there is a set of four encoders and buttons around an LCD screen under the Dynamics controls. These are macroders, which can be assigned to control any parameter for a selected channel. By default, they are assigned to control aux send nodes 1 to 4.



Macroder functions and controls can be found in the **'Macroder Editor'** panel, which can be accessed by going to **Master Screen > Setup > Macroders**. In the top left corner of the panel, there are three buttons labelled **'New'**, which adds a new macroder, **'Duplicate'**, which duplicates the selected macroder, and **'Delete'** which deletes one or multiple macroders. The list of commands in the middle to define the functionality of the macroder.

This can also be done by using the **'capture'** command in the top right corner of the panel. On a new macroder, toggle **'capture'**, manually change the parameters that the macroder is intended to control, then toggle **'capture'** again to complete the process. At the bottom of the Macroder Editor panel, assign the macroder to one of the worksurface encoders, which are represented by little circles in the same formation as the encoders on the worksurface. Tapping once will assign the macroder to the encoder, and tapping again will unassign it, and leave the encoder blank. Once assigned, the appropriate worksurface encoder will have the colour of the LED ring around it change to match the parameter it affects, and the name of the macroder will appear on the LCD.


Macroders can also be assigned to specific channels, as opposed to any channel on a section of the worksurface. To do this, toggle **'Assign to Channel'** in the bottom left corner of the Macroder Editor panel. This will open a little window that displays the name of the last selected channel, and a schematic of one set of four worksurface macroder encoders. Simply tapping on any one of the four encoders will assign the macroder to the selected channel only. That way, whatever section the channel is on, selecting it will change the assignment of the macroder encoders on that section to match whatever was particularly assigned.

*Note that Macroders are fundamentally different from Macros and Channel Macros in that they don't instantly trigger a set of commands. Instead, they control parameter values as the encoders are turned, much like underscreen rotaries.*

4.2.5 Meterbridge Displays (Q8 Only)



The meterbridge displays differ slightly on the 3 console sections.

All channel displays show the status of various elements of the channel as seen below:



Left display


The left display can also show general console status indicators optionally by selecting this in the **Options > Status** tab



Centre display


The centre display shows both upper and lower banks' meters and also meters for the channels which are assigned to the right and left assignable master faders and both solo busses.

There are also indicators for the **Audio Master** selection, the **Mirroring State** and the **Mirroring Mode**.



## Right display

The right display shows the standard channel view and the output of the console's video system.



### 4.2.6 Layers and Banks (Q8 Only)

The QUANTUM 8's worksurface is divided into Layers and Banks. Each Bank contains twelve channels, and the channels which are currently active on the control surface are defined using the **bank (left column)** and **layer (right column)** buttons on the switcher screen to the right of the channel strip section's faders.

The view in the switcher screen can be locked to prevent accidental changes by holding down on the button in the top left corner of the screen.

It can also be scrolled by swiping to the right to display Snapshot previous and Next buttons. The swipe function can also be locked by touching the button in the top right corner of the screen.



A 'bank' is a set of twelve faders, and a 'layer' contains up to six 'banks'. There are up to six 'layers' on the left, centre lower, and right sections of the desk, and four 'banks' on the centre upper section.

Tapping a **bank (left column)** button on the Switcher screen assigns the channels in that bank to the surface. To access a bank of faders within another layer, tapping the appropriate **layer (right column)** button on the Switcher screen will assign the banks in that layer to the 'banks' column on the Switcher screen. Holding any bank or layer button down for a couple of seconds will switch the left and right worksurface sections to the same bank level or layer.

*NOTE: There is also a Master Screen Assign button next to each set of faders on the centre section which is used to switch the centre section to display the Master Screen.*

The specific channels which are contained within each Bank are defined in the **Layout > Fader Banks** panel. By default, the Input channels will be assigned to Layer 1 on the left and right sections of the console. The different output channels and Control Groups will be assigned to the banks on the centre sections. These bank assignments can be customised by the user in the **Fader Banks** panel and saved in a session at any time.

## **Chapter 5: Quantum Home**


## 5.1 Quantum Home

When the Master screen > System > Quit To Home button is pressed, the console application is closed and the Quantum Home interface can be used to adjust various system settings.

When the system is locked, Quantum Home automatically launches the Quantum application on start-up. When unlocked, the system can be configured.

### 5.1.6 Main Shortcuts


- **Quantum x:** launches the Quantum x application.
- **Quantum Upgrade:** launches the Quantum Upgrade application.
- **Network Settings:** see section on network settings.
- **Surface CPU Upgrade**
- **Quantum Setup:** launches the Quantum Setup application.
- **File Browser:** opens a standard File Explorer.



### 5.1.7 Settings Pane

Click the bottom Settings pane to expand it.


- **Quantum Test:** launches the Quantum Test application.
- **Delete Startup Sessions:** deletes the following start-up files:
  - "D:\Quantumx\startup.ses"
  - "D:\Quantumx\\_session.ses"
- **Show All Windows:** restores all open windows that have been minimised.  
**System Information:** see section on system information.
- **Advanced Settings:** see section on advanced settings.
- **Power:** opens a window with three buttons:
  - **Power Off:** turns the console PC off.
  - **Restart:** reboots the console PC (does not reboot the engine or work-surfaces).
  - **Cancel:** closes the Power windows and returns to the main Quantum Home view.



### 5.1.8 System Information


Opens a window displaying general information about the system:

- **General:**
  - **PC Name:** name of the console PC – the factory default name should contain the serial number of the console.
  - **IP Address:** static IP address of the console PC.
  - **App Version:** version number of the Quantum 8 application.
  - **Home Version:** version number of Quantum Home.
  - **System Version:** version number of the overall system.
- **Disks:**
  - **C Drive:** amount of free disk space on the C:\ drive.
  - **D Drive:** amount of free disk space on the D:\ drive.
  - **Memory:** amount of RAM on the console PC.
- **BIOS:**
  - **BIOS:** version number of the console PC's BIOS.
  - **Firmware:** version number of the console PC's board controller firmware.
- **Save to File:** click to save the system information to a text file. The saved file also contains the “locked/unlocked” state of the PC and a timestamp.






### 5.1.9 Advanced Settings



- **Lock System Settings/Unlock System Settings:** locks/unlocks the system and triggers a console PC reboot.
  - **Locked state:** this is the “console mode” in which Quantum Home automatically launches the Quantum 8 application at start-up.
  - **Unlocked state:** “configuration mode” in which advanced settings and network settings are enabled.
- **Display Settings:**
  - **External Screen:** settings for the external monitor.
    - **Resolution:** drop-down list of available screen resolutions for the external screen.
    - **Orientation:** drop-down list of screen orientations:
      - Landscape.
      - Portrait.
      - Landscape (inverted).
      - Portrait (inverted).
      - Disconnected: disables the external screen.
  - **Configure All:** applies the external screen settings and reconfigures the master, left and right screens. Once configured, Quantum Home identifies the screens, allowing for a visual confirmation of the new display configuration.



Note that Quantum Home will require a restart after displays configuration, either by locking and rebooting the console or by a forced restart of Quantum Home when exiting the Advanced Settings menu.
  - **Identify Displays:** pops up the display identification view on each screen highlighting the current screen position.



- **Quantum Home Update:**
  - **Select File:** opens a file dialog window to browse and open a new QuantumHome.exe file.
  - **Update:** applies the update by replacing the current Quantum Home with the selected file. Triggers a restart of Quantum Home.

### 5.1.10 Network Settings

Requires the system to be unlocked to apply new setting. If the system is locked, the current settings are displayed but cannot be changed.



- **Console IP Address:** shows the current IP address of the console, can be edited to apply a new console IP address.
- **Subnet Mask:** shows the current subnet mask of the console, can be edited to apply a new console subnet mask.
- **Apply:** applies the network settings (console and engine IP addresses and subnet mask).
- **Lock & Restart:** is enabled after network settings have been applied. Causes the console PC to restart and locks the system.

### 5.1.11 Keyboard Shortcuts

- Hold **"Space"** at start-up: boots to Quantum Home without launching the Quantum application.

## **Chapter 6: DMI Cards**

The DiGiCo QUANTUM consoles and the SD12 have two option slots on their rear panel for the installation of DMI cards (see below).

These cards come in a variety of I/O types




DMI Slot 1    DMI Slot 2


## 6.1 Fitting DMI Cards

*NOTE: DMI cards are NOT hot swappable and therefore they should NEVER be fitted or removed from the console while the console is powered on.*

To fit a DMI card:



DMI Internal Socket




Card fits in slider grooves

Remove the four screws from the console blanking plate and this will expose a hole in the rear panel with an internal connector and a white slider on each side of the hole. Keep the four screws safe in order to secure the card in place.

*NOTE: Before fitting the DMI card, carefully examine the internal connector as in some cases this may have a protective cover that must be removed before fitting the card. If the cover is present, please remove it before proceeding*

*NOTE: With the DMI-MADI C there are 2 internal switches that must be set to the A position for use in the console. Please check these switch positions (as picture below) before fitting the card.*



- 1) Carefully slide the DMI card in the hole using the white slider grooves as a guide and then ensure that it pushes into the internal connector correctly with a click.
- 2) Replace the 4 fitting screws.

## 6.2 DMI-MADI Cards

There are 2 types of DMI-MADI Card:

**MADI B has 2 pairs of BNC connectors**

**MADI C has 2 bi-directional Cat5e connectors**

Both of these cards can be used to connect a Standard MADI stream at 48KHz or 96KHz or an SD-Series DiGiCo Rack with the appropriate connector (D-Rack, D2-Rack, SD-Rack, SD-MiNiRack).

*NOTE: Only one DiGiCo Rack can be connected to a single DMI-MADI card at one time.*

### 6.2.1 Connecting DMI-MADI

External audio connections can be made using either BNC MADI (AES10) or the DiGiCo Cat5e Connection.

There are 2 types of MADI connection available. A DiGiCo Stage rack can be connected to a console via a bi-directional MADI connection will have up to 112 channels (56 in, 56 out) of audio plus the control data for the Rack (located on CH57). A bi-directional standard MADI stream will contain up to . channels of Audio (64 in, 64 out) and can be connected to any 3rd party device that has MADI connectivity.

A DiGiCo Cat5e connection is a bi-directional up to 64 Channel interface that uses STP Cat5e Cable with interference suppressors fitted on each end used to connect D-Racks and D2-Racks.

**Please carefully note the following connection requirements:**

#### DMI-MADI C to D-Rack at 48KHz



Connect DMI card Cat5e socket A to D-Rack Cat5e socket.

#### DMI-MADI C to D-Rack at 96KHz

Connect DMI card Cat5e socket A to D-Rack Cat5e socket.

*NOTE: This setup provides one 28 channel 96kHz MADI stream therefore D-Rack input sockets 29-32 will not pass audio.*



Single Console to D-Rack with DMI MADI C Card



DMI-MADI C to D2-Rack at 48kHz

Connect DMI card Cat5e socket A to D2-Rack Cat5e Main socket.

Single Console to D-Rack with DMI MADI C Card




**DMI-MADI C to D2-Rack at 96kHz**

Connect DMI card Cat5e socket A to D2-Rack Cat5e MAIN socket.

Connect DMI card Cat5e socket B to D2-Rack Cat5e AUX socket.

**Single Console to D2-Rack with DMI MADI C Card at 96KHz**




**DMI-MADI B to D2-Rack, SD-Rack or SD-MiNiRack at 48kHz**

Connect DMI card BNC IN socket A to D2-Rack BNC OUT MAIN socket.

Connect DMI card BNC OUT socket A to D2-Rack BNC IN MAIN socket.

**Single Console to D2-Rack with DMI MADI B Card at 48KHz**




**DMI-MADI B to D2-Rack, SD-Rack or SD-MiNiRack at 96kHz**

Connect DMI card BNC IN socket A to D2-Rack BNC OUT MAIN socket.

Connect DMI card BNC OUT socket A to D2-Rack BNC IN MAIN socket.

Connect DMI card BNC IN socket B to D2-Rack BNC OUT AUX socket.

Connect DMI card BNC OUT socket B to D2-Rack BNC IN AUX socket.

**Single Console to D2-Rack with DMI MADI B Card at 96KHz****DMI-MADI B to a Standard MADI device at 48kHz**

Connect DMI card BNC IN socket A to Standard MADI device BNC OUT.

Connect DMI card BNC OUT socket A to Standard MADI device BNC IN.

**DMI-MADI B to a Standard MADI device at 96kHz**

Connect DMI card BNC IN socket A to Standard MADI device CH 1-32 BNC OUT.

Connect DMI card BNC OUT socket A to Standard MADI device CH 1-32 BNC IN.

Connect DMI card BNC IN socket B to Standard MADI device CH 33-64 BNC OUT.

Connect DMI card BNC OUT socket B to Standard MADI device CH 33-64 BNC IN.



### 6.2.2 Sharing Racks with DMI-MADI

If the system is running at a sample rate of 48KHz a D2-Rack, SD-Rack or SD-MINIRack can be shared between 2 consoles (Two QUANTUM 8s or an QUANTUM 8 and another S or SD-Series console) with the connection system shown below.

#### In this setup:

- 1) All inputs can be shared by the two consoles but only one console controls the rack analogue gains (the "Master" console)
- 2) The console which is not controlling the gains (the "Slave" console) can automatically adjust its digital trims to compensate for the gain changes using a system known as "Gain Tracking" (see below)
- 3) Only the "Master" console can use the outputs of the shared rack

The recommended connection between the Monitor (Slave) console and Stage Rack is a single MADI OUT from the Shared Rack's AUX MADI connected to the console's MADI A IN

The FOH (Master console) is connected via MADI A IN and OUT to the stage rack.

A similar method can be used if the Monitor console requires gain control and the FOH console will track the gain changes.

MADI OUT from the Shared Rack's AUX MADI connected to the FOH console's MADI A IN.

The Monitor (Master console) is connected via MADI A IN and OUT to the stage rack.

*Note: The "Master" console should be set to provide "Master Sync" (Setup>Audio Sync menu - see diagram below) to the Shared rack*

*The "Slave" console should be set to receive its Audio Sync from the MADI DMI slot that is connected to the Shared Rack.*


- 1) The operators should agree on and set a level of analogue gain that provides enough headroom for the required application.
- 2) The second console should connect to the Shared rack in **Receive Only** mode (only MADI Input cable connected)
- 3) **Gain Tracking** (the **GT ON/OFF** button at the top of the Input channel setup view) can be switched on for the console that is in

"**Receive Only**" mode for all the channels that are being shared.

- 4) When an analogue gain control is changed on the "Master" console, the "Slave" console's analogue gain should reflect the changes and the digital trim control should compensate for this change by moving by the same amount in the opposite direction.

*IMPORTANT Note: If Gain Tracking is active on a channel, the digital trim control will still respond to the local gain adjustment by compensating locally for the displayed gain change.*

*If the "Slave" console loads a session where the Analogue Gain and +48V settings do not match the current state of the racks, the Master console should then reload its session to update the state of these controls on the "Slave" console*

**FOH & MONITORS WITH SHARED RACK at 48KHz USING MADI**

If the system is running at a sample rate of 48KHz, a D-Rack can also be shared between 2 consoles (Two QUANTUM 8s or an QUANTUM 8 and another SD-Series console with Cat5e connections eg SD9 or SD11) with the connection system shown below.

This setup is similar to the one previously described but requires a DiGiCo Little Red Box.

The Little Red Box has separate Cat5e connections for:


The D-Rack itself

The FULL CONNECT "Master" console

The RECEIVE ONLY "Slave" console

In all other respects the setup is the same as that for the D2-Rack and SD-Rack

SHARING A D-RACK at 48KHz USING MADI



## 6.3 DMI - Dante Cards

A **DMI-Dante 64@96** DMI card provides 64 input and 64 output channels at 48kHz or 96kHz, along with support for SRC (Sample Rate Conversion). This enables the desk to run at a different sample rate to the Dante network.



Sample rate conversion can be enabled in the Audio IO panel by enabling 'Auto SRC'. This will automatically switch on when necessary to convert the sample rate of the desk inputs and outputs to match the Dante network's sample rate e.g. the Dante network at 96kHz and console structured at 48kHz. SRC will not affect the number of input and output channels that can be routed.

For both Dante cards, all control and configuration of the Dante interface is done externally by the Dante controller software. A separate control computer must be provided to do this.

In S-Series, the Dante network can be set to use the console as the network system clock (in the Dante Controller software) or the Dante card can be selected as the console clock source.

In the picture below, the Dante Controller software displays two DiGiCo DMI Dante devices.

The second device in the list is installed in an QUANTUM 8 and has been manually labelled "DiGiCo QUANTUM 8".

In the Dante Device Config tab the QUANTUM 8 DMI-Dante card must be set to match the QUANTUM 8 sample rate at 48KHz or 96KHz

### Example 1 - Console is Master clock for Dante Network

In the Dante Clock Status tab, the QUANTUM 8 DMI-Dante card is set to Sync To External and Preferred Master.

This setup enables the DMI-Dante in the QUANTUM 8 to take its Audio Sync Source from the console itself and in turn provide sync to the rest of the Dante network. The console would typically be set as Audio Master in the Main Menu > Audio Sync panel

The figure consists of three screenshots from the Dante Controller software interface, illustrating the configuration for the QUANTUM 8 DMI-Dante card.


- Left Screenshot (Device View):** Shows the 'Device Config' tab for the 'DIGIC621' device. The 'Sample Rate' is set to '48K'. A red box highlights the 'Sample Rate: 48K' dropdown menu. A red arrow points from the text 'Sample Rate' to this dropdown.
- Top Right Screenshot (Network View):** Shows the 'Clock Status' tab. A table lists devices and their clock sources. The 'DIGIC621' device is highlighted with a red box, showing its 'Clock Source' as 'External Clock' and 'Primary Status' as 'Master'. A red arrow points from the text 'Display Preferred Master & Sync To External' to this row.
- Bottom Right Screenshot (Audio Sync panel):** Shows the 'Audio Sync' panel. The 'active sync source' is set to 'primary' (MASTER). A red box highlights the 'MASTER' button. A red arrow points from the text 'Console Master Audio Sync' to this button.

Additional annotations include a red box around the 'Preferred Master' and 'Enable Sync To External' checkboxes in the top right screenshot, with a red arrow pointing from the text 'Set Preferred Master & Sync To External' to them.


Example 2 - Dante Network is Master clock for console

If the console is required to use the Dante network as its sync source the following settings should be applied.

Enable Sync to External = OFF




Sync To External = OFF



Console External DMI Sync

## 6.4 DMI - ADC - DAC - MIC - AES Cards



The **DMI-ADC** card provides 16 analogue inputs on 2 x 25 way "D" connectors.

The ADC card is a line card only. There is no microphone amplifier or phantom power available.

The S-series consoles have no gain control function for these inputs (only digital trim). Maximum input level +22dBu.

The **DMI-DAC** card provides 16 analogue outputs on 2 x 25 way "D" connectors.

DAC card is line level only. Maximum output level +22dBu (Digital Full Scale).

The **DMI-MIC** card provides 8 microphone pre-amps on 1 x 25 way "D" connector.

The S-Series consoles have control over phantom power, gain and pad on the card.

The **DMI-AES** card provides 16 Inputs (8 pairs) and 16 outputs (8 pairs) on 2 x 25 way "D" connectors.

All AES inputs are provided with sample rate conversion (SRC) by default.

All AES outputs are synchronised to the mixer system clock.

### Multi-Pin Connector Pinouts

The DMI module range use 25 way "D" connectors, Female on the module (Male required on the connecting cable). The pins connections are as follows.

Analogue inputs and outputs			
Sorted by pin		Sorted by function	
Function	Pin	Function	Pin
8+	1	0	2
0	2	0	5
7-	3	0	8
6+	4	0	11
0	5	0	16
5-	6	0	19
4+	7	0	22
0	8	0	25
3-	9	1-	12
2+	10	1+	24

AES-EBU combined in/out			
Sorted by pin		Sorted by function	
Function	Pin	Function	Pin
4out+	1	0	2
0	2	0	5
3out-	3	0	8
2out+	4	0	11
0	5	0	16
1out-	6	0	19
4in+	7	0	22
0	8	0	25
3in-	9	1in-	12
2in+	10	1in+	24

0	11		2-	23		0	11		1out-	6
1-	12		2+	10		1in-	12		1out+	18
nc	13		3-	9		nc	13		2in-	23
8-	14		3+	21		4out-	14		2in+	10
7+	15		4-	20		3out+	15		2out-	17
0	16		4+	7		0	16		2out+	4
6-	17		5-	6		2out-	17		3in-	9
5+	18		5+	18		1out+	18		3in+	21
0	19		6-	17		0	19		3out-	3
4-	20		6+	4		4in-	20		3out+	15
3+	21		7-	3		3in+	21		4in-	20
0	22		7+	15		0	22		4in+	7
2-	23		8-	14		2in-	23		4out-	14
1+	24		8+	1		1in+	24		4out+	1
0	25		nc	13		0	25		nc	13

**Pinout and connection notes:**

0 = earth/ground or screen/shield      nc = not connected      + = phase/hot    - = antiphase/cold

Analogue connections for input and output are connected in the same way, as shown.

Analogue connections for channels 1-8 shown, channels 9-16 follow the same pattern (1 = 9, 2 = 10 etc.).

AES connections are shown as 4 stereo (2 channel) connections, equivalent to channels 1-8.

AES connections for stereo connections 1-4 (ch 1-8) shown, connections stereo 5-8 (ch 9-16) follow the same pattern (1 = 5, 2 = 6 etc.).

## 6.5 DMI - Waves - Hydra Cards



**DMI-Waves** has 64 Inputs and 64 Outputs at both 48kHz and 96kHz - there is no control from the console, just simple routing of audio inputs and outputs.

Configuration of this card on the Waves network is done with Waves own software and Control Panels - please refer to Waves own documentation for SoundGrid Studio, Waves MultiRack or Waves SuperRack.


**DMI-Hydra** has 56 inputs and 56 Outputs and only functions when the console is at a sample rate of **48kHz** - there is no control from the console, just simple routing of audio inputs and outputs.

The ID of the card on the Hydra network can be changed from the console by touching the **Set Network ID** button, entering a new number using the on screen keyboard and the power cycling the console.

Configuration of this card on the Hydra network is done with Calrec's own software and Control Panels - please refer to Calrec's own documentation for details.

**IMPORTANT NOTE:** If a DMI Hydra card is used in the **QUANTUM 8**, the console **MUST** be set to **Clock Master**.

*The Hydra DMI cannot be used as a clock source for the console itself.*





## 6.6 DMI - ME - A3232 Cards



The **DMI-ME** provides 40 outputs at 48kHz and 96kHz to Allen & Heath ME-1 or ME-500 Personal Mixers. There are no controls on the card.

The **DMI-A3232** allows connection to A168 STAGE Racks. Each Cat5 port supports up to 32 I/O, for a total channel count of 64 I/O. The rack can be run in two different modes. In Cascade Mode, up to two A168 racks can be connected to each port. In redundant mode, one A168 rack can be connected with redundant cabling to both ports on the card. When a DMI-A3232 is connected, each rack connected will be shown in a different view. The mode is changed by touching the desired mode in the **Port Control Mode** section.

QUANTUM 8 consoles have control over gain, phantom power and pads of the rack.

*NOTE: When changing the Port Control Mode, there is a physical switch on the A168 STAGE racks that must also be changed.*

*NOTE: The primary and secondary ports on the racks are not interchangeable. The primary port must be used as the main connection.*

6.7 DMI – AMM

Quantum 852, Quantum 338 and SD12 are compatible with the DMI-AMM card. The DMI-AMM card automatically manages live microphones in unpredictable dialogue situations. When one person speaks, that microphone’s gain level fades up instantly, while the other microphone gains are reduced. When the speaker pauses, all microphone levels will adjust to medium gain to collectively match the level of one microphone at full gain. The resulting effect will be as if all speakers are sharing one microphone. When several people talk at once, the gain is shared. The AMM Controls (**Figure 1**) can be found in the Audio I/O window after conforming the DMI card (**Figure 2 & 3**).




Figure 1: AMM Control Window

Each of the 64 slots within the AMM control panel include a group assign (Group A & Group B) and a weight control. The Floor control of each group imposes a lower limit on the level detector for all microphones assigned to that group, this prevents a noisy microphone from receiving a disproportionate share of gain. The Floor should be left at the default value of -130dB for normal operation.




Figure 2: Conform AMM




Figure 3: Open AMM Control

There are two ways to route channels to the AMM. The first is from within the AMM Control window itself. Touch the white box below each of the slots, this will open the AMM Routing window (**Figure 4**). Here you can ripple route channels to the AMM, using touch turn to select the desired number of channels. The AMM is automatically assigned a post-fader Insert B. Therefore, AMM can also be assigned in a way that DiGiCo users will be more familiar with, via the Insert B routing window at the bottom of a channel strip (**Figure 5**).



Figure 4: Routing Within AMM Control




Figure 5: Routing via Insert B Routing Menu

When channels are routed to the AMM and assigned to a group, a **Share %** bar is seen in yellow on the right side of an AMM slot. This represents the gain Share that the channel is getting when the AMM is active. This meter is shown in terms of percentage, meaning that if 2 speakers stop talking at the same time then they will both get 50% of the gain share. The Weight control allows adjustment of the relative sensitivity on a per channel basis. When weighting controls are balanced (equal), each microphone has an equal opportunity to “take over” the system. Changing the weight will not have an effect on the overall level of the channel, just how easily it can take a share of the gain. Adding weight to one primary microphone ensure that the particular microphone (e.g. a chairperson) will get more of the share of gain (**Figure 6**).




Figure 6: AMM Share Percentage and Weights

There are a set of master controls available at the bottom of the AMM Control window. These include a Floor control for each AMM group within the card and a safe control. The Floor control imposes a lower limit on the level detector for all microphones assigned to the relevant AMM group. This prevents a noisy microphone from receiving a disproportionate share of gain. The Floor should be left at the default value of -130dB for normal operation. The safe option excludes these floor controls from snapshots.




Figure 7: AMM Master Controls

All AMM parameters (both master and channel specific) are saved on a per snapshot basis and can be safed or removed from the global scope. Only input channels can be added to the AMM. It can be saved globally via the Input Devices option in the Global Scope menu on the Snapshots window. This is **NOT** enabled by default.

Global Snapshot Scope

CLOSE

channel types	input/trim		delay		filters		eq		dynamics		inserts		sends		fader		mute		panner		to groups		outputs		external	
	recall	update	recall	update	recall	update	recall	update	recall	update	recall	update	recall	update	recall	update	recall	update	recall	update	recall	update	recall	update	recall	update
Input devices	✓	✓																								
Input Channels	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
Aux Outputs	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓			✓	✓	✓	✓					✓	✓		
Group Outputs	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓			✓	✓	✓	✓		
Control Groups															✓	✓	✓	✓								
FX	✓	✓																								
Matrix Inputs	✓	✓											✓	✓												
Matrix Outputs	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓			✓	✓	✓	✓					✓	✓		
Graphic EQ							✓	✓																		
Output devices																							✓	✓		

snapshot recalls

TOTAL gain

✗

included for auto-update: IO Devices - analog gains & switches, phantom power

midi

☀

✓

gpo relays

⚡

✓

Figure 8: Global Scope > Input Devices

6.8 DMI KLANG




The Card provides 64 sends from the console and returns 16 stereo binaural mixes plus a stereo solo (34 Channels).

From the control panel, the card’s network details can be viewed. There are 2 modes, Dynamic, where the cards IP is set by DHCP; and Fixed IP, where the IP address, Subnet Mask and Gateway (if required) can be defined.

All of these settings are also available in KLANG:app.

For Firmware details please see <https://www.klang.com/en/downloads>


6.9 DMI AVB



This Milan Certified card provides 64 input and 64 output channels at both 48kHz & 96kHz.

There are threee sample rate modes, 48kHz, 96kHz and Mixed mode which allows a 96KHz device to share AVB streams with other devices set to 48KHz but this will require additional configuration.

Consoles with DMI slots offer the facility to add a DMI AVB port type and this also provides a DMI AVB Control panel where The AVB card sample rate and mode can be selected.



Firmware updates for DMI AVB are done via the AVB Update Tool.

Further information on DMI AVB is available in TN632 – [DMI AVB User Guide](#).